



Minimotorkatalog

Briggs & Stratton
Hatz
Honda
Iseki
John Deere
Kawasaki
Kohler
Kubota
Lombardini
Mitsubishi
Robin
Stihl
Yanmar m.m.



 **Filtertechnik A/S**

ACME		AS-MOTOREN	BRIGGS & STRATTON
10199 Luftfilter Erstatter 359121 H: 33 mm U: 188 mm I: 80 mm 		20086 Luftfilter Erstatter E07545 H: 66 mm U: 63 mm I: 36 mm 	1037 Luftfilter H: 170 mm U: 42 / 45 mm I: 32 / 0 mm Inderfilter for AF25550 
13294 Luftfilter Erstatter 359129 H: 41 mm U: 143 mm I: 64 mm 		20187 Luftfilter Erstatter 4221 H: 73 mm U: 70 mm I: 38 mm 	13265 Luftfilter H: 82 mm U: 114 / 79 mm I: 98 / 63 mm 
50079 Fuelfilter Erstatter 175102 H: 72 mm U: 37 mm I: 15/8 mm 		ASPERA	
59930 Fuelfilter Erstatter 391012300 H: 69 mm U: 50 mm I: M 14X1.5/0 mm 		13025 Luftfilter Erstatter 2341-0030 H: 21 mm U: 180 mm I: 54 mm Forfilter er 13295 	13336 Luftfilter Erstatter 799579 H: 22 mm U: 107/83 mm I: 45 mm 
30228 Oliefilter Erstatter 175005300 H: 65 mm U: 23 mm I: 10 mm/By-pass 		13286 Luftfilter Erstatter 2341-0028 H: 60 mm U: 129/61 mm I: 92/26 mm 	10761 Luftfilter Erstatter 796031 H: 128 mm U: 78/78 mm I: 36/0 mm 
30228 Oliefilter Erstatter 175005300 H: 65 mm U: 23 mm I: 10 mm/By-pass 		13287 Luftfilter Erstatter 23410026 H: 29 mm U: 145 mm I: 39 mm 	10342 Luftfilter Erstatter 796032 H: 100 mm U: 78/78 mm I: 36/0 mm 
AS-MOTOREN		BRIGGS & STRATTON	
11040 Luftfilter Erstatter 12576247-168-002 H: 68 mm U: 64 mm I: 38 mm 		5571 Brændstoffilter Erstatter 541037.2 H: 60 mm U: 19 mm I: 5 mm 	13327 Luftfilter Erstatter 797032 H: 95 mm U: 124/73 mm I: 46/5 mm 
15390 Luftfilter H: 70 mm U: 64 mm I: 38 mm 		AF25550 Luftfilter Erstatter 820263 H: 186 mm U: 89 mm I: 48 / 0 mm Inderfilter er 1037 	13168 Luftfilter Erstatter 790388 / 792038 H: 53 mm U: 120 / 77 mm I: 52 / 0 mm 

BRIGGS & STRATTON	BRIGGS & STRATTON	BRIGGS & STRATTON
13001 Luftfilter Erstatter 270843 H: 38 / 9 mm U: 238 / 227 mm l: 114 / 98 mm 	13011 Luftfilter Erstatter 272235 H: 31 / 9 mm U: 150 / 135 mm l: 90 / 79 mm 	13029 Luftfilter Erstatter 491384 H: 35 mm U: 175 mm l: 87 mm  Forfilter er 13268
13002 Luftfilter Erstatter 270987 H: 37 / 9 mm U: 142 / 125 mm l: 114 / 96 mm 	13012 Luftfilter Erstatter 270067 H: 36 / 10 mm U: 143 / 125 mm l: 94 / 75 mm 	13030 Luftfilter Erstatter 491950 H: 70 mm U: 140 / 65 mm l: 100 / 25 / 8 mm  Forfilter er 13013
13003 Luftfilter Erstatter 270447 H: 37 / 6 mm U: 149 / 133 mm l: 105 / 89 mm 	13013 Forfilter Erstatter 272218 H: 5 mm U: 160 mm l: 70 mm  Forfilter for 13030	13031 Luftfilter Erstatter 491021 H: 77 mm U: 165 / 69 mm l: 123 / 25 / 9 mm  Forfilter er 13032
13004 Luftfilter Erstatter 270579 H: 36 / 7 mm U: 133 / 119 mm l: 87 / 73 mm 	13027 Luftfilter Erstatter 397795 H: 23 mm U: 162 mm l: 112 mm  Forfilter er 13110	13032 Forfilter Erstatter 492947 H: 4 mm U: 160 mm l: 73 mm  Forfilter for 13031
13005 Luftfilter Erstatter 270528 H: 40 / 7 mm U: 214 / 195 mm l: 110 / 94 mm 	13028 Luftfilter Erstatter 399877 H: 22 mm U: 117 mm l: 117 mm 	13033 Luftfilter Erstatter 491519 H: 67 mm U: 215 / 67 mm l: 183 / 33 / 8 mm  Forfilter er 13034
13006 Luftfilter Erstatter 270848 H: 36 / 10 mm U: 137 / 122 mm l: 100 / 83 mm 	11028 Luftfilter Erstatter 491588 / 399959 H: 22 mm U: 131 mm l: 112 mm  Forfilter er 10280	13034 Forfilter Erstatter 271962 H: 6 mm U: 207 mm l: 66 mm  Forfilter for 13033
13010 Luftfilter Erstatter 270251 H: 37 / 7 mm U: 148 / 131 mm l: 91 / 74 mm 	10280 Forfilter Erstatter 491435 / 271933 H: 10 mm U: 128 mm l: 107 mm  Forfilter for 11028	13035 Luftfilter Erstatter 392286 H: 61 mm U: 126 mm l: 89 mm  Forfilter er 13224



BRIGGS & STRATTON	BRIGGS & STRATTON	BRIGGS & STRATTON
13036 Luftfilter Erstatter 805113 H: 20 mm U: 180 mm l: 160 mm  Forfilter er 13037	13058 Luftfilter Erstatter 710266 H: 27 mm U: 211 mm l: 101 mm  Forfilter er 13219	13109 Luftfilter Erstatter 494586 H: 56 mm U: 101 / 62 mm l: 64 / 25 / 8 mm  Forfilter er 13232
13037 Forfilter Erstatter 805267 H: 7 mm U: 172 mm l: 150 mm  Forfilter for 13036	10273 Luftfilter Erstatter 497725 H: 80 / 75 mm U: 102 / 61 mm l: 66 / 26 mm  	13110 Forfilter Erstatter 399039 H: 4 mm U: 152 mm l: 104 mm  Forfilter for 13027
13038 Luftfilter Erstatter 494511 H: 29 mm U: 175 mm l: 87 mm  Forfilter er 13268	13083 Luftfilter Erstatter 499486 / 695667 H: 38 mm U: 183 mm l: 148 / 108 mm  	13124 Luftfilter Erstatter 613541 / 622942 H: 37 mm U: 225 mm l: 80 mm  Forfilter er 15446
13039 Luftfilter Erstatter 496077 H: 33 mm U: 174 mm l: 86 mm  Forfilter er 13268	AF25351 Luftfilter Erstatter 541061-2 H: 173 mm U: 126 mm l: 65 / 9 mm  	13135 Luftfilter Erstatter 390492 H: 76 mm U: 97 mm l: 33 mm  Forfilter er 13248
13050 Luftfilter Erstatter 493910 H: 63 mm U: 183 / 66 mm l: 153 / 36 / 10 mm  Forfilter er 13216	13099 Luftfilter Erstatter 692446 H: 81 / 75 mm U: 102 / 61 mm l: 66 / 26 mm  Forfilter er 13251	13152 Luftfilter Erstatter 692496 H: 75 mm U: 102 / 61 mm l: 66 / 26 mm  Forfilter er 13251
13051 Luftfilter Erstatter 493909 H: 77 mm U: 183 / 65 mm l: 153 / 36 / 10 mm  Forfilter er 13217	10057 Luftfilter Erstatter 692519 H: 57 mm U: 197 mm l: 140 mm  Forfilter er 14955	13155 Luftfilter Erstatter 697152 H: 38 mm U: 184 mm l: 79 mm 
13056 Luftfilter Erstatter 270093 H: 80 mm U: 125 mm l: 33 mm  	13107 Luftfilter Erstatter 392308 H: 70 mm U: 71 mm l: 33 mm  Forfilter er 13230	13285 Luftfilter Erstatter 396424 H: 71 mm U: 71 mm l: 32 / 5 mm 

BRIGGS & STRATTON	BRIGGS & STRATTON	BRIGGS & STRATTON
13291 Luftfilter Erstatter 393725 H: 65 mm U: 130 / 84 mm I: 103 / 58 mm 	13224 Forfilter Erstatter 270973 H: 8 mm U: 176 mm I: 65 mm Forfilter for 13035 	13251 Forfilter Erstatter 273356 H: 4 mm U: 119 mm I: 68 mm Forfilter for 10273 / 13099 / 13152 
13292 Luftfilter Erstatter 393406 H: 56 mm U: 134 / 78 mm I: 109 / 52 mm 	13302 Forfilter Erstatter 273638 H: 6 mm U: 170 mm I: 90 mm 	13257 Forfilter Erstatter 270782 H: 5 mm U: 153 mm I: 98 mm Forfilter for 10201 
10201 Luftfilter Erstatter 393959 / 390930 H: 94 mm U: 108 mm I: 51 mm Forfilter er 13257 	14955 Forfilter Erstatter 692520 H: 9 mm U: 297 mm I: 64 mm Forfilter for 10057 	13259 Luftfilter Erstatter 392642 H: 57 mm U: 176 mm I: 140 mm Forfilter er 13246 
13268 Forfilter Erstatter 492889 H: 9 mm U: 162 / 148 mm I: 74 / 58 mm Forfilter for 13038 / 13029 	13230 Forfilter Erstatter 271466 / 270979 H: 9 mm U: 114 mm I: 77 mm Forfilter for 13107 	13260 Luftfilter Erstatter 394019 H: 64 mm U: 246 / 87 mm I: 209 / 50 mm Forfilter er 13246 
13216 Forfilter Erstatter 272477 H: 3 mm U: 170 mm I: 60 mm Forfilter for 13050 	13232 Forfilter Erstatter 272533 H: 6 mm U: 122 mm I: 47 mm Forfilter for 13109 	FF 149 Fuelfilter Erstatter 492836 H: 101 mm U: 49 / 44 mm I: 8 / 8 mm 
13217 Forfilter Erstatter 272403 H: 4 mm U: 170 mm I: 76 mm Forfilter for 13051 	15446 Forfilter Erstatter 697015 H: 5 mm U: 160 mm I: 64 mm Forfilter for 13124 	52014 Fuelfilter Erstatter 493629 H: 69 mm U: 35 mm I: 7 / 7 mm 
13219 Forfilter Erstatter 710268 H: 8 mm U: 192 mm I: 80 mm Forfilter for 13058 	13246 Forfilter Erstatter 271271 H: 9 mm U: 263 mm I: 63 mm Forfilter for 13259 / 13260 / AF25340 	52026 Fuelfilter Erstatter 808116S H: 41 mm U: 30 mm I: 14 / 7 mm 

BRIGGS & STRATTON		EZ-GO	FARYMANN
52021 Fuelfilter Erstatter 394358 / 298090 H: 45 mm U: 34 mm I: 7 / 7 mm 	10046 Luftfilter Erstatter 72144G01 / 72368G01 H: 41 mm U: 290 mm I: 128 mm 		LF 3402 Oliefilter H: 139 mm U: 98 mm I: 3/4 - 16 UNF 
52025 Fuelfilter H: 52 mm U: 20 mm I: 6 / 6 mm 	15095 Luftfilter Erstatter 26855G01 / 26635G01 H: 34 mm U: 218 mm I: 130 mm 		LF 3778 Oliefilter H: 69 mm U: 95 mm I: 3/4 - 16 UNF 
LF 3826 Oliefilter Erstatter 492932 H: 58 mm U: 76 mm I: 3/4-16 UNF By-pass 	FARYMANN AF 435KM Luftfilter H: 265 mm U: 131 / 103 mm I: 63 / 17 mm 		LF 3826 Oliefilter H: 59 mm U: 77 / 75 mm I: 3/4 - 16 UNF 
LF 3335 Oliefilter Erstatter 491056 H: 87 mm U: 76 mm I: 3/4-16 UNF By-pass 	13081 Luftfilter Erstatter 541073-2 H: 116 mm U: 164 mm I: 88 mm 		LF 3536 Oliefilter H: 102 mm U: 84 / 80 mm I: M 20 x 1.5 
LF 3338 Oliefilter Erstatter 807894 H: 80 mm U: 82 mm I: 3/4-16 UNF By-pass 	AF25351 Luftfilter Erstatter 541061-2 H: 173 mm U: 126 mm I: 65 / 9 mm 		HATZ AF25376 Luftfilter Erstatter 40084500 / 01493000 H: 95 mm U: 164 mm I: 87 mm 
31049 Oliefilter Erstatter 499532 / 820314 H: 72 mm U: 65 mm I: 3/4-16 UNF 	AF25433 Luftfilter Erstatter 541.052.2 H: 135 mm U: 105 / 97 mm I: 35 mm 		AF25322 Luftfilter Erstatter 00952900 H: 93 mm U: 244 / 161 mm I: 143 / 60 mm 
CLUB CAR		FF 167 Fuelfilter H: 72 mm U: 87 mm I: 19 / 17 mm 	10086 Luftfilter Erstatter 50484100 H: 84 / 82 mm U: 142 mm I: 51 / 6 mm 

HATZ	HATZ	HATZ
10281 Luftfilter Erstatter 50426000 H: 78 mm U: 113 mm I: 52 / 6 mm 	50060 Fuelfilter Erstatter 40043800 H: 133 mm U: 39 mm I: 9 mm 	LF 3402 Oliefilter Erstatter 40065300 H: 139 mm U: 98 mm I: 3/4 - 16 UNF 
10279 Luftfilter Erstatter 01391800 H: 78 mm U: 113 mm I: 52 mm 	52030 Fuelfilter Erstatter 50539200 / 05259300 H: 104 mm U: 59 / 49 mm I: 6.5 (x2) / 5 mm 	LF 3826 Oliefilter Erstatter 50408400 H: 59 mm U: 77 / 75 mm I: 3/4 - 16 UNF 
AF 4066 Luftfilter H: 225 mm U: 110 mm I: 50 / 9 mm 	FF 5135 Fuelfilter Erstatter 50345700 H: 158 mm U: 81 mm I: M 16 x 1.5 	33378 Oliefilter Erstatter 03795700 H: 64 mm U: 42 mm I: 14 mm By-Pass 
AF25481 Luftfilter Erstatter 04030100 H: 81 mm U: 141 mm I: 81 mm 	H70WK04 Fuelfilter Erstatter 50379100 H: 170 mm U: 92 mm I: 8 mm 	LF 3341 Oliefilter Erstatter 401201000 H: 108 mm U: 97 / 95 mm I: 3/4 - 16 UNF 
FF 5018 Fuelfilter Erstatter 40120300 H: 122 mm U: 81 mm I: M 16 x 1.5 	FF 149 Fuelfilter Erstatter 40089400 / 40089401 / 50478800.0943 / 50473800.0943 H: 101 mm U: 49 / 44mm I: 8 / 8 mm 	H10W03 Oliefilter Erstatter 40038140 / 40038100 H: 102 mm U: 98 mm I: 3/4 - 16 UNF 
FF 146 Fuelfilter Erstatter 4000730 H: 114 mm U: 65 mm I: 13 mm 	FF42002 Fuelfilter Erstatter 50251500 H: 78 mm U: 77 mm I: M 16 x 1.5 	H14W27 Oliefilter Erstatter 505473 H: 138 / 124 mm U: 78 mm I: 3/4 - 16 UNF 
FF 147 Fuelfilter H: 145 mm U: 85 mm I: 14 mm 	50003 Fuelfilter Erstatter 50440500 H: 56 mm U: 29 mm I: 8 mm 	LF 3605 Oliefilter H: 134 mm U: 83 mm I: 25 mm 

HONDA	HONDA	HONDA
52038 Fuelfilter Erstatter 16900-ZE8-005 / 16900-ZE8-015 H: 65 mm U: 29 / 22 mm l: 7 / 5 mm 	13043 Luftfilter Erstatter 17210-ZE5-000 H: 46 mm U: 183 / 58 mm l: 153 / 27 / 6 mm 	13070 Luftfilter Erstatter 17211-ZE7-W03 H: 54 mm U: 177 / 62 mm l: 142 / 27 / 7 mm 
52039 Fuelfilter Erstatter 16910-GB2-005 H: 52 mm U: 30 mm l: 5 mm 	13049 Luftfilter Erstatter 17211-ZG9-M00 H: 25 mm U: 145 mm l: 89 mm Forfilter er 13298 	13071 Luftfilter Erstatter 17211-ZF5-V000 H: 87 mm U: 126 / 58 mm l: 92 / 25 / 8 mm 
11028 Luftfilter Erstatter 17211-ZL8-000 H: 22 mm U: 131 mm l: 112 mm 	13057 Luftfilter Erstatter 17205-GJ4-760 H: 15 mm U: 166 mm l: 84 / 8 mm 	13098 Luftfilter Erstatter 17210-ZG3-003 H: 71 mm U: 122 mm l: 60 / 7 mm 
13038 Luftfilter Erstatter 17211-883-W20 H: 29 mm U: 175 mm l: 87 mm Forfilter er 13268 	13059 Luftfilter Erstatter 17211-ZE7-W010 H: 49 mm U: 170 / 55 mm l: 143 / 26 / 16 mm 	13100 Luftfilter Erstatter 17211-899-000 H: 29 mm U: 164 mm l: 117 mm 
13041 Luftfilter Erstatter 17210-ZC6-003 / 17220-ZC6-003 H: 205 mm U: 128 / 104 mm l: 63 / 18 mm 	13060 Luftfilter Erstatter 17211-ZG9-800 H: 24 mm U: 136 mm l: 60 mm Forfilter er 13300 	13102 Luftfilter Erstatter 17210-ZK7-V01 H: 158 mm U: 44 mm l: 19 mm Forfilter er 13229 
11643 Luftfilter Erstatter 17210-ZE3-000 H: 92 mm U: 110 / 94 mm l: 42 / 38 / 6 mm Forfilter er 13212 	13062 Luftfilter Erstatter 17210-759-013 H: 205 mm U: 107 / 94 mm l: 46 / 10 mm 	13271 Luftfilter Erstatter 17211-ZA8-800 H: 20 mm U: 116 mm l: 50 mm 
13042 Luftfilter Erstatter 17210-734-003 H: 60 mm U: 119 / 64 mm l: 110 / 54 / 84 / 28 / 6 mm 	13064 Luftfilter Erstatter 17211-ZJ1-000 H: 39 / 29 mm U: 235 mm l: 202 / 180 mm Forfilter er 13221 	13104 Luftfilter Erstatter 17211-Z07-000 H: 17 mm U: 124 mm l: 82 / 60 / 10 mm 

HONDA		HONDA		HONDA	
13105 Luftfilter Erstatter 17218-Z07-000 H: 25 mm U: 82 mm l: 25 mm 		11028 Luftfilter Erstatter 17211-ZL8-A000 / 17211-ZS9-A01 H: 22 mm U: 132 mm l: 114 mm 		13166 Luftfilter Erstatter 17211-896-000 H: 25 mm U: 95 mm l: 78 mm 	
13106 Luftfilter Erstatter 17211-ZM7-000 H: 12 mm U: 88 mm l: 86 mm 		10068 Luftfilter Erstatter 17210-ZJ1-841 H: 32 mm U: 228 mm l: 168 mm Forfilter er 14953 		13167 Luftfilter Erstatter 17210-ZE8-003 H: 81 mm U: 130 / 67 mm l: 90 / 28 / 6 mm Forfilter er 13248 	
10045 Luftfilter Erstatter 17211-ZM3-000 H: 20 mm U: 70 mm l: 55 mm 		13276 Luftfilter Erstatter 17211-891-004 H: 60 mm U: 216 / 64 mm l: 185 / 38 / 2 x 9 mm 		11653 Luftfilter Erstatter 17210-ZE2-822 / 17210-ZE2-882 H: 78 mm U: 102 / 89 mm l: 41 / 38 / 6 mm Forfilter er 13307 	
13120 Luftfilter Erstatter 17211-ZB2-000 H: 31 mm U: 137 mm l: 79 mm 		13135 Luftfilter H: 76 mm U: 97 mm l: 33 mm Forfilter er 13248 		13293 Luftfilter Erstatter 17211-883-010 H: 38 mm U: 117 mm 	
13333 Luftfilter Erstatter 17211-ZA7-000 H: 28 mm U: 108 / 53 mm 		13281 Luftfilter Erstatter 17211-Z0H-000 H: 20 mm U: 104 mm l: 70 mm 		13193 Luftfilter Erstatter 17211-ZE1-000 H: 40 mm U: 130 mm l: 100 mm 	
10301 Luftfilter Erstatter 17211-Z0A-003 / 17211-Z0A-000 H: 22 mm U: 219 mm l: 118 mm 		13164 Luftfilter Erstatter 17210-ZE6-003 / 17211-888-013 H: 48 mm U: 193 / 65 mm l: 152 / 27 mm 		10197 Luftfilter Erstatter 17210-ZE1-821 / 17210-ZE1-822 H: 68 mm U: 101 / 73 mm l: 34 / 32 / 5 mm Forfilter er 13308 	
14954 Luftfilter Erstatter 17211-896-700 H: 22 mm U: 97 mm l: 77 mm 		13283 Luftfilter Erstatter 17211-ZG1-700 H: 25 mm U: 130 mm l: 70 mm 		10198 Luftfilter Erstatter 17210-ZE0-821 / 17210-ZE0-822 H: 52 mm U: 101 / 73 mm l: 34 / 32 / 5 mm Forfilter er 13309 	



HONDA	HONDA	HONDA
10198 Luftfilter Erstatter 17210-ZE0-821 / 17210-ZE0-822 H: 52 mm U: 101 / 73 mm l: 34 / 32 / 5 mm  Forfilter er 13309	13300 Forfilter Erstatter 17218-ZG9-800 H: 6 mm U: 132 mm l: 53 mm  Forfilter for 13060	13308 Forfilter H: 6 mm U: 107 mm l: 64 mm  Forfilter for 10197
13195 Luftfilter Erstatter 17211-ZA0-702 H: 44 mm U: 165 / 105 mm l: 109 / 49 / 6 (x2)  	13221 Forfilter Erstatter 17218-ZJ1-000 H: 5 mm U: 216 / 131 mm l: 161 / 112 mm  Forfilter for 13064	13309 Forfilter H: 8 mm U: 120 mm l: 43 mm  Forfilter for 10198 / AF25607
13199 Luftfilter Erstatter 172A1-883-902 H: 65 mm U: 111 / 81 mm l: 55 / 8 / 6 mm  	13229 Forfilter Erstatter 17218-ZK7-V01 H: 8 mm U: 143 mm l: 73 mm  Forfilter for 13102	13310 Forfilter Erstatter 17218-883-901 H: 6 mm U: 125 mm l: 54 mm 
13200 Luftfilter Erstatter 172A1-890-013 / 17211-890-023 H: 71 mm U: 135 / 97 mm l: 77 / 7 mm  Forfilter er 13255	13234 Forfilter Erstatter 17218-Z0A-810 H: 6 mm U: 210 mm l: 45 mm  	13255 Forfilter Erstatter 17218-890-003 / 17211-889-003 H: 6 mm U: 150 mm l: 61 mm  Forfilter for 13200
13212 Forfilter Erstatter 17218-ZE3-000 H: 7 mm U: 140 mm l: 85 mm  Forfilter for 11643	14953 Forfilter Erstatter 17218-ZJ1-840 H: 5 mm U: 220 mm l: 159 mm  Forfilter for 10068	59931 Fueelfilter Erstatter 17682-ZG3-003 H: 137 mm U: 51 / 37 mm l: 13 mm 
13298 Forfilter Erstatter 17218-ZG9-M00 H: 7 mm U: 135 mm l: 85 mm  Forfilter for 13049	13248 Forfilter Erstatter 17288-888-003 H: 6 mm U: 147 mm l: 72 mm  Forfilter for 13167 / 13135	LF 3682 Oliefilter Erstatter 80492-Y08-003 H: 130 mm U: 98 / 95 mm l: 3/4 - 16 UNF 
13215 Forfilter Erstatter 17218-896-505 H: 5 mm U: 140 mm l: 33 mm  	13307 Forfilter H: 6 mm U: 134 mm l: 68 mm  Forfilter for 1165	30386 Oliefilter Erstatter 15221-ZG3-000 H: 59 mm U: 36 / 30 mm l: 8 mm 

HONDA		HUSQVARNA		ISEKI	
30387 Oliefilter Erstatter 15220-ZG3-000 H: 69 / 59 mm U: 37 / 30 mm l: 8 mm 		13288 Luftfilter Erstatter 5061458 H: 79 mm U: 102 mm l: 60 mm 		AF 1658 K Luftfilter Erstatter 1427-101-2840-0 H: 185 mm U: 107 / 83 mm l: 44 / 12 mm 	
LF 3536 Oliefilter Erstatter 15400-PH1-014 / 15400-PH2-003 H: 102 mm U: 84 / 80 mm l: M 20 x 1.5 		13289 Luftfilter Erstatter 5061457 H: 20 mm U: 133 mm l: 125 mm 		13086 Luftfilter Erstatter 5490-642-010-XX H: 48 mm U: 102 / 83 mm l: 60 mm 	
33661 Oliefilter Erstatter 15400-679-023 H: 82 mm U: 84 / 80 mm l: M 20 x 1.5 		ISEKI 1031 Luftfilter Erstatter 1544-104-2020-0 H: 190 mm U: 125 / 83 mm l: 46 / 6 mm 		13137 Luftfilter H: 80 / 68 mm U: 157 / 73 mm l: 120 / 36 mm Forfilter er 13305 	
HUSQVARNA		AF 4939 Luftfilter		AF 4991 Luftfilter	
52024 Fuelfilter H: 42 / 31 mm U: 20 mm l: 5 mm 		Erstatter 1560-103-2024-0 H: 267 mm U: 146 / 104 mm l: 63 / 7 mm 		H: 292 mm U: 180 / 135 mm l: 72 / 13 mm 	
10363 Luftfilter Erstatter 5746680-01 H: 22 mm U: 95 / 83 mm 		1052 Luftfilter Erstatter 1550-104-2020-0 H: 250 mm U: 126 / 83 mm l: 46 / 6 mm 		13267 Luftfilter Erstatter 3656-301-2130-0 H: 200 mm U: 149 / 104 mm l: 63 / 7 mm 	
13055 Luftfilter Erstatter 5018071-01 H: 39 mm U: 95 mm l: 90 mm 		13008 Luftfilter Erstatter 1444-101-3700-0 H: 244 mm U: 110 / 83 mm l: 46 / 10 mm 		13305 Forfilter Erstatter 5110-132-1090-0 H: 6 mm U: 154 mm l: 64 mm Forfilter for 13137 	
13158 Luftfilter H: 36 mm U: 126 mm l: 115 mm 		13009 Luftfilter Erstatter 1572-103-2500-0 H: 265 mm U: 149 / 104 mm l: 63 / 14 mm 		FF 5103 Fuelfilter Erstatter 1513-102-3290-0 H: 88 mm U: 50 mm l: 20 / 0 mm 	

ISEKI		ISUZU		JACOBSEN	
5844 Fuelfilter Erstatter 5650-040-4879-0 H: 60 mm U: 29 mm I: 13 / 0 mm 		FF42003 Fuelfilter Erstatter 8-94132947-1 / 8-94132947-0 H: 71 mm U: 78 / 76 mm I: M 20 x 1.5 		AF 257 Luftfilter Erstatter 271272 H: 92 mm U: 238 / 238 mm I: 175 / 175 mm 	
5819 Fuelfilter Erstatter 1415-102-0110-0 H: 69 mm U: 35 mm I: 11 / 0 		LF 3490 Oliefilter Erstatter 5-13240017-0 / 5-13240093-0 H: 117 mm U: 84 / 80 mm I: 3/4 - 16 UNF 		13259 Luftfilter Erstatter 5000441 H: 56 mm U: 180 / 180 mm I: 138 / 138 mm 	
52031 Fuelfilter Erstatter 6213-200-002-10 H: 112 mm U: 53 / 46 mm I: 8 / 7 / 7 mm 		33726 Oliefilter Erstatter 8-94314263-2 / 8-94368727-0 H: 82 mm U: 72 / 68 mm I: M 20 x 1.5 		AF25551 Luftfilter Erstatter 5000919 H: 270 mm U: 105 / 105 mm I: 62 / 0 mm 	
LF 3682 Oliefilter Erstatter 1732-132-431 H: 130 mm U: 98 / 95 mm I: 3/4 - 16 UNF 		JACOBSEN AF1668 Luftfilter Erstatter 230840 / 230848 / 236840 H: 40 mm U: 112 / 112 mm I: 76 / 76 mm 		AF25557 Luftfilter Erstatter 5003370 H: 350 mm U: 165 / 165 mm I: 93 / 0 mm 	
31049 Oliefilter Erstatter 6213-240-0021-0 H: 62 mm U: 69 / 65 mm I: 3/4 - 16 UNF 		AF25550 Luftfilter Erstatter 5000913 / 840352 H: 186 mm U: 89 mm I: 48 / 0 mm Inderfilter er 1037 		AF 1658 K Luftfilter Erstatter 502619 H: 184 mm U: 106 / 83 mm I: 45 / 10 mm 	
ISUZU					
53017 Fuelfilter Erstatter 8-94119532-0 H: 122 mm U: 84 / 80 mm I: M 20 x 1.5 / M 22 x 1.5 		1037 Luftfilter H: 170 mm U: 42 / 45 mm I: 32 / 0 mm Inderfilter for AF25550 		AF 435KM Luftfilter Erstatter 549593 / 554700 H: 265 mm U: 131 / 104 mm I: 63 / 17 mm 	
5852 Fuelfilter Erstatter 5-87810197-0/1 / 1-87810049-0 H: 46 mm U: 42 mm I: 14 mm 		13016 Luftfilter Erstatter 235116 H: 47 mm U: 154 / 154 mm I: 120 / 120 mm Forfilter er 10316 		AF 437KM Luftfilter Erstatter 549633 / A819168 H: 289 mm U: 158 / 133 mm I: 69 / 17 mm 	

JACOBSEN		JACOBSEN	JOHN DEER
FF42003 Fuelfilter Erstatter 2500809 / 557619 H: 88 mm U: 77 / 77 mm l: M 20 x 1.5 		LF 4016 Oliefilter Erstatter 5003207 H: 116 mm U: 94 / 94 mm l: 3/4 - 16 	AF 437KM Luftfilter Erstatter AT18650T / AT20728 H: 280 mm U: 159 / 134 mm l: 66 / 17 mm 
FF 5104 Fuelfilter Erstatter 5001190 / 550463 / 550486 / 550489 / 840161 H: 87 mm U: 29 / 29 mm l: 13 / 0 mm 		LF 716 Oliefilter Erstatter 554464 H: 116 mm U: 77 / 77 mm l: M 20 x 1.5 	AF25550 Luftfilter Erstatter M113621 / M807331 / MIU10783 H: 186 mm U: 89 mm l: 48 / 0 mm Inderfilter er 1037 
FF 5135 Fuelfilter Erstatter 5003212 H: 158 mm U: 77 / 77 mm l: M 16 x 1.5 		LF 3341 Oliefilter Erstatter 555773 H: 107 mm U: 97 / 97 mm l: 3/4 - 16 	1037 Luftfilter Erstatter M123378 / M807332 H: 170 mm U: 42 / 45 mm l: 32 / 0 mm Inderfilter for AF25550 
5554 Fuelfilter Erstatter 556224 / 593391 H: 117 mm U: 54 / 54 mm l: 8 / 6 mm 		LF3536 Oliefilter Erstatter 557759 H: 100 mm U: 80 / 80 mm l: M 20 x 1.5 	13320 Luftfilter Erstatter MIU11517 H: 80 / 5 mm U: 160 mm 
LF 689 Oliefilter Erstatter 130355 H: 108 mm U: 97 / 97 mm l: 3/4 - 16 		JOHN DEER	
52003 Fuelfilter Erstatter AM116304 H: 108 mm U: 35 mm l: 8 / 6 mm 		13325 Luftfilter Erstatter 11029-7019 / 11029-7023 H: 75 mm U: 90 / 90 mm l: 59 / 0 mm 	
33661 Oliefilter Erstatter 131044 / 550556 / 551044 / 554011 H: 80 mm U: 80 / 80 mm l: M 20 x 1.5 		10343 Luftfilter Erstatter AM130295 H: 159 mm U: 99 / 99 mm l: 65 / 0 	13026 Luftfilter Erstatter M92359 H: 72 mm U: 116 / 95 mm l: 85 / 66 / 8 mm Forfilter er 10319 
LF 3335 Oliefilter Erstatter 2208174 / 5000440 H: 88 mm U: 77 / 77 mm l: 3/4 - 16 		AF 435KM Luftfilter Erstatter AH19847 H: 265 mm U: 131 / 103 mm l: 63 / 17 mm 	13027 Luftfilter Erstatter PT11025 H: 23 mm U: 162 mm l: 112 mm 

JOHN DEER		JOHN DEER		JOHN DEER	
11028 Luftfilter Erstatter AM116236 H: 22 mm U: 131 mm l: 112 mm 		AF25340 Luftfilter Erstatter M47494 H: 63 mm U: 178 mm l: 137 mm Forfilter er 13246 		10319 Forfilter Erstatter M92360 H: 6 mm U: 148 mm l: 73 mm Forfilter for 13026 	
AF 1658 K Luftfilter Erstatter CH15451 / M73009 H: 185 mm U: 107 / 83 mm l: 44 / 12 mm 		13277 Luftfilter Erstatter M70284 H: 72 / 60 mm U: 121 / 70 mm l: 85 / 34 mm Forfilter er 13303 		13235 Forfilter Erstatter M70127 H: 5 mm U: 200 mm l: 60 mm Forfilter for 13133 	
AF 1669 Luftfilter Erstatter HE1401228 H: 53 mm U: 204 mm l: 165 mm 		10062 Luftfilter Erstatter M76077 H: 74 / 63 mm U: 222 / 89 mm l: 176 / 42 mm Forfilter er 13238 		13238 Forfilter Erstatter M76076 H: 6 mm U: 230 mm l: 54 mm Forfilter for 10062 	
13076 Luftfilter Erstatter M117254 H: 66 mm U: 192 / 112 mm l: 150 / 68 mm 		13137 Luftfilter Erstatter M97211 H: 80 / 68 mm U: 157 / 73 mm l: 120 / 36 mm Forfilter er 13305 		13240 Forfilter Erstatter M71951 H: 8 mm U: 118 mm l: 48 mm Forfilter for 13142 	
13107 Luftfilter Erstatter M83339 H: 70 mm U: 71 mm l: 33 mm Forfilter er 13230 		13142 Luftfilter Erstatter 880701DY2 H: 53 mm U: 124 mm l: 109 / 75 mm Forfilter er 13240 		13306 Forfilter Erstatter M151345 H: 10 mm U: 180 mm l: 60 mm Forfilter for 13282 	
13133 Luftfilter Erstatter M70128 H: 81 / 70 mm U: 190 / 83 mm l: 155 / 47 mm Forfilter er 13235 		13143 Luftfilter Erstatter M115978 H: 71 / 60 mm U: 169 / 90 mm l: 124 / 41 mm Forfilter er 13241 		52021 Fuelfilter Erstatter AM38708 / 75 my H: 45 mm U: 34 mm l: 7 / 7 mm 	
13136 Luftfilter Erstatter M79451 H: 54 / 50 mm U: 100 / 63 mm l: 68 / 30 / 13 mm 		13282 Luftfilter Erstatter AM134111 H: 29 mm U: 218 mm l: 69 mm Forfilter er 13306 		52025 Fuelfilter Erstatter AM36483 / 75 my H: 52 mm U: 20 mm l: 6 / 6 mm 	


JOHN DEER		KAWASAKI		KAWASAKI	
59902 Fuelfilter Erstatter M811032 H: 118 mm U: 53 / 20 mm l: 20 / 16 mm 		13329 Luftfilter Erstatter 49064-2074 H: 39 mm U: 94 / 94 mm l: 65 / 0 mm 		13133 Luftfilter Erstatter 11013-2098 / 11013-1214 H: 81 / 70 mm U: 190 / 83 mm l: 155 / 47 mm  Forfilter er 13235	
52008 Fuelfilter Erstatter AL153517 H: 118 / 58 mm U: 50 mm l: 5 / 5 mm 		13314 Luftfilter Erstatter 11013-2226 / 6308315-S H: 9 mm U: 90 / 88 / 74 mm l: 10 mm 		13277 Luftfilter Erstatter 11013-2093 H: 72 / 60 mm U: 121 / 70 mm l: 85 / 34 mm  Forfilter er 13303	
LF 3646 Oliefilter Erstatter AM101378 H: 76 mm U: 84 / 80 mm l: M 20 x 1.5 		13321 Luftfilter Erstatter 5110132180XX H: 10 mm U: 160 / 40 mm 		13136 Luftfilter Erstatter 11029-2002 H: 54 / 50 mm U: 100 / 63 mm l: 68 / 30 / 13 mm  Forfilter er 13304	
KAWASAKI		1037 Luftfilter H: 170 mm U: 42 / 45 mm l: 32 / 0 mm Inderfilter for AF25550 		13137 Luftfilter Erstatter 11013-2110 H: 80 / 68 mm U: 157 / 73 mm l: 120 / 36 mm  Forfilter er 13305	
AF25550 Luftfilter Erstatter 110131290 / 110137029 H: 186 mm U: 89 mm l: 48 / 0 mm Inderfilter er 1037 		13324 Luftfilter Erstatter 11013-0727 / 11013-7050 H: 85 / 34 mm U: 151 / 71 mm l: 46 mm 		13065 Luftfilter Erstatter 11013-2128 H: 23 mm U: 129 / 116 mm l: 118 mm 	
13324 Luftfilter Erstatter 11013-0727 / 11013-7050 H: 85 / 34 mm U: 151 / 71 mm l: 46 mm 		13065 Luftfilter Erstatter 11013-2128 H: 23 mm U: 129 / 116 mm l: 118 mm 		13138 Luftfilter Erstatter 11013-1263 H: 113 / 98 mm U: 76 mm l: 53 / 42 mm 	
13074 Luftfilter Erstatter 49064-2066 H: 85 / 83 mm U: 118 / 67 mm l: 70 / 0 mm 		13086 Luftfilter Erstatter 49864-2010 H: 48 mm U: 102 / 83 mm l: 60 / 0 mm 		13140 Luftfilter Erstatter 11013-1217 / 11029-1004 H: 115 / 97 mm U: 115 / 97 mm l: 73 / 0 mm 	
13082 Luftfilter Erstatter 11013-2074 H: 30 mm U: 127 mm l: 103 mm 		13132 Luftfilter Erstatter 11013-2021 H: 71 / 60 mm U: 178 / 57 mm l: 142 / 21 mm Forfilter er 10028 		13141 Luftfilter Erstatter 11013-2132 H: 60 / 55 mm U: 150 / 82 mm l: 98 / 20 / 0 mm 	


KAWASAKI		KAWASAKI		KAWASAKI	
13142 Luftfilter Erstatter 31444AA-1312AA H: 53 mm U: 124 mm l: 109 / 75 mm 		10028 Forfilter Erstatter 11013-2020 H: 6 mm U: 182 mm l: 54 mm Forfilter for 13132 		13244 Forfilter Erstatter 11013-7016 / 11013-7034 H: 10 mm U: 182 mm l: 105 mm Forfilter for 13153 	
13143 Luftfilter Erstatter 11013-2135 H: 71 / 60 mm U: 169 / 90 mm l: 124 / 41 mm Forfilter er 13241 		13235 Forfilter Erstatter 11013-2097 H: 5 mm U: 200 mm l: 60 mm Forfilter for 13133 		13306 Forfilter Erstatter 11013-7018 H: 10 mm U: 180 mm l: 60 mm Forfilter for 13282 	
13145 Luftfilter Erstatter 11013-7002 H: 27 mm U: 210 mm l: 161 / 8 mm 		13303 Forfilter Erstatter 11013-2092 H: 5 mm U: 125 mm l: 56 mm Forfilter for 13277 		52029 Fueelfilter Erstatter 49019-1055 H: 99 mm U: 37 mm l: 8 / 8 mm 	
13279 Luftfilter Erstatter 49064-2011 H: 62 / 57 mm U: 72 / 46 mm l: 49 / 0 mm 		13304 Forfilter Erstatter 11013-2119 H: 6 mm U: 114 mm l: 44 mm Forfilter for 13136 		KOHLER AF 250 Luftfilter Erstatter 23575 H: 69 mm U: 76 mm l: 34 mm 	
13153 Luftfilter Erstatter 11013-7017 H: 27 mm U: 190 mm l: 112 mm Forfilter er 13244 		13305 Forfilter Erstatter 11013-2109 H: 6 mm U: 154 mm l: 64 mm Forfilter for 13137 		AF 257 Luftfilter Erstatter 271276 H: 94 mm U: 230 mm l: 175 mm 	
13154 Luftfilter Erstatter 11029-7015 H: 82 mm U: 190 / 90 mm l: 140 / 31 mm 		13240 Forfilter Erstatter 11013-2010 H: 8 mm U: 118 mm l: 48 mm Forfilter for 13142 		13311 Luftfilter H: 35 mm Ø: 122 mm l: 34 / 34 mm 	
13282 Luftfilter Erstatter 11029-7016 / 11029-7010 H: 29 mm U: 218 mm l: 69 mm Forfilter er 13306 		13241 Forfilter Erstatter 11013-2133 H: 5 mm U: 141 mm l: 56 mm Forfilter for 13143 		13318 Luftfilter Erstatter 1708307 H: 99 mm U: 64 mm l: 32 / 0 mm 	

KOHLER	KOHLER	KOHLER
AF 290 Luftfilter Erstatter 271519 / 272042 H: 76 mm U: 160 mm l: 127 mm 	13016 Luftfilter Erstatter 235116 H: 51 mm U: 151 mm l: 118 mm  Forfilter er 10316	13272 Forfilter Erstatter 1508305 H: 6 mm U: 79 mm l: 79 mm  Forfilter for 13273
AF 4539 Luftfilter Erstatter 253108 H: 278 mm U: 205 mm l: 136 mm 	13026 Luftfilter Erstatter 1208305 H: 72 mm U: 116 / 95 mm l: 85 / 66 / 8 mm  Forfilter er 10319	13273 Luftfilter Erstatter 1508301 H: 23 mm U: 100 mm l: 100 mm  Forfilter er 13272
AF25340 Luftfilter Erstatter 4708303 H: 63 mm U: 178 mm l: 137 mm  Forfilter er 13246	13040 Luftfilter Erstatter 1208310 / 1208316 H: 82 mm U: 115 / 97 mm l: 85 / 83 / 6 mm  Forfilter er 10320	10282 Luftfilter Erstatter 4708301 H: 46 mm U: 176 mm l: 142 mm  Forfilter er 13266
10134 Luftfilter Erstatter 2808303-S H: 39 mm U: 233 / 203 mm l: 175 mm  Forfilter er 13296	1194 Luftfilter Erstatter 231847 H: 60 mm U: 111 mm l: 77 mm  Forfilter er 13296	13259 Luftfilter H: 57 mm U: 176 mm l: 140 mm  Forfilter er 13246
10767 Luftfilter Erstatter 1708303S H: 113 mm U: 76 mm l: 41 / 0 mm  Forfilter er 13296	AF1668 Luftfilter Erstatter 230840 H: 39 mm U: 112 mm l: 76 mm  Forfilter for 13016	10316 Forfilter H: 6 mm U: 215 mm l: 45 mm  Forfilter for 13016
13326 Luftfilter Erstatter 6308311-S H: 96 mm U: 124 / 117 mm l: 86 / 5 mm  Forfilter er 13225	13313 Luftfilter Erstatter 277138 H: 104 mm U: 151 mm l: 117 mm  Forfilter for 13026	10319 Forfilter Erstatter 1208308 H: 6 mm U: 148 mm l: 73 mm  Forfilter for 13026
13080 Luftfilter Erstatter 2408303 H: 74 mm U: 177 mm l: 142 mm  Forfilter er 13225	10277 luftfilter Erstatter 4508302 H: 76 mm U: 152 mm l: 118 mm  Forfilter er 10300	10320 Forfilter Erstatter 1208312 H: 6 mm U: 150 mm l: 85 mm  Forfilter for 13040





KOHLER	KUBOTA	KUBOTA
13296 Forfilter Erstatter 234869 H: 6 mm U: 163 mm l: 57 mm Forfilter for 1194 	1279 Luftfilter Erstatter 6A100-8263-0 H: 177 mm U: 90 mm l: 42 / 0 mm 	13046 Luftfilter Erstatter 15621-1118-0 H: 170 mm U: 85 mm l: 55 / 18 mm 
10300 Forfilter Erstatter 4508301 H: 6 mm U: 235 mm l: 80 mm Forfilter for 10277 	AF25373 K Luftfilter Erstatter 15451-1108-0 H: 160 mm U: 198 / 154 mm l: 88 / 17 mm 	10011 Luftfilter Erstatter 11460-1118-0 H: 73 mm U: 125 / 122 mm l: 60 / 6 mm 
13225 Forfilter Erstatter 2408305 H: 5 mm U: 253 mm l: 74 mm Forfilter for 13080 	AF 437KM Luftfilter Erstatter 15000-3710-1 H: 280 mm U: 159 / 134 mm l: 66 / 17 mm Kubota 	AF25440 K Luftfilter Erstatter 14791-1118-0 H: 109 mm U: 104 / 87 mm l: 25 / 31 mm 
13246 Forfilter Erstatter 2408302 H: 9 mm U: 263 mm l: 63 mm Forfilter for 13259 / AF25340 	AF25550 Luftfilter Erstatter 11965512560 / 21D9811180 / KT1G34711180 / YMR001371 H: 186 mm U: 89 mm l: 48 / 0 mm Inderfilter er 1037 	13092 Luftfilter Erstatter 14348-1118-0 H: 107 mm U: 119 / 102 mm l: 40 / 11 mm 
13266 Forfilter Erstatter 5208301 H: 6 mm U: 248 mm l: 44 mm Forfilter for 10282 	1037 Luftfilter H: 170 mm U: 42 / 45 mm l: 32 / 0 mm Inderfilter for AF25550 	13096 Luftfilter Erstatter 12451-1108-0 H: 74 mm U: 106 / 106 mm l: 40 / 7 mm 
LF 3568 Oliefilter Erstatter 277233 H: 177 mm U: 79 / 76 mm l: 3/4 - 16 UNF 	60063 Hydraulik Erstatter 3741038550 H: 81 / 56 mm U: 61 / 61 mm l: 26 mm 	13098 Luftfilter Erstatter 10460-1118-0 H: 71 mm U: 122 mm l: 60 / 7 mm 
KUBOTA		
AF 4760 Luftfilter Erstatter 15287-1149-0 H: 232 mm U: 63 / 61 mm l: 49 / 17 mm 	61148 Hydraulik Erstatter HHK7014070 H: 103 mm U: 80 mm l: 3/4 - 16 UNF 	AF 4991 Luftfilter Erstatter 17351-1108-0 / 17351-1108-3 H: 292 mm U: 180 / 135 mm l: 72 / 13 mm 

KUBOTA		KUBOTA		KUBOTA	
AF25221 Luftfilter Erstatter 11420-1118-0 H: 50 mm U: 123 / 112 mm I: 64 / 49 mm 		59927 Fuelfilter Erstatter 11420-4301-0 H: 117 mm U: 57 / 32 mm I: 6 mm 		5827 Fuelfilter Erstatter 16271-4356-0 H: 90 mm U: 35 mm I: 13 / 12 / 0 mm 	
AF 4066 Luftfilter H: 225 mm U: 110 mm I: 50 / 9 mm 		59923 Fuelfilter Erstatter 11460-4301-2 H: 141 mm U: 57 / 32 mm I: 6 mm 		59925 Fuelfilter Erstatter 6A320-5993-0 H: 53 mm U: 45 / 35 mm I: 6 / 0 mm 	
AF 4502K Luftfilter Erstatter 15852-1101-1 / 15852-1108-0 H: 188 / 174 mm U: 124 / 107 mm I: 44 / 12 mm 		50023 Fuelfilter Erstatter RA211-51280 H: 81 mm U: 50 mm I: 20 / 0 mm 		LF 3341 Oliefilter Erstatter 15521-3243-1 H: 108 mm U: 97 / 95 mm I: 3/4 - 16 UNF 	
H70WK04 Fuelfilter Erstatter RG108-2341-0 H: 170 mm U: 92 mm I: 8 mm 		FF 5103 Fuelfilter Erstatter 15521-4316-0 H: 88 mm U: 50 mm I: 20 / 0 mm 		LF 3682 Oliefilter Erstatter 1C010-3243-0 / 1C020-3243-0 H: 130 mm U: 98 / 95 mm I: 3/4 - 16 UNF 	
FF42002 Fuelfilter H: 78 mm U: 77 mm I: M 16 x 1.5 		5856 Fuelfilter Erstatter RB101-5128-0 H: 50 mm U: 35 mm I: 13 / 12 / 0 mm 		LF 3682 Oliefilter Erstatter 1C010-3243-0 / 1C020-3243-0 H: 130 mm U: 98 / 95 mm I: 3/4 - 16 UNF 	
FF 5468 Fuelfilter Erstatter 15291-4301-2 H: 69 mm U: 35 mm I: 13 / 12 / 0 mm 		FF 5104 Fuelfilter Erstatter 15231-4356-3 H: 87 mm U: 29 mm I: 13 / 0 mm 		LF 3646 Oliefilter Erstatter 15241-3209-0 / 76611-3671-0 H: 76 mm U: 84 / 80 mm I: M 20 x 1.5 	
FF 5018 Fuelfilter H: 122 mm U: 81 mm I: M 16 x 1.5 		5819 Fuelfilter Erstatter 10450-055710 H: 69 mm U: 35 mm I: 13 / 12 / 0 mm 		LF 3313 Oliefilter Erstatter 15831-3243-0 H: 131 mm U: 97 mm I: 3/4 - 16 UNF 	

KUBOTA		LOMBARDINI		LOMBARDINI	
LF 3536 Oliefilter Erstatter 16271-3209-0 H: 102 mm U: 84 / 80 mm I: M 20 x 1.5 		10108 Luftfilter Erstatter 2175.215 / 2175.223 H: 80 mm U: 118 mm I: 63 / 6 mm 		10196 Luftfilter Erstatter 2175-119 H: 40 mm U: 275 mm I: 133 mm 	
AF 4066 Luftfilter H: 225 mm U: 110 mm I: 50 / 9 mm 		13294 Luftfilter Erstatter 2175.097 H: 41 mm U: 143 mm I: 64 mm 		5557 Fuelfilter Erstatter 196.3730.096 H: 86 mm U: 48 / 43 mm I: 6 (x3) mm 	
10202 Luftfilter Erstatter 550-2175-096 / 2175-134 H: 38 mm U: 160 mm I: 157 mm 		10200 Luftfilter Erstatter 2175.150 H: 29 mm U: 153 mm I: 104 mm 		FF 5280 Fuelfilter Erstatter 500-2175-32 H: 52 mm U: 42 mm I: 14 / 9 mm 	
1023 Luftfilter Erstatter 2175-105 / 2175-132 H: 40 mm U: 223 mm I: 135 mm 		AF 4085 Luftfilter Erstatter 530.2175.050 H: 75 mm U: 140 mm I: 96 mm 		FF 5281 Fuelfilter Erstatter 273-2175-09 H: 51 mm U: 50 mm I: 14 / 10 mm 	
AF25550 Luftfilter Erstatter 1072175166 / 2175166 H: 186 mm U: 89 mm I: 48 / 0 mm Inderfilter er 1037 		1174 Luftfilter Erstatter 2175-128 H: 76 mm U: 104 mm I: 63 / 7 mm 		FF 5018 Fuelfilter Erstatter 104.3740.068 H: 122 mm U: 81 mm I: M 16 x 1.5 	
1037 Luftfilter Erstatter 0021752330 / 21752330 H: 170 mm U: 42 / 45 mm I: 32 / 0 mm Inderfilter for AF25550 		10203 Luftfilter Erstatter 2175-168 H: 63 mm U: 108 / 104 mm I: 64 / 7 mm 		FF 146 Fuelfilter Erstatter 276.2175.14 / 276.2175.24 H: 114 mm U: 65 mm I: 13 mm 	
13139 Luftfilter Erstatter 2175.239 H: 72 / 65 mm U: 125 mm I: 65 / 10 mm Forfilter er 13235 		13235 Forfilter H: 5 mm U: 200 mm I: 60 mm Forfilter for 13139 		FF 147 Fuelfilter H: 145 mm U: 85 mm I: 14 mm 	



LOMBARDINI		LOMBARDINI	MAKITA
FF 147 Fuelfilter H: 145 mm U: 85 mm l: 14 mm 		31002 Oliefilter Erstatter 2175.072 H: 117 mm U: 51 mm l: M 14 x 1.5 	AF 4525 Luftfilter H: 71 mm U: 98 mm l: 60 mm Yderfilter for 13021 
FF42002 Fuelfilter Erstatter 115.2175.138 / 2175.083 H: 78 mm U: 77 mm l: M 16 x 1.5 		LF 716 Oliefilter Erstatter 104.2175.104 H: 122 mm U: 78 / 77 mm l: M 20 x 1.5 By-pass 	13263 Luftfilter Erstatter 394-17301-0 H: 58 mm U: 107 mm l: 82 mm Forfilter er 10017 
33379 Oliefilter Erstatter 2175.129 H: 90 mm U: 26 / 18 mm l: 6 mm / By-pass 		30235 Oliefilter Erstatter 277.2175.12 H: 248 mm U: 69 mm l: 30 / 15 mm 	10017 Forfilter Erstatter 394-17303-0 H: 20 mm U: 138 mm l: 92 / 26 mm Forfilter for 10017 
30205 Oliefilter Erstatter 2175-171 H: 82 mm U: 19 / 13 mm l: 6 / 0 mm 		3072 Oliefilter Erstatter 500-2175-19 H: 52 mm U: 23 mm l: 10 mm / By-pass 	MITSUBISHI 5842-U Fuelfilter Erstatter MM435190 H: 98 mm U: 55 / 46 mm l: 8 / 7 mm 
LF 3624 Oliefilter Erstatter 2175.131 / 2175.137 H: 92 mm U: 79 / 76 mm l: M 20 x 1.5 / By-pass 		3035 Oliefilter Erstatter 560-2175-044 H: 76 mm U: 23 mm l: 10 mm / By-pass 	AF 4066 Luftfilter H: 225 mm U: 110 mm l: 50 / 9 mm 
LF 655 Oliefilter Erstatter 2175.036 / 2175.071 H: 120 mm U: 80 mm l: 3/4 - 16 UNF 		30037 Oliefilter Erstatter 710-2175-25 H: 65 mm U: 38 mm l: 12 mm / By-pass 	AF 1658 k Luftfilter Erstatter MD200570 H: 185 mm U: 107 / 83 mm l: 44 / 12 mm 
LF 3678 Oliefilter Erstatter 270.2175.28 H: 73 mm U: 79 / 76 mm l: M 14 x 1.5 By-pass 		MAKITA 13021 Luftfilter Erstatter 001173020 / 001173030 H: 76 / 69 mm U: 59 / 53 mm l: 52 / 8 Inderfilter for AF4525 	13063 Luftfilter Erstatter MM510093 / MM510094 H: 98 mm U: 136 / 114 mm l: 42 mm 

MITSUBISHI		MITSUBISHI	PARTNER
AF25550 Luftfilter Erstatter 30L3003400 H: 186 mm U: 89 mm l: 48 / 0 mm Inderfilter er 1037 		5838 Fuelfilter Erstatter MM408992 H: 35 mm U: 41 mm l: 25 mm 	13052 Luftfilter Erstatter 506224201 H: 54 mm U: 121 / 87 mm l: 75 / 41 / 11 mm Forfilter er 13053 
1037 Luftfilter H: 170 mm U: 42 / 45 mm l: 32 / 0 mm Inderfilter for AF25550 		5856 Fuelfilter Erstatter MM434147 H: 50 mm U: 35 mm l: 13 / 12 / 0 mm 	13053 Forfilter Erstatter 506226301 H: 18 mm U: 195 mm l: 123 / 110 / 3 mm Forfilter for 13052 
52004 Fuelfilter Erstatter MM435191 H: 98 mm U: 55 / 46 mm l: 8 / 7 mm 		5844 Fuelfilter Erstatter MM404879 H: 60 mm U: 29 mm l: 13 / 0 mm 	13054 Luftfilter Erstatter 505315546 H: 52 mm U: 160 mm l: 110 mm 
53017 Fuelfilter Erstatter MB433425 H: 122 mm U: 84 / 80 mm l: M 20 x 1.5 / M 22 x 1.5 		33661 Oliefilter Erstatter MD097003 H: 82 mm U: 84 / 80 mm l: M 20 x 1.5 	13078 Luftfilter Erstatter 506231801 H: 69 mm U: 151 / 105 mm l: 101 / 54 / 10 mm Forfilter er 13223 
1194 Luftfilter Erstatter MM510090 H: 62 mm U: 117 mm l: 72 mm 		33726 Oliefilter Erstatter MD135735 / MD135737 H: 82 mm U: 72 / 68 mm l: M 20 x 1.5 	13078 Luftfilter Erstatter 506231801 H: 69 mm U: 151 / 105 mm l: 101 / 54 / 10 mm Forfilter er 13223 
5819 Fuelfilter Erstatter 91264-02200 H: 69 mm U: 35 mm l: 13 / 12 / 0 mm 		PARTNER	
		1719 Luftfilter Erstatter 315431 H: 45 mm U: 98 mm l: 60 mm 	13129 Luftfilter Erstatter 506347001 H: 66 mm U: 154 / 106 mm l: 10 mm 
50073 Fuelfilter Erstatter MM409870 H: 46 mm U: 35 mm l: 13 / 12 / 0 mm 		AF 1852 Luftfilter Erstatter 315530 H: 64 mm U: 147 mm l: 106 mm Forfilter er 10028 	13158 Luftfilter Erstatter 5063672F / 5063672K H: 36 mm U: 126 mm l: 115 mm 

PARTNER		ROBIN		ROBIN	
10028 Forfilter Erstatter 505315567 H: 6 mm U: 182 mm l: 54 mm Forfilter for AF1852 		13330 Luftfilter Erstatter 20B-32610-H7 H: 26 mm U: 184 / 106 mm 		13077 Luftfilter Erstatter 161-32612-08 H: 24 mm U: 178 mm l: 111 mm Forfilter er 13301 	
13223 Forfilter H: 19 mm U: 266 mm l: 132 mm Forfilter for 13078 		13069 Luftfilter Erstatter 128-32602-07 H: 46 / 35 mm U: 62 mm l: 46 mm 		13084 Luftfilter Erstatter 267-35003-01 H: 68 mm U: 148 / 93 mm l: 89 / 44 / 10 mm 	
13256 Luftfilter Erstatter 506268701 / 999807 H: 20 mm U: 257 mm l: 165 mm 		13072 Luftfilter Erstatter 228-32801-07 H: 47 mm U: 185 mm l: 115 mm 		13089 Luftfilter Erstatter 251-32831-12 H: 46 / 36 mm U: 217 mm l: 128 mm 	
ROBIN		13073 Luftfilter Erstatter 580-30390-00 H: 50 / 37 mm U: 84 mm l: 64 mm 		13091 Luftfilter Erstatter 227-36002-03 H: 30 mm U: 118 mm l: 82 mm 	
13093 Luftfilter Erstatter 226-32610-07 H: 58 / 54 mm U: 97 / 52 mm l: 52 / 0 mm 		13074 Luftfilter Erstatter 234-32604-07 H: 85 / 83 mm U: 118 / 67 mm l: 70 / 0 mm 		13284 Luftfilter Erstatter 207-32600-08 H: 64 / 58 mm U: 121 / 96 mm l: 77 / 0 mm 	
13094 Luftfilter Erstatter 207-32606-18 H: 87 / 83 mm U: 106 / 67 mm l: 72 / 0 mm 		13075 Luftfilter Erstatter 107-32701-00 H: 80 / 76 mm U: 87 / 51 mm l: 60 / 0 mm 		13187 Luftfilter Erstatter 246-32601-07 H: 48 mm U: 184 / 77 mm l: 147 / 41 / 7 (x2) mm 	
13323 Luftfilter Erstatter 224-32602-08 H: 85 mm U: 130 / 90 mm l: 80 mm 		10278 Luftfilter Erstatter 252-32601-07 H: 46 / 31 mm U: 91 mm l: 67 mm 		13290 Luftfilter Erstatter 209-32620-07 H: 93 / 86 mm U: 111 / 84 mm l: 80 / 0 mm 	


ROBIN		ROBIN	RUGGERINI
13095 Luftfilter Erstatter 227-32610-07 H: 63 / 60 mm U: 108 / 67 mm l: 55 / 0 mm 		10302 Luftfilter Erstatter 220-32812-04 H: 46 mm U: 124 / 60 mm l: 86 / 22 / 7 mm 	13139 Luftfilter Erstatter 2175.2390/2175.2520 H: 72 / 65 mm U: 125 mm l: 65 / 10 mm Forfilter er 13235 
13097 Luftfilter Erstatter 106-32704-07 H: 55 / 45 mm U: 61 mm l: 47 mm 		13171 Luftfilter Erstatter 206-32601-07 H: 62 / 57 mm U: 87 / 67 mm l: 60 / 0 mm 	10202 Luftfilter Erstatter 175.40 / 175.43 H: 38 mm U: 160 mm l: 157 mm 
13275 Luftfilter Erstatter 282-32601-07 / 282-32601-08 H: 27 mm U: 140 mm l: 87 mm 		5839 Fuelfilter Erstatter 228-62110-08 H: 50 mm U: 35 mm l: 13 / 12 / 0 mm 	13235 Forfilter H: 5 mm U: 200 mm l: 60 mm Forfilter for 13139 
13127 Luftfilter Erstatter 267-32602-18 H: 43 mm U: 168 mm l: 106 mm 		52030 Fuelfilter Erstatter 243/62101-10 H: 104 mm U: 59 / 49 mm l: 7 (x2) / 5 mm 	FF 146 Fuelfilter Erstatter D952446 H: 114 mm U: 65 mm l: 13 mm 
13144 Luftfilter Erstatter 243-32600-08 H: 52 mm U: 100 mm l: 70 / 6 mm 		31049 Oliefilter Erstatter 248-65801-00 H: 62 mm U: 69 / 65 mm l: 3/4 - 16 UNF 	FF 5091 Fuelfilter Erstatter 175.23 H: 56 mm U: 80 mm l: M 16 x 1.5 
13148 Luftfilter Erstatter 279-32606-08 / 279-32607-07 H: 71 mm U: 145 / 85 mm l: 98 / 37 / 6 mm 		30245 Oliefilter Erstatter 228-64301-00 H: 64 mm U: 30 mm l: 13 / 12 / 0 mm 	FF42002 Fuelfilter Erstatter 175.19 H: 78 mm U: 77 mm l: M 16 x 1.5 
13169 Luftfilter Erstatter 157-36201-01 H: 60 / 48 mm U: 79 mm l: 57 mm 		30314 Oliefilter Erstatter 251-64302-01 H: 67 mm U: 31 mm l: 13 / 12 / 0 mm 	50068 Fuelfilter H: 63 mm U: 51 mm l: 13 mm 

RUGGERINI		SACHS	SLANZI
FF 5091 Fuelfilter Erstatter 175-28 H: 58 mm U: 78 mm I: M 16 x 1.5 		52037 Fuelfilter Erstatter 963601250 H: 45 mm U: 21 mm I: 4 mm 	FF42002 Fuelfilter Erstatter 40.60.37 H: 78 mm U: 77 mm I: M 16 x 1.5 
50078 Fuelfilter Erstatter 175.32 H: 71 mm U: 51 mm I: 13 mm 		10018 Luftfilter Erstatter 0925111000 H: 55 mm U: 105 mm I: 80 mm 	LF 655 Oliefilter Erstatter 40.10.53 H: 120 mm U: 80 mm I: 3/4 - 16 UNF 
FF 230 Fuelfilter Erstatter 175-04 H: 64 mm U: 63 mm I: 13 mm 		13021 Luftfilter Erstatter 001173020 / 001173030 H: 76 / 69 mm U: 59 / 53 mm I: 52 / 8 mm Inderfilter for AF4525 	LF 3678 Oliefilter Erstatter 40.70.37 H: 73 mm U: 79 / 76 mm I: M 14 x 1.5 By-pass 
LF 655 Oliefilter Erstatter 175.22 H: 120 mm U: 80 mm I: 3/4 - 16 UNF 		AF 4525 Luftfilter H: 71 mm U: 98 mm I: 60 mm Inderfilter er 13021 	31002 Oliefilter Erstatter 40.70.45 H: 117 mm U: 51 mm I: M 14 x 1.5 
31002 Oliefilter Erstatter 175-11 H: 117 mm U: 51 mm I: M 14 x 1.5 		13299 Luftfilter H: 10 mm U: 112 mm I: 56 mm 	STIHL 59932 Fuelfilter Erstatter 1115-350-3503 H: 45 mm U: 19 mm I: 7 mm 
30228 Oliefilter Erstatter 175-05 H: 65 mm U: 23 mm I: 10 mm / By-pass 		SLANZI FF 146 Fuelfilter Erstatter 40.60.03 H: 80 mm U: 63 mm I: 16 / 13 mm 	13265 Luftfilter H: 82 mm U: 114 / 79 mm I: 98 / 63 mm 
LF 3826 Oliefilter Erstatter 175.24 H: 59 mm U: 77 / 75 mm I: 3/4 - 16 UNF 		53133 Fuelfilter Erstatter 40.60.40 H: 117 mm U: 51 / 48 mm I: M 12 x 1.75 	AF 4525 Luftfilter Erstatter 4201-141-0300 H: 71 mm U: 98 mm I: 60 mm Inderfilter er 13021 / 13022 / 13024 

STIHL	STIHL	STIHL
13023 Luftfilter Erstatter 4201-141-0310 H: 3 mm U: 154 / 71 mm Forfilter for AF 4525 	13112 Luftfilter Erstatter 4223-141-0300 H: 46 mm U: 137 mm l: 89 mm Forfilter er 13233 	13151 Luftfilter Erstatter 4224-141-0300A H: 47 mm U: 140 mm l: 103 mm 
13024 Luftfilter Erstatter 4201-140-1802 H: 57 mm U: 66 / 52 mm l: 47 / 12 mm Inderfilter for AF 4525 	13113 Luftfilter Erstatter 4221-141-0300 H: 58 mm U: 112 mm l: 53 / 7 mm Forfilter er 13115 	13233 Forfilter Erstatter 4223-141-0600 H: 18 mm U: 125 mm l: 77 mm Forfilter for 13112 
10299 Luftfilter Erstatter 4134-141-0300 H: 25 mm U: 86 mm l: 72 mm 	13114 Luftfilter Erstatter 4221-140-1800 H: 43 mm U: 48 mm l: 44 / 27 mm Inderfilter for 13113 	13243 Luftfilter Erstatter 4224-140-1801A H: 25 / 8 mm U: 120 mm l: 84 mm 
13319 Luftfilter Erstatter 42031410305 H: 48 mm U: 85 / 85 mm l: 43 / 43 mm 	13115 Forfilter Erstatter 4221-141-0310 H: 3 mm U: 168 mm l: 51 mm Forfilter for 13113 	AF25550 Luftfilter Erstatter 1083811 / 932195 / 993173 / 1083811 / 932195 H: 186 mm U: 89 mm l: 48 / 0 mm Inderfilter er 1037 
13332 Luftfilter Erstatter 1130140800 H: 7 mm U: 90 / 67 mm l: 40 mm 	13117 Luftfilter Erstatter 4223-140-1800 H: 29 mm U: 117 mm l: 69 mm 	1037 Luftfilter Erstatter 982982 H: 170 mm U: 42 / 45 mm l: 32 / 0 mm Inderfilter for AF25550 
13334 Luftfilter Erstatter 4148-141-0300B H: 22 / 8 mm U: 107 / 85 / 77 mm 	13122 Luftfilter Erstatter 4203-141-0301 A H: 35 mm U: 128 mm l: 87 mm 	13007 Luftfilter Erstatter 810100 H: 27 mm U: 168 mm l: 93 mm 
13022 Luftfilter Erstatter 4201-140-1801 H: 65 mm U: 63 / 40 mm l: 37 mm Inderfilter for AF 4525 	13130 Luftfilter Erstatter 4282-141-0300 H: 35 mm U: 203 mm l: 81 mm 	13016 Luftfilter Erstatter 235116 H: 51 mm U: 151 mm l: 118 mm Forfilter er 10316 

STIHL		STIHL	WACKER
10277 Luftfilter Erstatter 4508302 H: 76 mm U: 152 mm l: 118 mm		LF 3682 Oliefilter Erstatter 987431 H: 130 mm U: 98 mm l: 3/4 - 16 UNF	52037 Fuelfilter Erstatter 0108058 H: 45 mm U: 21 mm l: 4 mm
13274 Luftfilter Erstatter 545190 H: 10 mm U: 58 mm l: 9 mm (x2)		LF 3646 Oliefilter Erstatter 998384 H: 76 mm U: 84 mm l: M 20 x 1.5	52003 Fuelfilter Erstatter 15206 H: 108 mm U: 35 mm l: 6 / 8 mm
13286 Luftfilter Erstatter 623970 H: 60 mm U: 129 / 61 mm l: 92 / 26 mm		33726 Oliefilter Erstatter 674330 H: 82 mm U: 72 mm l: M 20 x 1.5	AF25376 Luftfilter Erstatter 95091 H: 95 mm U: 164 mm l: 87 mm
5838 Fuelfilter Erstatter 432550 H: 35 mm U: 41 mm l: 25 mm		WACKER	
		1396 Luftfilter Erstatter 80856 H: 42 mm U: 273 / 172 mm l: 25 / 8 mm	13166 Luftfilter Erstatter 77194 H: 25 mm U: 95 mm l: 78 mm
52014 Fuelfilter Erstatter 0406925-11 H: 69 mm U: 35 mm l: 7 / 7 mm		11041 Luftfilter Erstatter 14819 H: 80 mm U: 78 mm l: 59 mm	10197 Luftfilter Erstatter 71622 H: 68 mm U: 101 / 73 mm l: 34 / 32 / 5 mm Forfilter er 13308
52021 Fuelfilter Erstatter 425240 / 125 my H: 45 mm U: 34 mm l: 7 / 7 mm		13021 Luftfilter Erstatter 0094693 H: 76 / 69 mm U: 59 / 53 mm l: 52 / 8 mm Inderfilter for AF 4525	10198 Luftfilter Erstatter 72314 H: 52 mm U: 101 / 73 mm l: 34 / 32 / 5 mm Forfilter er 13304
53026 Fuelfilter Erstatter 637650 / 638300 H: 82 mm U: 78 mm l: M 16 x 1.5		AF 4525 Luftfilter Erstatter 33704 H: 71 mm U: 98 mm l: 60 mm Inderfilter er 13021	AF25433 Luftfilter Erstatter 66588 H: 135 mm U: 105 / 97 mm l: 35 / 0 mm

WACKER		WACKER		WACKER	
13023 Luftfilter Erstatter 58382 H: 3 mm U: 154 / 71 mm Forfilter for AF 4525 		13095 Luftfilter Erstatter 54798 H: 63 / 60 mm U: 108 / 67 mm l: 55 / 0 mm 		13242 Forfilter Erstatter 016459 H: 8 mm U: 116 mm l: 85 mm Forfilter for 10283 	
11028 Luftfilter Erstatter 77020 H: 22 mm U: 131 mm l: 112 mm Forfilter er 10280 		10283 Luftfilter Erstatter 0157193 H: 55 / 16 mm U: 170 mm l: 55 mm Forfilter er 13242 		FF 149 Fuelfilter Erstatter 49223 H: 101 mm U: 49 / 44 mm l: 8 / 8 mm 	
10280 Forfilter H: 10 mm U: 128 mm l: 107 mm Forfilter for 11028 		13280 Luftfilter Erstatter 0204305 / 204305 H: 17 mm U: 195 mm l: 127 mm 		52016 Fuelfilter Erstatter 95950 H: 130 / 103 mm U: 40 mm l: 8 mm 	
13069 Luftfilter Erstatter 66767 H: 46 / 35 mm U: 62 mm l: 46 mm 		13210 Luftfilter Erstatter 95254 H: 79 mm U: 147 / 92 mm l: 107 / 52 mm Forfilter er 13228 		59905 Fuelfilter Erstatter M36265 / 0112179 H: 72 mm U: 25 mm l: 14 mm 	
13263 Luftfilter Erstatter 0108076 H: 58 mm U: 107 mm l: 82 mm Forfilter er 10017 		10017 Forfilter Erstatter 0108074 H: 20 mm U: 138 mm l: 92 mm Forfilter for 13263 		33378 Oliefilter Erstatter 94930 H: 64 mm U: 42 mm l: 14 mm By-Pass 	
AF25351 Luftfilter Erstatter 66108 H: 173 mm U: 126 mm l: 65 / 9 mm 		13224 Forfilter Erstatter 95294 H: 8 mm U: 176 mm l: 65 mm Forfilter for 13035 		YAMAHA 52039 Fuelfilter Erstatter 68T-24251-00 H: 52 mm U: 30 mm l: 5 mm 	
1394 Luftfilter Erstatter 97711 / 0095711 H: 30 mm U: 124 / 68 mm l: 102 / 45 mm 		13304 Forfilter Erstatter 76941 H: 6 mm U: 114 mm l: 44 mm Forfilter for 10198 		5571 Fuelfilter Erstatter 646-24251-02 / 717635 H: 60 mm U: 19 mm l: 5 / 5 mm 	

YAMAHA		YAMAHA		YANMAR	
13044 Luftfilter Erstatter J38-14450-00 H: 148 mm U: 105 mm l: 33 / 32 / 0 mm Forfilter er 13297				30245 Oliefilter Erstatter YA2-28643-01-00 / 575423-8 H: 64 mm U: 30 mm l: 13 / 12 / 0 mm	
		13063 Luftfilter Erstatter 105370-12570 H: 98 mm U: 136 / 114 mm l: 42 mm			
13061 Luftfilter Erstatter JA9-14450-00 H: 20 / 13 mm U: 197 mm l: 108 mm				11646 Luftfilter Erstatter 114650-12590 H: 73 mm U: 142 / 99 mm l: 94 / 50 / 9 mm	
		AF 437KM Luftfilter Erstatter 121850-12510 / 171064-12540 H: 280 mm U: 159 / 134 mm l: 66 / 17 mm			
13068 Luftfilter Erstatter J10-14450-00 / J10-14450-10 H: 146 mm U: 146 / 105 mm l: 28 / 0 mm				AF25550 Luftfilter Erstatter 119515-12520 / 119655-12560 H: 186 mm U: 89 mm l: 48 / 0 mm Inderfilter er 1037	
		AF25607 Luftfilter Erstatter 114250-12540 H: 46 mm U: 105 / 100 mm l: 52 / 6 mm Forfilter er 13309			
13087 Luftfilter Erstatter JN6-E4450-00 H: 40 mm U: 320 / 158 mm l: 255 / 158 mm				1037 Luftfilter Erstatter 119233-12700 / 1W314531180 H: 170 mm U: 42 / 45 mm l: 32 / 0 mm Inderfilter for AF25550	
		10153 Luftfilter Erstatter 114210-12590 H: 78 / 71 mm U: 130 / 110 mm l: 73 / 55 / 7 mm			
13297 Forfilter Erstatter J10-14417-00 H: 11 mm U: 170 mm l: 138 mm Forfilter for 13044				13317 Luftfilter Erstatter 10550012570 H: 122 mm U: 121 / 121 mm l: 54 / 2 mm	
		10069 Luftfilter Erstatter 118400-12520 H: 65 mm U: 220 / 87 mm l: 180 / 45 mm			
5839 Fuelfilter Erstatter YA2-228621-10-08 H: 50 mm U: 35 mm l: 13 / 12 / 0 mm				13335 Luftfilter Erstatter 7RH-14454-00 / 7CT-E4451-00 	
52029 Fuelfilter Erstatter 1FK-24450-00 H: 99 mm U: 37 mm l: 8 / 8 mm				13265 Luftfilter Erstatter 128270-12540 	
13264 Luftfilter Erstatter 128171-12540 H: 80 mm U: 98 / 53 mm l: 82 / 38 mm				AF 4066 Luftfilter H: 225 mm U: 110 mm l: 50 / 9 mm	
					

YANMAR	YANMAR	YANMAR
AF 4502K Luftfilter Erstatter 119860-12510 H: 188 / 174 mm U: 124 / 107 mm l: 44 / 12 mm 	5856 Fuelfilter Erstatter 171081-55910 H: 50 mm U: 35 mm l: 13 / 12 / 0 mm 	5862 Fuelfilter Erstatter 114260-55120 H: 180 / 154 mm U: 40 mm l: 8 / 2 mm 
FF 5103 Fuelfilter Erstatter 129100-55650 H: 88 mm U: 50 mm l: 20 / 0 mm 	FF 5468 Fuelfilter Erstatter 121850-55710 H: 69 mm U: 35 mm l: 13 / 12 / 0 mm 	FF 230 Fuelfilter Erstatter 120324-55760 H: 61 mm U: 73 mm l: 13 mm 
5852 Fuelfilter Erstatter 58781-01780 H: 46 mm U: 42 mm l: 14 mm 	5819 Fuelfilter Erstatter 104500-55710 H: 69 mm U: 35 mm l: 13 / 12 / 0 mm 	LF 3646 Oliefilter Erstatter 129150-35151 / 129150-35152 H: 76 mm U: 84 mm l: M 20 x 1.5 
5827 Fuelfilter Erstatter 124550-55700 H: 90 mm U: 35 mm l: 13 / 12 / 0 mm 	52002 Fuelfilter Erstatter 129052-55630 H: 76 mm U: 52 / 44 mm l: 8 / 8 mm 	LF 3536 Oliefilter Erstatter 119005-35100 / 124550-35110 / 171056-35110 H: 102 mm U: 84 mm l: M 20 x 1.5 
52016 Fuelfilter Erstatter 114250-55120 H: 130 / 103 mm U: 40 mm l: 8 mm 	50071 Fuelfilter Erstatter 105370-55710 H: 86 mm U: 30 mm l: 11 / 8 / 0 mm 	33699 Oliefilter Erstatter 114250-35100 / 114250-35110 H: 97 / 87 mm U: 24 / 15 mm l: 7 / 0 mm 
52027 Fuelfilter Erstatter 114350-55120 H: 155 / 130 mm U: 40 mm l: 8 / 2 mm 	59902 Fuelfilter Erstatter 119802-55710 / 119802-55710T H 118 / 60 mm U: 53 / 20 mm l: 20 / 16 mm 	
52028 Fuelfilter Erstatter 114650-55120 H: 198 / 171 mm U: 40 mm l: 8 / 2 mm 	FF42003 Fuelfilter Erstatter CN039623 / 121850-55701 H: 71 mm U: 78 mm l: M 20 x 1.5 	

SLANGEFILTER	SLANGEFILTER	SLANGEFILTER
52013 Slangefilter H: 80 mm U: 49 mm Slangefilter 	5565 Slangefilter H: 103 mm U: 39/33 mm l: 10 mm 	52030 Slangefilter H: 96 mm U: 50 / 40 mm l: 6 mm 
52014 Slangefilter H: 67 mm U: 30 mm l: 7 mm 	5554 Slangefilter H: 117 mm U: 54 mm l: 6 / 8 mm 	52031 Slangefilter 
5563 Slangefilter H: 104 mm U: 37 mm l: 6 / 8 mm 	FF 5077 Slangefilter H: 91 mm U: 48 mm l: 5 / 8 - 24 mm (Gevind) 	5557 Slangefilter H: 86 mm U: 48 / 42 mm 
52006 Slangefilter H: 121 mm U: 50 mm l: 6 / 8 mm 	FF 5079 Slangefilter H: 97 mm U: 48 mm l: 10 mm 	5842 Slangefilter H: 97 mm U: 55 / 45 mm l: 7 / 8 mm 
52007 Slangefilter H: 200 mm U: 50 mm l: 6 / 8 mm 	FF 149 Slangefilter H: 97 mm U: 48 mm l: 8 mm 	5842-U Slangefilter H: 97 mm U: 55 / 45 mm l: 7 / 8 mm 
52035 Slangefilter H: 130 mm U: 70 mm l: 7 mm 	5571 Slangefilter H: 57 mm U: 19 mm l: 5 mm 	
H103WK Slangefilter H: 106 mm U: 38 mm l: 8 mm 	52003 Slangefilter H: 97 mm U: 48 mm l: 6 / 8 mm 	

AFTAGERVÆRKTØJ	AFTAGERVÆRKTØJ	AFTAGERVÆRKTØJ
99801 Filtertang (220 MM) 	99806 Filtertang (75 - 85 MM) 	99809 Filtertang (120 - 140 MM) 
99802 Filtertang (105 MM) 	99807 Filtertang (85 - 98 MM) 	99810 Filtertang (133 - 146 MM) 
99803 Aftagerværktøj (180 MM) 	99808 Filtertang (95 - 115 MM) 	3311468 Aftagerværktøj (Strap-Wrench) 
99805 Filtertang (65 - 76 MM) 		

NOTATER



Filtertechnik A/S

Filtertechnik A/S
Korskildeeng 2
DK-2670 Greve
Tlf. +45 5613 1072, Fax +45 5613 1073
www.filtertechnik.dk



Filtertechnik
Sverige

Filtertechnik Sverige AB
SE-625 21 Karlstad
Tlf.: +46 (0)54 690900, Fax +46 (0)54 690909
www.filtertechnik.se



Lekang
Maskin AS

Lekang Maskin AS
NO-1550 Hølen, Norge
Tlf. +47 6498 2000, Faks +47 6498 2002
www.lekang.com

Forhandler: