









- 3**
- 3a - 261 700 01
  - 3b - 261 700 02
  - 3c - 261 700 06
  - 3d - 261 700 07
  - 3e - 261 700 03
  - 3f - 261 700 05




**⚠ DANGER**



LED	X2	X1	X0 (COM)	Function
		•	•	permanent
	•		•	blinking


TONE	X3	X4	X0 (COM)	Function
	•		•	🔊
		•	•	🔊




LED	X2	X1	X0 (COM)	Function
		•	•	flashing
	•		•	EVS


TONE	X3	X4	X0 (COM)	Function
	•		•	🔊
		•	•	🔊



TONE	X3	X4	X0 (COM)	Function
	•		•	🔊
		•	•	🔊



LED	X2	X1	X0 (COM)	Function
		•	•	GN
	•		•	RD
		•	•	YE



LED	X2	X1	X0 (COM)	Function
		•	•	rotating

**5**

**NOTICE**  
dB = dB A (SPL) 1m

Tone	Frequency	Level [dB]	Level [dB]
0	110 Hz	107	99
1	3.3 kHz	106	101
2	3.3 kHz	110	101
3	3.3 kHz	110	101
4	970 Hz - 800 Hz	95	94
5	2.85 kHz - 2.40 kHz	99	92
6	1200 Hz - 500 Hz	101	93
7	1200 Hz - 800 Hz	100	92
8	4.1 kHz - 2.1 kHz	110	101
9	700 Hz	97	92

