



Tryklåse Push-to-open Push-Beschläge




318729 319635 323185

318729
319635
323185 m/ w/ Magnet

92,5x48x10,5 mm
92,5x48x10,5 mm
92,5x48x10,5 mm

grå/ grey/ grau
hvid/ white/ weiss
grå/ grey/ grau

plast/plastic/ Kunststoff
plast/plastic/ Kunststoff
plast/plastic/ Kunststoff




328180

328180

82x14x9,5 mm

grå/ grey/ grau

plast/plastic/ Kunststoff




328637

328637 83x14x9,5 mm


grå/børstet/grey/stainless steel colour/grau/edelstahlfarbig

plast/plastic/ Kunststoff

997620




324760
329630




325287 316245
316487 316755

324760	m/ w/ Magnet	82x14x9,5 mm	grå/ grey/ grau	plast/ plastic/Kunststoff
329630	m/ w/ Magnet	82x14x9,5 mm	hvid/ white/ weiss	plast/plastic/Kunststoff
325287		74x14,5 mm	grå/ grey/ grau	plast/ plastic/Kunststoff
316245		74x14,5 mm	hvid/ white/ weiss	plast/plastic/Kunststoff
316487		74x14,5 mm	sort/ black/schwarz	plast/ plastic/ Kunststoff
316755	m/ w/ Magnet	74x14,5 mm	sort/ black/schwarz	plast/ plastic/ Kunststoff




312798

312798		49,5x14,5 mm	grå/ grey/ grau	plast/plastic/ Kunststoff
--------	--	--------------	-----------------	---------------------------



330436
329856



322699

330436		Ø10x48 mm	grå/ grey/ grau	plast/ plastic/Kunststoff
329856		Ø10x48 mm	hvid/ white/ weiss	plast/plastic/Kunststoff
322699	m/ w/ Magnet	Ø10x48 mm	hvid/ white/ weiss	plast/plastic/Kunststoff