

# THE CUTTING EDGE KOMET MicroKom BluFlex® 2






Finger on the pulse of time – The clever alternative: "MicroKom BluFlex" APP for use as display unit in Google Play™ for Android™ smartphones or the App Store for smartphones running iOS®.

Bluetooth® is a registered trademark of Bluetooth SIG, Inc. iOS® is a registered trademark of Cisco Systems, Inc. Google Play™ and Android™ are registered trademarks of Google Inc. App Store is a trademark of Apple Inc.



## **KOMET** MicroKom BluFlex® 2

## Variation options



# **KOMET** MicroKom BluFlex® 2

## Micro-adjustable head
















Micro-adjustable head												
								Tool	lamp:	Battery	Slide clamp (4):	
								Clamping screw	Clamping screw	compartment:	Clamping	Sleeve
	ABS			Adjust- ment				<b>(1)</b>	<b>(1)</b> (2)	Cover/O-ring  (3)	screw	
Order No.	Ød	Ø d1	Ø d2	S	L	L1	9	<b>Order No.</b> Article	Order No. Article	Order No.	Order No. Article	Order No.
M04 30100	50	65	ABS32	2,3	71	38	1,45	55051 08120	N00 02062	( ( ( )	M04 30000.24 M5×14-⊖4	M04 30000.23
M04 30000 🐉 °	30	03	Ø 16	۷,۵	71	20	1,45	M8×1×20-⊖4	ABS32-F1.1-⊖4	52914 011315	8 Nm	10104 50000.23

Adjustment must be in line with cutting parameters and spindle speed.

A radio certification is required for the distribution of radio-enabled devices (M04 30000). This certification for the MicroKom *BluFlex* 2 currently exists for all CE countries, USA and Canada (FCC). In other countries, only the distribution of the fine adjustment head without Bluetooth (M04 30100) is permitted.

## **KOMET** MicroKom BluFlex® 2

Fine boring set Ø 6 – 125 mm	Contents of case				
Order No.		Order No.	Qty.	Article	
M04 30110	1	M04 30100	1	Micro-adjustable head	
M04 30010 🛞 °	1	M04 30000 🐉 °	1	Micro-adjustable head   Bluetooth ®	
	2	M05 20101	1	Insert holder Ø 25-44 mm / 0.98"-1.73"	
	3	M05 20151	1	Insert holder Ø 44-125 mm / 1.73"-4,92"	
	4	M05 80101	1	Bridge Ø 90-125 mm / 3,54"-4,92"	
	5	M05 90100	1	Serrated body Ø 25-63 mm / 0.98"-2.48"	
U	6	M05 90501	1	Packing piece	
	7	B05 20100	1	Boring bar ∅ 6 mm / 0.236"	
B	8	B05 20140	1	Boring bar Ø 10 mm / 0.394"	
2	9	B05 20180	1	Boring bar Ø 14 mm / 0.551"	
	10	B05 20220	1	Boring bar Ø 18 mm / 0.709"	
5 KOMET	11)	B05 20260	1	Boring bar Ø 22 mm / 0.866"	
3 4	12	18050 10030	1	Allen key SW3	
2	(3)	L05 01110	1	Flag key 5IP	
		L05 01120	1	Flag key 6IP	
To the last of the		L05 01240	1	Flag key 8IP	
		55011 05016	5	Cylindrical screw M5×16	
	14)	W57 04140.0260	4	Insert BK60	
		W57 14140.0460	4	Insert BK60	
		W00 04120.018440	2	Insert BK8440	
		39924 28021	1	Operating Instructions	
		49811 02040	1	Case	

#### Start-up

Press and hold the button to switch on the display.

Press and hold the button to switch between absolute mode and difference mode.

Pressing the button briefly when in **absolute mode** will take you to the settings.

From here, pressing the button briefly will take you to the next setting, while pressing and holding the button will change the selected setting.

If you are in the last setting ("Rotate display"), pressing the button briefly again will take you back to the readings screen.

In **difference mode**, by contract, pressing the button briefly will set the starting point for the difference calculation.


If the device is not operated or the reading does not change, the display will switch itself off.

If Bluetooth \* is enabled, the display's automatic switch-off time is extended.

We recommend cleaning the display regularly using a solvent-free glass cleaner.

This will ensure that the display works as it should.





Bluetooth\* is a registered trademark of Bluetooth SIG, Inc.