



SENTRALGASSUTSTYR SPECTROLAB

VERSJON 2.0. 2019

www.itec.as

iTec AS leverer komplette maskinløsninger for plater, rør og profiler, samt gassutstyr, og har de siste 20 år vært en ledende leverandør til norsk industri.

iTec leverer gassutstyr fra den tyske høykvalitetsleverandøren Spectron. I samarbeid med leverandør kan vi levere gassutstyr til ulike industrier; medisinsk, farmasøytisk, prosess, akvakultur og næringsmiddel applikasjoner.

Spectron har en bred produktportefølje som inneholder komponenter for alle typer komprimerte gasser og bruksområder.

Denne katalogen inneholder teknisk spesifikasjon på gassutstyr i forkrommet utførelse (SpectroLab).

Generell informasjon:

Inngangstrykk	: fra 0 - 300 bar
Utgangstrykk	: fra 0 - 200 bar
Max volumstrøm gass	: 50 m ³ /t
Lekkasjerate	: 1x10 ⁻⁸ mbar l/s


Alle produktene tilfredsstiller de normer og lovpålagte krav som gjelder for gass og trykkpåkjent utstyr.

iTec leverer komplette gass distribusjonsløsninger, med tilhørende prosjektering/ dimensjonering og dokumenter jobben i henhold til kundens krav.

Det tas forbehold om endringer på produktenes visuelle utforming vist i denne katalogen.

Ta kontakt med iTec for nærmere informasjon om prosjektering/ dimensjonering, priser, normer og lovpålagte krav, installasjon, service og preventivt vedlikehold av dine gasssystemer.

Med vennlig hilsen



Daniel R. Persen
Salgssjef Gassutstyr



FORORD	02
LINJEREGULATOR (LINE PRESSURE REGULATORS)	04
LM51-2	04
LM51-4	06
LM51-6	08
LM52exact-2	10
LM52exact-4	12
LM52exact-6	14
LM53-2	16
LM53-6	18
LM61/LM62	20
LM71	22
FLASKEREGULATOR (CYLINDER PRESSURE REGULATORS)	25
FM45	25
FM51	27
FM52exact	29
FM53	31
FM61/ FM62	33
PANELREGULATOR (PANEL PRESSURE REGULATORS)	36
PM51-2	36
PM51-4	38
PM51-6	40
PM52exact-2	42
PM52exact-4	44
PM52exact-6	46
PM53-2	48
PM53-6	50
GASSENTRAL (PRESSURE CONTROL PANELS)	53
BM55-1	53
BM55-2	55
BM56-1	57
BM56-2	59
BM55-2U	61
BM56-2U	63
BM55-2A	65
BM50-1+2	66
BM55+56-E	67
BM65-1	69
BM66-1	71
BM65-2	73
BM65-2U	75
BM65-2L	77
BM65-E	79
BM65-AC	81
BM65-2A-AC	83
VENTILER (VALVES)	86
MV3-M	86
DVM	88
V6M-3	90
UTTAKSPOST (TAPPING POINTS)	92
EM55	92
EM65	94
EM15/EE15	96
EM55 (Spectrolab plus)	109
EM65-AC	119
TILBEHØR (ACCESSORIES)	120
Flowmeter FLM 32	120
Pigtails og Braketter	122
Høytrykkslanger HDS	124

LINJEREGULATOR

LM51-2



Line pressure regulator LM51-2



Line pressure regulator LM51-2

- Specifications**
- SPECTROLAB-components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
 - All parts in the gas wetted surface area are cleaned in an ultrasonic cleaning system (CFC-free) with the special Cleaning process SPECTRO-CLEAN® and then baked out.
 - SPECTROLAB-components undergo a 100% function- and Helium-leak-test.

- Product features**
- Brass (chrome plated) line pressure regulator
 - For non-corrosive gases and gas mixtures up to quality 6.0
 - 2 ports for flexible and individual configuration
 - Very stable outlet pressure
 - Suitable for inlet pressures up to 300 bar
 - Max. outlet pressures 1,5 up to 200 bar *
 - Metal-to-metal seal to atmosphere
 - Suitable for ECD-applications
 - Pressure regulator can be evacuated
 - Inlet filter
 - Approved for use with oxygen
 - Simple outlet pressure limitation by handwheel
 - Easy to install
 - New laboratory-style design
 - Ergonomically designed



* 1,5 / 4 bar only for inlet pressure ≤ 50 bar

Technical data

Type	single-stage
Inlet pressure P ₁	max. 300 bar
Outlet pressure P ₂	1,5 / 4 bar (P ₁ ≤ 50 bar) 10 / 20 / 50 / 100 / 200 bar (P ₁ > 50 bar)
Materials	
Body regulator:	chrome plated brass
Valve seat:	PA
Diaphragm:	Hastelloy C276
Filter:	Sintered SS 316L
In- and outlets	1/4" NPT-F
Temperature range	-30°C to +60°C
Leak rate (to atmosphere) (via seat)	1x10 ⁻⁸ mbar l/s He 1x10 ⁻⁶ mbar l/s He
Flow capacity	C _v =0.15
Weight	1.0 kg

Dimensions
LM51-2

Side view




Line pressure regulator LM51-2

spectro lab

Ordering information:

Line pressure regulator LM51-2



Ordering example:

LM51-2-300-10-CE6-CE6-N2



LINJEREGULATOR

LM51-4




Line pressure regulator LM51-4



- Specifications**
- SPECTROLAB-components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
 - All parts in the gas wetted surface area are cleaned in an ultrasonic cleaning system (CFC-free) with the special Cleaning process SPECTRO-CLEAN® and then baked out.
 - SPECTROLAB-components undergo a 100% function- and Helium-leak-test.


<p>Product features</p> <ul style="list-style-type: none"> Brass (chrome plated) line pressure regulator For non-corrosive gases and gas mixtures up to quality 6.0 4 ports for flexible and individual configuration Very stable outlet pressure Suitable for inlet pressures up to 300 bar Max. outlet pressures 1,5 up to 200 bar * Metal-to-metal seal to atmosphere Suitable for ECD-applications Pressure regulator can be evacuated Inlet filter Approved for use with oxygen Simple outlet pressure limitation by handwheel Easy to install New laboratory-style design Ergonomically designed 																			
<p>* 1,5 / 4 bar only for inlet pressure ≤ 50 bar</p>																			
<p>Technical data</p> <table> <tr> <td>Type</td><td>single-stage</td></tr> <tr> <td>Inlet pressure P₁</td><td>max. 300 bar</td></tr> <tr> <td>Outlet pressure P₂</td><td>1,5 / 4 bar (P₁ ≤ 50 bar) 10 / 20 / 50 / 100 / 200 bar (P₁ > 50 bar)</td></tr> </table> <p>Materials</p> <p>Body regulator, relief valve: chrome plated brass Valve seat: PA Diaphragm: Hastelloy C276 Filter: Sintered SS 316L</p> <table> <tr> <td>In- and outlets</td><td>1/4" NPT-F</td></tr> <tr> <td>Temperature range</td><td>-30°C to +60°C</td></tr> <tr> <td>Leak rate (to atmosphere) (via seat)</td><td>1x10⁻³ mbar l/s He 1x10⁻⁶ mbar l/s He</td></tr> <tr> <td>Pressure gauge</td><td>Safety pressure gauges ISO5171/KI1.6/NG50</td></tr> <tr> <td>Flow capacity</td><td>C_v=0.15</td></tr> <tr> <td>Weight</td><td>1.0 kg</td></tr> </table>		Type	single-stage	Inlet pressure P ₁	max. 300 bar	Outlet pressure P ₂	1,5 / 4 bar (P ₁ ≤ 50 bar) 10 / 20 / 50 / 100 / 200 bar (P ₁ > 50 bar)	In- and outlets	1/4" NPT-F	Temperature range	-30°C to +60°C	Leak rate (to atmosphere) (via seat)	1x10 ⁻³ mbar l/s He 1x10 ⁻⁶ mbar l/s He	Pressure gauge	Safety pressure gauges ISO5171/KI1.6/NG50	Flow capacity	C _v =0.15	Weight	1.0 kg
Type	single-stage																		
Inlet pressure P ₁	max. 300 bar																		
Outlet pressure P ₂	1,5 / 4 bar (P ₁ ≤ 50 bar) 10 / 20 / 50 / 100 / 200 bar (P ₁ > 50 bar)																		
In- and outlets	1/4" NPT-F																		
Temperature range	-30°C to +60°C																		
Leak rate (to atmosphere) (via seat)	1x10 ⁻³ mbar l/s He 1x10 ⁻⁶ mbar l/s He																		
Pressure gauge	Safety pressure gauges ISO5171/KI1.6/NG50																		
Flow capacity	C _v =0.15																		
Weight	1.0 kg																		




Line pressure regulator LM51-4

spectro lab

Ordering information:
Line regulator LM51-4



Ordering example:
LM51-4-300-10-CE6-M-CE6-B-N2



Line pressure regulator LM51-6

spectro lab



Line regulator LM51-6

Specifications

- SPECTROLAB-components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All parts in the gas wetted surface area are cleaned in an ultrasonic cleaning system (CFC-free) with the special Cleaning process SPECTRO-CLEAN® and then baked out.
- SPECTROLAB-components undergo a 100% function- and Helium-leak-test.

Product features

- Brass (chrome plated) line pressure regulator
- For non-corrosive gases and gas mixtures up to quality 6.0
- 6 ports for flexible and individual configuration
- Extremely stable outlet pressure
- Suitable for inlet pressures up to 300 bar
- Max. outlet pressures 1,5 up to 200 bar *
- Metal-to-metal seal to atmosphere
- Suitable for ECD-applications
- Pressure regulator can be evacuated
- Inlet filter
- Approved for use with oxygen
- Simple outlet pressure limitation by handwheel
- Easy to install
- New laboratory-style design
- Ergonomically designed



* 1,5 / 4 bar only for inlet pressure ≤ 50 bar

Technical data

Type	single-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	1,5 / 4 bar ($P_1 \leq 50$ bar) 10 / 20 / 50 / 100 / 200 bar ($P_1 > 50$ bar)
Materials	
Body regulator, relief valve:	chrome plated brass
Valve seat:	PA
Diaphragm:	Hastelloy C276
Filter:	Sintered SS 316L
In- and outlets	1/4" NPT-F
Temperature range	-30°C to +60°C
Leak rate (to atmosphere) (via seat)	1×10^{-8} mbar l/s He 1×10^{-6} mbar l/s He
Pressure gauge	Safety pressure gauges ISO5171/KI1.6/NG50
Flow capacity	$C_v=0.15$
Weight	1.1 kg

Dimensions
LM51-6


Side view




Line pressure regulator LM51-6

spectro lab

Ordering information:
Line regulator LM51-6



Ordering example:
LM51-6-L-20-10-CE6-M-M-CE6-B-0-N2



Ordering example:
LM51-6-R-200-10-0-M-M-CE1/8-A-B-Ar



Line regulator LM52^{exact}-2

spectro lab



Line regulator LM52^{exact}-2

Specifications

- SPECTROLAB-components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All parts in the gas wetted surface area are cleaned in an ultrasonic cleaning system (CFC-free) with the special Cleaning process SPECTRO-CLEAN® and then baked out.
- SPECTROLAB-components undergo a 100% function- and Helium-leak-test.

Product features

- Brass (chrome plated) line pressure regulator
- Extremely stable outlet pressure by applied extremely accurate Technology "exact" and anti- vibration device
- For non-corrosive gases and gas mixtures up to quality 6.0
- 2 ports for flexible and individual configuration
- Suitable for inlet pressures up to 300 bar
- Max. outlet pressures 1.5 up to 20 bar
- Light weight
- Compact design
- Metal-to-metal seal to atmosphere
- Suitable for ECD-applications
- Pressure regulator can be evacuated
- Central filter
- Approved for use with oxygen
- Simple outlet pressure limitation by handwheel
- Easy to install
- New laboratory-style design
- Ergonomically designed

exact = extremely accurate technology

Technical data

Type single-stage EXACT

Inlet pressure P_1 max. 300 bar

Outlet pressure P_2 1.5 / 4 / 10 / 20 bar

Materials

Body regulator: chrome plated brass

Valve seat: PA

Diaphragm: Hastelloy C276

Soft goods: EPDM

Filter: Sintered SS 316L

In- and outlets 1/4" NPT female


Temperature range -30°C to +60°C

Leak rate (to atmosphere) 1×10^{-8} mbar l/s He
(via seat) 1×10^{-6} mbar l/s He


Flow capacity $C_v=0.16$

Weight 1.0 kg

Dimensions
LM52^{exact}-2




Side view



Line regulator LM52^{exact}-2

Ordering information:


Line regulator LM52^{exact}-2



For inlet pressure up to 50 bar and outlet pressure of max. 1,5 or 4 bar please use M51

Ordering example:

LM52-2-300-10-CE6-CE6-N2



Line regulator LM52^{exact}-4

spectro lab



Line regulator
LM52^{exact}-4

Specifications

- SPECTROLAB-components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All parts in the gas wetted surface area are cleaned in an ultrasonic cleaning system (CFC-free) with the special Cleaning process SPECTRO-CLEAN® and then baked out.
- SPECTROLAB-components undergo a 100% function- and Helium-leak-test.

Product features


- Brass (chrome plated) line pressure regulator
- Extremely stable outlet pressure by applied extremely accurate Technology "exact" and anti-vibration device
- For non-corrosive gases and gas mixtures up to quality 6.0
- 4 ports for flexible and individual configuration
- Suitable for inlet pressures up to 300 bar
- Max. outlet pressures 1.5 up to 20 bar
- Light weight
- Compact design
- Metal-to-metal seal to atmosphere
- Suitable for ECD-applications
- Pressure regulator can be evacuated
- Central filter
- Approved for use with oxygen
- Simple outlet pressure limitation by handwheel
- Easy to install
- New laboratory-style design
- Ergonomically designed

exact = extremely accurate technology


Technical data

Type	single-stage EXACT
Inlet pressure P₁	max. 300 bar
Outlet pressure P₂	1.5 / 4 / 10 / 20 bar
Materials	
Body regulator, relief valve:	chrome plated brass
Valve seat:	PA
Diaphragm:	Hastelloy C276
Soft goods:	EPDM
Filter:	Sintered SS 316L
In- and outlets	1/4" NPT female
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
(via seat)	1x10 ⁻⁸ mbar l/s He
Pressure gauge	Safety pressure gauges ISO5171/K11.6/NG50
Flow capacity	C _v =0.16
Weight	1.0 kg

Dimensions
LM52^{exact}-4



Side view



Line regulator LM52^{exact}-4


spectro lab

Ordering information:

Line regulator LM52^{exact}-4

In- / outlets

- CM 1/4 - 1/8" / 1/4" / 1/2" - OD compression fitting (brass)
- CM 6 - 3/6/8/10/12mm compression fitting (brass)
- CE 1/4 - 1/8" / 1/4" / 1/2" - OD compression fitting (stainless steel)
- CE 6 - 3/6/8/10/12mm compression fitting (stainless steel)
- B - plug
- A - relief valve - 1/4"-NPT-F
- K - contact gauge
- M - pressure gauge
- 0 - 1/4"-NPT-F (port only)



port selection

LM52 - 4 - 300 - 10 - 1 - 2 - 3 - 4 - N2

Inlet pressure P₁

- 100 - max. 100 bar
- 200 - max. 200 bar
- 300 - max. 300 bar

Outlet pressure P₂

- 1,5- to 1.5 bar
- 4 - to 4 bar
- 10 - to 10 bar
- 20 - to 20 bar


Type of gas

Please specify type of gas
(for selection of valve seat
materials)

For inlet pressure up to 50 bar and outlet pressure of max. 1,5 or 4 bar please use M51

Ordering example:

LM52-4-300-10-CE6-M-CE6-B-N2



Line regulator LM52^{exact}-6

spectro lab



Line regulator
LM52^{exact}-6

Specifications

- SPECTROLAB-components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All parts in the gas wetted surface area are cleaned in an ultrasonic cleaning system (CFC-free) with the special Cleaning process SPECTRO-CLEAN® and then baked out.
- SPECTROLAB-components undergo a 100% function- and Helium-leak-test.

Product features


- Brass (chrome plated) line pressure regulator
- Extremely stable outlet pressure by applied extremely accurate Technology "exact" and anti-vibration device
- For non-corrosive gases and gas mixtures up to quality 6.0
- 6 ports for flexible and individual configuration
- Suitable for inlet pressures up to 300 bar
- Max. outlet pressures 1.5 up to 20 bar
- Light weight
- Compact design
- Metal-to-metal seal to atmosphere
- Suitable for ECD-applications
- Pressure regulator can be evacuated
- Central filter
- Approved for use with oxygen
- Simple outlet pressure limitation by handwheel
- Easy to install
- New laboratory-style design
- Ergonomically designed

exact = extremely accurate technology


Technical data

Type	single-stage EXACT
Inlet pressure P₁	max. 300 bar
Outlet pressure P₂	1.5 / 4 / 10 / 20 bar
Materials	
Body regulator, relief valve:	chrome plated brass
Valve seat:	PA
Diaphragm:	Hastelloy C276
Soft goods:	EPDM
Filter:	Sintered SS 316L
In- and outlets	1/4" NPT female
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
(via seat)	1x10 ⁻⁶ mbar l/s He
Pressure gauge	Safety pressure gauges ISO5171/K11.6/NG50
Flow capacity	C _v =0.16
Weight	1.1 kg

Dimensions
LM52^{exact}-6



Side view



Line regulator LM52^{exact}-6


spectro lab

Ordering information:

Line regulator LM52^{exact}-6

In- / outlets

CM 1/4	- 1/8" / 1/4" / 1/2" - OD compression fitting (brass)
CM 6	- 3 / 6 / 8 / 10 / 12 mm compression fitting (brass)
CE 1/4	- 1/8" / 1/4" / 1/2" - OD compression fitting (stainless steel)
CE 6	- 3 / 6 / 8 / 10 / 12 mm compression fitting (stainless steel)
B	- plug
A	- relief valve - 1/4"-NPT-F
K	- contact gauge
M	- pressure gauge
0	- 1/4"-NPT-F (port only)



Inlet left: **L**

LM52 - 6 - **L** - 300 - 20 - 1 - 2 - 3 - 4 - 5 - 6 - N2

Inlet

- L** - left
- R** - right

Inlet pressure P_1


- 100** - max. 100 bar
- 200** - max. 200 bar
- 300** - max. 300 bar

Outlet pressure P_2

- 1,5** - to 1.5 bar
- 4** - to 4 bar
- 10** - to 10 bar
- 20** - to 20 bar

Type of gas

Please specify type of gas
(for selection of valve seat
materials)




Inlet right: **R**

port selection

For inlet pressure up to 50 bar and outlet pressure of max. 1,5 or 4 bar please use M51

Ordering example:

LM52-6-**L**-20-10-CE6-M-M-CE6-A-B-N2



Ordering example:

LM52-6-**R**-200-10-0-M-M-CE1/8-A-B-Ar



Line pressure regulator LM53-2

spectro lab



Line pressure regulator LM53-2

Specifications

- SPECTROLAB-components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All parts in the gas wetted surface area are cleaned in an ultrasonic cleaning system (CFC-free) with the special Cleaning process SPECTRO-CLEAN® and then baked out.
- SPECTROLAB-components undergo a 100% function- and Helium-leak-test.


Product features

- 2-stage diaphragm line pressure regulator with extremely stable outlet pressure and anti-vibration device
- For non-corrosive gases and gas mixtures up to quality 6.0
- 2 ports for flexible and individual configuration
- New laboratory-style design
- Central filter
- Suitable for ECD-applications
- Pressure regulator can be evacuated
- Suitable for inlet pressures up to 300 bar
- Max. outlet pressures 1.5 up to 20 bar
- Light weight
- Compact design
- Approved for use with oxygen
- Simple outlet pressure limitation by handwheel
- Easy to install

Technical data

Type	double-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	1.5 / 4 / 10 / 20 bar
Materials	
Body regulator, relief valve:	chrome plated brass
Valve seat:	PA
Diaphragm:	Hastelloy C276
Soft goods:	EPDM
Filter:	Sintered bronze
In- and outlets	1/4" NPT-F
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
(via seat)	1x10 ⁻⁶ mbar l/s He
Weight	1.6 kg

Flow curves LM53





LINJEREGULATOR

LM53-2



Line pressure regulator LM53-2

spectro lab




Line pressure regulator LM53-6

spectro lab



Line pressure regulator LM53-6




Product features

- 2-stage diaphragm line pressure regulator with extremely stable outlet pressure and anti-vibration device
- For non-corrosive gases and gas mixtures up to quality 6.0
- 6 ports for flexible and individual configuration
- New laboratory-style design
- Central filter
- Suitable for ECD-applications
- Pressure regulator can be evacuated
- Suitable for inlet pressures up to 300 bar
- Max. outlet pressures 1.5 up to 20 bar
- Light weight
- Compact design
- Approved for use with oxygen
- Simple outlet pressure limitation by handwheel
- Easy to install

Technical data


Type	double-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	1.5 / 4 / 10 / 20 bar
Materials	
Body regulator, relief valve:	chrome plated brass
Valve seat:	PA
Diaphragm:	Hastelloy C276
Soft goods:	EPDM
Filter:	Sintered bronze
In- and outlets	1/4" NPT-F
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
(via seat)	1x10 ⁻⁶ mbar l/s He
Pressure gauge	Safety pressure gauges ISO5171/KI1.6/NG50
Weight	1.7 kg

Flow curves LM53




Line pressure regulator LM53-6

Dimensions



Ordering information:
Line pressure regulator LM53



For inlet pressure up to 50 bar and outlet pressure of max. 1.5 or 4 bar please use M51


Line pressure regulator LM61 / LM62

spectro lab



Line pressure regulator LM61 / LM62

Dimensions Pressure regulator LM61 / LM62




Product features

- Single- or double-stage line pressure regulator for non-corrosive gases and gas mixtures up to quality 6.0
- New laboratory-style design
- Central filter
- High control accuracy
- Integrated relief valve
- Tested for use with oxygen
- Suitable for ECD-applications
- Simple outlet pressure limitation by handwheel
- Powder-coated bonnet
- Piston type regulators for outlet pressure >20 bar

Technical data

Inlet pressure P_1	max. 300 bar
Max. outlet pressure P_2	1,5/4/10/20/50/100 bar
Flow rate Q	see flow curves
Materials	
Body:	chrome-plated brass
Diaphragm:	stainless steel 1.4310
Valve seat:	PA 11 or EPDM
Piston ($P_2 > 20$ bar):	Messing
Connectors	1/4" NPT female
Relief valve connector	1/8" NPT female
Leak rate	1×10^{-8} mbar l/s He
Weight	1,3 kg (LM61) 1,6 kg (LM62)


Flow curves LM61 / LM62



Line pressure regulator LM61 / LM62

spectro lab

Dimensions - pressure regulator LM61 / LM62



Additional configurations upon request!

Ordering information: LM61 / LM62 series line pressure regulators

LM 61 - 200 - 10 - M - M - A - N₂

Type

- 61 - single-stage
- 62 - double-stage

Inlet pressure P₁

- 40 - max. 40 bar (only LM61)
- 200 - max. 200 bar
- 300 - max. 300 bar

Outlet pressure P₂

- 1,5 - to 1,5 bar (LM62)
- 4 - to 4 bar (LM62)
- 10 - to 10 bar
- 20 - to 20 bar
- 50 - to 50 bar (piston type)
- 100 - to 100 bar (piston type)

Inlet press. indication

- B - plug
- M - pressure gauge
- 0 - 1/4"-NPT-F (port only)

Type of gas

Please specify type of gas!

Relief valve

- B - without relief valve (plug)
- A - relief valve

Outlet press. indication

- B - plug
- M - pressure gauge
- 0 - 1/4"-NPT-F (port only)

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% Helium-leak-test.

Pressure indication

- All pressure regulators are equipped with pressure gauges for inlet- and outlet pressure indication.

Important note regarding component selection

- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a pressure regulator.
- The function of the regulator, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.


Line pressure regulator LM71

spectro lab



Pressure regulator LM71

Dimensions Pressure regulator LM71




Product features

- Single-stage line pressure regulator for non-corrosive gases and gas mixtures up to quality 6.0.
- New laboratory-style design
- High control accuracy
- Suitable for ECD-applications
- Simple outlet pressure limitation by handwheel
- Powder-coated bonnet

Technical data

Inlet pressure P_1	max. 50 bar
Outlet pressure P_2	max. 20 bar
Flow rate Q	see flow curves
Materials	
Body:	chrome-plated brass
Diaphragm:	Hastelloy
Valve seat:	PTFE
In- / outlet	3/8"-NPT female
Pressure gauge connect.	1/4"-NPT female
Leak rate	1×10^{-8} mbar l/s He
Weight	1,5 kg

Flow curves LM71



LINJEREGULATOR


LM71




Line pressure regulator LM71

spectro lab


Dimensions - LM71



side view



rear view / mounting



Ordering information: LM71 series pressure regulators

LM71 - 50 - 10 - 0 - M - 0 - N₂

Inlet pressure P₁

50 - max. 50 bar

Outlet pressure P₂

1,5 - to 1,5 bar
4 - to 4 bar
10 - to 10 bar
20 - to 20 bar

Type of gas

Please specify type of gas!

Outlet press. indication

B - plug
M - pressure gauge
0 - 1/4"-NPT port

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% function- and Helium-leak-test.

Important note regarding component selection

- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control panel.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.



Flaskeregulator FM53/FE53

FLASKEREGULATOR

FM45




Cylinder regulator FM45

spectro lab



Cylinder pressure regulator FM45



Product features


- Single-stage cylinder pressure regulator with compensated main valve for improved performance
- Simple and safe gas withdrawal from gas cylinders, for non-corrosive gases and gas mixtures up to quality 6.0
- Compensated main valve for significantly improved outlet pressure accuracy similar to a dual-stage regulator
- Compact design, light weight
- New laboratory-style design
- Manual cylinder connection (for non-metal-to-metal sealing cylinder connections)
- Suitable for ECD-applications
- High control accuracy
- Integrated relief valve
- Hastelloy-diaphragm
- Minimised gas-wetted surface

Technical data

Inlet pressure P_1	max. 230 bar 300 bar on request
Outlet pressure P_2	0.1 - 10 bar
Materials	
Body:	chrome-plated brass
Diaphragm:	Hastelloy C276
Valve seat:	PCTFE ¹⁾
Cylinder connection	acc. to international standards and gas type
Outlet connector	1/8"-NPT female
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	10 ⁻⁸ mbar l/sec He
Weight	520 g

¹⁾ Other valve seat materials such as PVDF upon request


Flow curves FM45



Cylinder regulator FM45

spectro lab

Dimensions



Additional configurations upon request!

Ordering information:
FM45 series cylinder regulators

FM45 - 230 - 4 - DIN477-1 - H₂

Inlet pressure P₁

230 - max. 230 bar

Outlet pressure P₂

1,5 - up to 1.5 bar
4 - up to 4 bar
10 - up to 10 bar

Type of gas

Please specify type of gas (for selection of valve seat material)

Cylinder connection

Detailed description of the cylinder connection including the relevant standard and the number of the connection (e.g. DIN477-1)

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% function- and Helium-leak-test.

Pressure indication

- All pressure regulators are equipped with pressure gauges for inlet- and outlet pressure indication.

Important note regarding component selection

- In order to assure safe operation it is essential to take the configuration of the whole gas supply system into account when selecting a pressure regulator.
- The function of the regulator, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

FLASKEREGULATOR

FM51



Cylinder regulator FM51

spectro lab



Cylinder regulator FM51

Specifications

- SPECTROLAB-components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All parts in the gas wetted surface area are cleaned in an ultrasonic cleaning system (CFC-free) with the special Cleaning process SPECTRO-CLEAN® and then baked out.
- SPECTROLAB-components undergo a 100% function- and Helium-leak-test.

Product features


- Brass (chrome plated) cylinder pressure regulator
- For non-corrosive gases and gas mixtures up to quality 6.0
- 6 ports for flexible and individual configuration
- Very stable outlet pressure
- Suitable for inlet pressures up to 300 bar
- Max. outlet pressures 1,5 up to 200 bar *
- Metal-to-metal seal to atmosphere
- Suitable for ECD-applications
- Pressure regulator can be evacuated
- Inlet filter
- Approved for use with oxygen
- Simple outlet pressure limitation by handwheel
- Easy to install
- New laboratory-style design
- Ergonomically designed

* 1,5 / 4 bar only for inlet pressure ≤ 50 bar


Technical data

Type	single-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	1,5 / 4 bar ($P_1 \leq 50$ bar) 10 / 20 / 50 / 100 / 200 bar ($P_1 > 50$ bar)
Materials	
Body regulator, relief valve:	chrome plated brass
Valve seat:	PA
Diaphragm:	Hastelloy C276
Filter:	Sintered SS 316L
In- and outlets	1/4" NPT-F
Temperature range	-30°C to +60°C
Leak rate (to atmosphere) (via seat)	1×10^{-8} mbar l/s He 1×10^{-6} mbar l/s He
Pressure gauge	Safety pressure gauges ISO5171/K11.6/NG50
Flow capacity	$C_v=0.15$
Weight	1.2 kg

Dimensions
FM51



Side view




Cylinder regulator FM51

spectro lab


Ordering information:
Cylinder regulator FM51

In- / outlets

- CM 1/4 - 1/8" / 1/4" / 1/2" - OD compression fitting (brass)
- CM 6 - 3/6/8/10/12 mm compression fitting (brass)
- CE 1/4 - 1/8" / 1/4" / 1/2" - OD compression fitting (stainless steel)
- CE 6 - 3/6/8/10/12 mm compression fitting (stainless steel)
- B - plug
- A - relief valve - 1/4"-18 NPT-F ($P_2 \leq 100$ bar)
- xxxx - detailed specification of cylinder connection including the relevant standard and number (e.g. BS no.3 for nitrogen up to 230 bar)
- K - contact gauge
- M - pressure gauge
- 0 - 1/4"-NPT-F (port only)



Inlet left: **L**



Inlet right: **R**

FM51 - L - 300 - 20 - 1 - 2 - 3 - 4 - 5 - 6 - N2

Inlet

- L - left
- R - right

Inlet pressure P_1

- | | |
|------------------|--------------------|
| 10 - max. 10 bar | 100 - max. 100 bar |
| 20 - max. 20 bar | 200 - max. 200 bar |
| 50 - max. 50 bar | 300 - max. 300 bar |

Outlet pressure P_2


- 1,5 - to 1,5 bar ($P_1 \leq 50$ bar)
- 4 - to 4 bar ($P_1 \leq 50$ bar)
- 10 - to 10 bar
- 20 - to 20 bar
- 50 - to 50 bar
- 100 - to 100 bar
- 200 - to 200 bar

Type of gas

Please specify type of gas
(for selection of valve seat materials)

Ordering example:

FM51-L-200-10-DIN10-M-M-CE6-A-B-N2



Ordering example:

FM51-R-200-10-CGA540-M-M-CE1/8-A-B-Ar



Cylinder regulator FM52^{exact}

spectro lab



Cylinder regulator FM52^{exact}

Specifications

- SPECTROLAB-components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All parts in the gas wetted surface area are cleaned in an ultrasonic cleaning system (CFC-free) with the special Cleaning process SPECTRO-CLEAN[®] and then baked out.
- SPECTROLAB-components undergo a 100% function- and Helium-leak-test.

Product features


- Brass (chrome plated) cylinder pressure regulator
- Extremely stable outlet pressure by applied extremely accurate Technology "exact" and anti- vibration device
- For non-corrosive gases and gas mixtures up to quality 6.0
- 6 ports for flexible and individual configuration
- Suitable for inlet pressures up to 300 bar
- Max. outlet pressures 1.5 up to 20 bar
- Light weight
- Compact design
- Metal-to-metal seal to atmosphere
- Suitable for ECD-applications
- Pressure regulator can be evacuated
- Central filter
- Approved for use with oxygen
- Simple outlet pressure limitation by handwheel
- Easy to install
- New laboratory-style design
- Ergonomically designed

exact = extremely accurate technology


Technical data

Type	single-stage EXACT
Inlet pressure P₁	max. 300 bar
Outlet pressure P₂	1.5 / 4 / 10 / 20 bar
Materials	
Body regulator, relief valve:	chrome plated brass
Valve seat:	PA
Diaphragm:	Hastelloy C276
Soft goods:	EPDM
Filter:	Sintered SS 316L
In- and outlets	1/4" NPT female
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
(via seat)	1x10 ⁻⁶ mbar l/s He
Pressure gauge	Safety pressure gauges ISO5171/K11.6/NG50
Flow capacity	C _v =0.16
Weight	1.2 kg

Dimensions



Side view FM52^{exact}



Cylinder regulator FM52^{exact}

spectro lab

Ordering information:
Cylinder regulator FM52^{exact}

In- / outlets

CM 1/4	- 1/8" / 1/4" / 1/2" - OD compression fitting (brass)
CM 6	- 3/6/8/10/12 mm compression fitting (brass)
CE 1/4	- 1/8" / 1/4" / 1/2" - OD compression fitting (stainless steel)
CE 6	- 3/6/8/10/12 mm compression fitting (stainless steel)
B	- plug
A	- relief valve - 1/4"-NPT-F
xxxx	- detailed specification of cylinder connection including the relevant standard and number (e.g. BS no.3 for nitrogen up to 230 bar)
K	- contact gauge
M	- pressure gauge
0	- 1/4"-NPT-F (port only)

Inlet left: L

FM52 - L - 300 - 20 - 1 - 2 - 3 - 4 - 5 - 6 - N2

Inlet

L - left
R - right

Inlet pressure P₁

100 - max. 100 bar
200 - max. 200 bar
300 - max. 300 bar

Outlet pressure P₂

1,5 - to 1.5 bar
4 - to 4 bar
10 - to 10 bar
20 - to 20 bar

Type of gas

Please specify type of gas (for selection of valve seat materials)

For inlet pressure up to 50 bar and outlet pressure of max. 1,5 or 4 bar please use M51


Ordering example:
FM52-L-200-10-DIN10-M-M-CE6-A-B-N2

Ordering example:
FM52-R-200-10-CGA540-M-M-CE1/8-A-B-Ar

Cylinder pressure regulator FM53

spectro lab


Dimensions



Ordering information:
Cylinder pressure regulator FM53

In- / outlets

- CM 1/4 - 1/8" / 1/4" / 1/2" - OD compression fitting (brass)
- CM 6 - 3/6/8/10/12 mm compression fitting (brass)
- CE 1/4 - 1/8" / 1/4" / 1/2" - OD compression fitting (stainless steel)
- CE 6 - 3/6/8/10/12 mm compression fitting (stainless steel)
- B - plug
- A - relief valve - 1/4" NPT-F
- xxxx - detailed specification of cylinder connection including the relevant standard and number (e.g. BS no.3 for nitrogen up to 230 bar)
- K - contact gauge
- M - pressure gauge
- 0 - 1/4" NPT-F (port only)



Inlet left: **L**

FM53 - L - 300 - 20 - 1 - 2 - 3 - 4 - 5 - 6 - N2

Inlet

- L - left
- R - right


Inlet pressure P₁

- 100 - max. 100 bar
- 200 - max. 200 bar
- 300 - max. 300 bar

port selection

Outlet pressure P₂

- 1,5 - to 1.5 bar
- 4 - to 4 bar
- 10 - to 10 bar
- 20 - to 20 bar



Inlet right: **R**

Type of gas

Please specify type of gas (for selection of valve seat materials)

For inlet pressure up to 50 bar and outlet pressure of max. 1,5 or 4 bar please use M51


Cylinder regulator FM 61/ FM 62

spectro lab



Cylinder regulator FM 61

Dimensions
FM61/FM62




Product features

- Single- and dual-stage cylinder pressure regulators
- Simple and safe gas withdrawal from gas cylinders, for non-corrosive gases and gas mixtures up to quality 6.0
- New laboratory-style design
- Manual cylinder connection (not for metal-to-metal sealing connections)
- Ergonomically designed
- Filter at the regulator inlet
- Suitable for ECD-applications
- High control accuracy
- Integrated relief valve
- Simple outlet pressure limitation by handwheel
- Powder-coated bonnet
- Piston type regulators for outlet pressure >20 bar
- Tested for use with oxygen
- Compact design

Technical data


Inlet pressure P_1	max. 200/300 bar
Max. Outlet pressure P_2	1,5/4/10/20/50/100 bar
Flow rate Q	see flow curves
Materials	
Body:	chrome-plated brass
Diaphragms:	SS 1.4310 (SS 301)
Valve seat:	PA11 or EPDM, depending on gas type
Piston ($P_2 > 20$ bar):	brass
Cylinder connection	acc. to international standards and gas type
Outlet connector	1/4"-18 NPT-F
Relief valve connector	1/8"-27 NPT-F
Leak rate	10^{-8} mbar l/s He
Weight	1,8 kg (FM61) 2,1 kg (FM62)

Flow curves FM 61 / FM 62



FM 61
Inlet pressure
 $P_1 = 21$ bar

Flow rate
 Q [m³/h air]




FM 62
Inlet pressure
 $P_1 = 9$ bar

Flow rate
 Q [m³/h air]


Cylinder regulator FM 61/ FM 62

spectro lab

Cylinder pressure regulator FM61/FM62



Side view



Additional configurations upon request!

Ordering information: FM 61/ FM 62 series cylinder regulators

FM 61 - 200 - 10 - DIN 10 - N₂

Please specify gas type with your order (valve seat material)

Type

- 61 - single-stage regulator
- 62 - dual-stage regulator

Inlet pressure P₁

- 200 - max. 200 bar
- 300 - max. 300 bar

Outlet pressure P₂

- 1,5 - up to 1,5 bar (2-stage only)
- 4 - up to 4 bar (2-stage only)
- 10 - up to 10 bar (2-stage only)
- 20 - up to 20 bar (1-stage)
- 50 - up to 50 bar (1-stage, piston type regulator)
- 100 - up to 100 bar (1-stage, piston type regulator)

Type of gas

Please specify gas type!

Cylinder connection

Detailed description of the cylinder connection including the relevant standard and the number of the connection (e.g. BS no. 3)

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% Helium-leak-test.

Pressure indication

- All pressure regulators are equipped with pressure gauges for inlet- and outlet pressure indication.

Important note regarding component selection

- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a pressure regulator.
- The function of the regulator, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.



Flaskeregulator FM51/FE51

PANELREGULATOR

PM51-2




Panel regulator PM51-2



Product features <ul style="list-style-type: none"> • Brass (chrome plated) panel pressure regulator • For non-corrosive gases and gas mixtures up to quality 6.0 • 2 ports for flexible and individual configuration • Very stable outlet pressure • Suitable for inlet pressures up to 300 bar • Max. outlet pressures 1,5 up to 200 bar * • Metal-to-metal seal to atmosphere • Suitable for ECD-applications • Pressure regulator can be evacuated • Inlet filter • Approved for use with oxygen • Simple outlet pressure limitation by handwheel • Easy to install • New laboratory-style design • Ergonomically designed 	
Technical data	
Type	single-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	1,5 / 4 bar ($P_1 \leq 50$ bar) 10 / 20 / 50 / 100 / 200 bar ($P_1 > 50$ bar)
Materials	
Body regulator:	chrome plated brass
Valve seat:	PA
Diaphragm:	Hastelloy C276
Filter:	Sintered SS 316L
In- and outlets	1/4" NPT-F
Temperature range	-30°C to +60°C
Leak rate (to atmosphere) (via seat)	1×10^{-3} mbar l/s He 1×10^{-6} mbar l/s He
Flow capacity	$C_v=0.15$
Weight	1.0 kg

* 1,5 / 4 bar only for inlet pressure ≤ 50 bar



PANELREGULATOR

PM51-2



Panel regulator PM51-2

Ordering information:
Panel regulator PM51-2

In- / outlets

CM 1/4	- 1/8" / 1/4" / 1/2" - OD compression fitting (brass)
CM 6	- 3/6/8/10/12mm compression fitting (brass)
CE 1/4	- 1/8" / 1/4" / 1/2" - OD compression fitting (stainless steel)
CE 6	- 3/6/8/10/12mm compression fitting (stainless steel)
0	- 1/4"-NPT-F (port only)

port selection

PM51 - 2 - 300 - 10 - 1 - 2 - N2

Inlet pressure P₁

10	- max. 10 bar	100	- max. 100 bar
20	- max. 20 bar	200	- max. 200 bar
50	- max. 50 bar	300	- max. 300 bar

Outlet pressure P₂

1,5	- to 1,5 bar (P ₁ ≤ 50 bar)
4	- to 4 bar (P ₁ ≤ 50 bar)
10	- to 10 bar
20	- to 20 bar
50	- to 50 bar
100	- to 100 bar
200	- to 200 bar

Type of gas

Please specify type of gas
(for selection of valve seat materials)

Ordering example:
PM51-2-300-10-CE6-CE6-N2


Panel regulator PM51-4

spectro lab

Ordering information:
Panel regulator PM51-4

In- / outlets

CM 1/4	- 1/8" / 1/4" / 1/2" - OD compression fitting (brass)
CM 6	- 3 / 6 / 8 / 10 / 12 mm compression fitting (brass)
CE 1/4	- 1/8" / 1/4" / 1/2" - OD compression fitting (stainless steel)
CE 6	- 3 / 6 / 8 / 10 / 12 mm compression fitting (stainless steel)
B	- plug
A	- relief valve - 1/4"-NPT-F ($P_2 \leq 100$ bar)
K	- contact gauge
M	- pressure gauge
0	- 1/4"-NPT-F (port only)



PM51 - 4 - 300 - 10 - 1 - 2 - 3 - 4 - N2

Inlet

- L - left
- R - right

Inlet pressure P_1

10 - max. 10 bar	100 - max. 100 bar
20 - max. 20 bar	200 - max. 200 bar
50 - max. 50 bar	300 - max. 300 bar

Outlet pressure P_2


1,5 - to 1,5 bar ($P_1 \leq 50$ bar)
4 - to 4 bar ($P_1 \leq 50$ bar)
10 - to 10 bar
20 - to 20 bar
50 - to 50 bar
100 - to 100 bar
200 - to 200 bar

Type of gas

Please specify type of gas
(for selection of valve seat
materials)

Ordering example:

PM51-4-300-10-CE6-M-CE6-B-N2



PANELREGULATOR


PM51-6



Panel regulator PM51-6



Product features	
<ul style="list-style-type: none"> • Brass (chrome plated) panel pressure regulator for panel and panel surface mounting • For non-corrosive gases and gas mixtures up to quality 6.0 • 6 ports for flexible and individual configuration • Extremely stable outlet pressure • Suitable for inlet pressures up to 300 bar • Max. outlet pressures 1,5 up to 200 bar * • Metal-to-metal seal to atmosphere • Suitable for ECD-applications • Pressure regulator can be evacuated • Inlet filter • Approved for use with oxygen • Simple outlet pressure limitation by handwheel • Easy to install • New laboratory-style design • Ergonomically designed 	
* 1,5 / 4 bar only for inlet pressure ≤ 50 bar	
Technical data	
Type	single-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	1,5 / 4 bar ($P_1 \leq 50$ bar) 10 / 20 / 50 / 100 / 200 bar ($P_1 > 50$ bar)
Materials	
Body regulator, relief valve:	chrome plated brass
Valve seat:	PA
Diaphragm:	Hastelloy C276
Filter:	Sintered SS 316L
In- and outlets	1/4" NPT-F
Temperature range	-30°C to +60°C
Leak rate (to atmosphere) (via seat)	1x10 ⁻⁸ mbar l/s He 1x10 ⁻⁶ mbar l/s He
Pressure gauge	Safety pressure gauges ISO5171/C11.6/NG50
Flow capacity	$C_v=0.15$
Weight	1.1 kg




Panel regulator PM51-6

spectro lab

Ordering information:
Panel regulator PM51-6


In- / outlets

CM 1/4	- 1/8" / 1/4" / 1/2" - OD compression fitting (brass)
CM 6	- 3/6 / 8 / 10 / 12 mm compression fitting (brass)
CE 1/4	- 1/8" / 1/4" / 1/2" - OD compression fitting (stainless steel)
CE 6	- 3/6 / 8 / 10 / 12 mm compression fitting (stainless steel)
B	- plug
A	- relief valve - 1/4"-NPT-F ($P_2 \leq 100$ bar)
K	- contact gauge
M	- pressure gauge
0	- 1/4"-NPT-F (port only)



Inlet left: L

PM51 - 6 - L - 300 - 20 - 1 - 2 - 3 - 4 - 5 - 6 - N2



Inlet right: **R**

Inlet

L - left
R - right

Inlet pressure P_1

10	- max. 10 bar	100	- max. 100 bar
20	- max. 20 bar	200	- max. 200 bar
50	- max. 50 bar	300	- max. 300 bar

Outlet pressure P_2


- 1,5 - to 1,5 bar ($P_1 \leq 50$ bar)
- 4 - to 4 bar ($P_1 \leq 50$ bar)
- 10 - to 10 bar
- 20 - to 20 bar
- 50 - to 50 bar
- 100 - to 100 bar
- 200 - to 200 bar

Type of gas

Please specify type of gas
(for selection of valve seat
materials)

Ordering example:

PM51-6-L-20-10-CE6-M-M-CE6-B-0-N2



Ordering example:

Ordering example:
PM51-6-R-200-10-0-M-M-CE1/8-A-B-Ar



Panel regulator PM52^{exact}-2

spectro lab



Panel regulator PM52^{exact}-2



Example:
PM52^{exact}
panel mounted

Product features

- Brass (chrome plated) panel pressure regulator for panel and panel surface mounting
- Extremely stable outlet pressure by applied extremely accurate Technology "exact" and anti- vibration device
- For non-corrosive gases and gas mixtures up to quality 6.0
- 2 ports for flexible and individual configuration
- Suitable for inlet pressures up to 300 bar
- Max. outlet pressures 1.5 up to 20 bar
- Light weight
- Compact design
- Metal-to-metal seal to atmosphere
- Suitable for ECD-applications
- Pressure regulator can be evacuated
- Central filter
- Approved for use with oxygen
- Simple outlet pressure limitation by handwheel
- Easy to install
- New laboratory-style design
- Ergonomically designed


exact = extremely accurate technology

Technical data


Type	single-stage EXACT
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	1.5 / 4 / 10 / 20 bar
Materials	
Body regulator:	chrome plated brass
Valve seat:	PA
Diaphragm:	Hastelloy C276
Soft goods:	EPDM
Filter:	Sintered SS 316L
In- and outlets	1/4" NPT female
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
(via seat)	1x10 ⁻⁶ mbar l/s He
Flow capacity	$C_v=0.16$
Weight	1.0 kg

Dimensions
PM52^{exact}-2


Side view



Bore template
for panel
mounting




Fixing holes
for panel surface
mounting



Panel regulator PM52^{exact}-2

Ordering information:

Panel regulator PM52^{exact}-2



For inlet pressure up to 50 bar and outlet pressure of max. 1,5 or 4 bar please use M51

Ordering example:

PM52-2-300-10-CE6-N2



Specifications

- SPECTROLAB-components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All parts in the gas wetted surface area are cleaned in an ultrasonic cleaning system (CFC-free) with the special Cleaning process SPECTRO-CLEAN® and then baked out.
- SPECTROLAB-components undergo a 100% function- and Helium-leak-test.

Panel regulator PM52^{exact}-4

spectro lab



Panel regulator
PM52^{exact}-4



Example:
PM52^{exact}
panel mounted

Product features

- Brass (chrome plated) panel pressure regulator for panel and panel surface mounting
- Extremely stable outlet pressure by applied extremely accurate Technology "exact" and anti-vibration device
- For non-corrosive gases and gas mixtures up to quality 6.0
- 4 ports for flexible and individual configuration
- Suitable for inlet pressures up to 300 bar
- Max. outlet pressures 1.5 up to 20 bar
- Light weight
- Compact design
- Metal-to-metal seal to atmosphere
- Suitable for ECD-applications
- Pressure regulator can be evacuated
- Central filter
- Approved for use with oxygen
- Simple outlet pressure limitation by handwheel
- Easy to install
- New laboratory-style design
- Ergonomically designed


exact = extremely accurate technology

Technical data

Type	single-stage EXACT
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	1.5 / 4 / 10 / 20 bar
Materials	
Body regulator, relief valve:	chrome plated brass
Valve seat:	PA
Diaphragm:	Hastelloy C276
Soft goods:	EPDM
Filter:	Sintered SS 316L
In- and outlets	1/4" NPT female
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
(via seat)	1x10 ⁻⁸ mbar l/s He
Pressure gauge	Safety pressure gauges ISO5171/K11.6/NG50
Flow capacity	$C_v=0.16$
Weight	1.0 kg

Dimensions
PM52^{exact}-4

Side view



Panel regulator PM52^{exact}-4


spectro lab

Ordering information:

Panel regulator PM52^{exact}-4

In- / outlets

CM 1/4	- 1/8" / 1/4" / 1/2" - OD compression fitting (brass)
CM 6	- 3 / 6 / 8 / 10 / 12 mm compression fitting (brass)
CE 1/4	- 1/8" / 1/4" / 1/2" - OD compression fitting (stainless steel)
CE 6	- 3 / 6 / 8 / 10 / 12 mm compression fitting (stainless steel)
B	- plug
A	- relief valve - 1/4"-NPT-F
K	- contact gauge
M	- pressure gauge
0	- 1/4"-NPT-F (port only)



port selection

PM52 - 4 - 300 - 10 - 1 - 2 - 3 - 4 - N2

Inlet pressure P₁

100	- max. 100 bar
200	- max. 200 bar
300	- max. 300 bar

Outlet pressure P₂

1,5	- to 1.5 bar
4	- to 4 bar
10	- to 10 bar
20	- to 20 bar


Type of gas

Please specify type of gas
(for selection of valve seat
materials)

For inlet pressure up to 50 bar and outlet pressure of max. 1,5 or 4 bar please use M51

Ordering example:

PM52-4-300-10-CE6-M-CE6-B-N2



Specifications

- SPECTROLAB-components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All parts in the gas wetted surface area are cleaned in an ultrasonic cleaning system (CFC-free) with the special Cleaning process SPECTRO-CLEAN® and then baked out.
- SPECTROLAB-components undergo a 100% function- and Helium-leak-test.

Panel regulator PM52^{exact}-6

spectro lab



Panel regulator
PM52^{exact}-6



Example:
PM52^{exact}
panel mounted

Product features


- Brass (chrome plated) panel pressure regulator for panel and panel surface mounting
- Extremely stable outlet pressure by applied extremely accurate Technology "exact" and anti- vibration device
- For non-corrosive gases and gas mixtures up to quality 6.0
- 6 ports for flexible and individual configuration
- Suitable for inlet pressures up to 300 bar
- Max. outlet pressures 1.5 up to 20 bar
- Light weight
- Compact design
- Metal-to-metal seal to atmosphere
- Suitable for ECD-applications
- Pressure regulator can be evacuated
- Central filter
- Approved for use with oxygen
- Simple outlet pressure limitation by handwheel
- Easy to install
- New laboratory-style design
- Ergonomically designed

exact = extremely accurate technology

Technical data

Type	single-stage EXACT
Inlet pressure P₁	max. 300 bar
Outlet pressure P₂	1.5 / 4 / 10 / 20 bar
Materials	
Body regulator, relief valve: chrome plated brass	
Valve seat:	PA
Diaphragm:	Hastelloy C276
Soft goods:	EPDM
Filter:	Sintered SS 316L
In- and outlets	1/4" NPT female
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
(via seat)	1x10 ⁻⁶ mbar l/s He
Pressure gauge	Safety pressure gauges ISO5171/KI1.6/NG50
Flow capacity	C _v =0.16
Weight	1.1 kg

Dimensions
PM52^{exact}-6




Panel regulator PM52^{exact}-6

spectro lab

Ordering information:


Panel regulator PM52^{exact}-6



For inlet pressure up to 50 bar and outlet pressure of max. 1,5 or 4 bar please use M51

Ordering example:

PM52-6-L-20-10-CE6-M-M-CE6-A-B-N2



Ordering example:

PM52-6-R-200-10-0-M-M-CE1/8-A-B-Ar



PANELREGULATOR

PM53-2




Panel pressure regulator PM53-2

spectro lab



Product features		Technical data	
<ul style="list-style-type: none"> • 2-stage diaphragm panel pressure regulator with extremely stable outlet pressure and anti-vibration device • For non-corrosive gases and gas mixtures up to quality 6.0 • 2 ports for flexible and individual configuration • New laboratory-style design • Central filter • Suitable for ECD-applications • Pressure regulator can be evacuated • Suitable for inlet pressures up to 300 bar • Max. outlet pressures 1.5 up to 20 bar • Light weight • Compact design • Approved for use with oxygen • Simple outlet pressure limitation by handwheel • Easy to install 		Type	double-stage
		Inlet pressure P_1	max. 300 bar
		Outlet pressure P_2	1.5 / 4 / 10 / 20 bar
		Materials	
		Body regulator, relief valve: chrome plated brass	
		Valve seat:	PA
		Diaphragm:	Hastelloy C276
		Soft goods:	EPDM
		Filter:	Sintered bronze
		In- and outlets	1/4" NPT-F
		Temperature range	-30°C to +60°C
		Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
		(via seat)	1x10 ⁻⁶ mbar l/s He
		Weight	1.6 kg





PANELREGULATOR

PM53-2



Panel pressure regulator PM53-2

spectro lab




PANELREGULATOR


PM53-6



Panel pressure regulator PM53-6




Product features		Technical data	
<ul style="list-style-type: none"> • 2-stage diaphragm panel pressure regulator with extremely stable outlet pressure and anti-vibration device • For non-corrosive gases and gas mixtures up to quality 6.0 • 6 ports for flexible and individual configuration • New laboratory-style design • Central filter • Suitable for ECD-applications • Pressure regulator can be evacuated • Suitable for inlet pressures up to 300 bar • Max. outlet pressures 1.5 up to 20 bar • Light weight • Compact design • Approved for use with oxygen • Simple outlet pressure limitation by handwheel • Easy to install 		Type	double-stage
		Inlet pressure P_1	max. 300 bar
		Outlet pressure P_2	1.5 / 4 / 10 / 20 bar
		Materials	
		Body regulator, relief valve: chrome plated brass Valve seat: PA Diaphragm: Hastelloy C276 Soft goods: EPDM Filter: Sintered bronze	
		In- and outlets	1/4" NPT-F
		Temperature range	-30°C to +60°C
		Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
		(via seat)	1x10 ⁻⁶ mbar l/s He
		Pressure gauge	Safety pressure gauges ISO5171/KI1.6/NG50
		Weight	1.7 kg




Panel pressure regulator PM53-6


Dimensions



Ordering information:
Panel pressure regulator PM53



For inlet pressure up to 50 bar and outlet pressure of max. 1,5 or 4 bar please use M51




p1: 300 bar
p2: 10 bar
S-Nr.: 71115
Typ: BM 2

Pressure control panel BM55-1

spectro lab



Pressure control panel BM55-1
with valve in the outlet adapter




Product features

- Wall- and cabinet-mounting pressure control panels
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Ergonomically designed
- Modular design (to be extended to 2, 3 etc. cylinders)
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Suitable for ECD-applications
- Diaphragm-type pressure regulator with high control accuracy and anti-vibration device
- Outlet adapter with integrated relief valve and optional diaphragm-shut-off valve (this prevents the outlet piping from draining during disconnecting the panel)
- Designed for easy installation
- Approved for use with oxygen
- Suitable for inlet pressure values up to 300 bar
- Compact design especially for installation into safety cabinets for gas cylinders
- Dual-stage model: BM56-1

Technical data


Type	single-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	10/20/50/100/200 bar
Materials	
Body regulator and valves:	chrome-plated brass
Valve seat regulator:	PA 11
Valve seat valves:	PVDF
Diaphragm regulator:	Hastelloy C276
Diaphragm valve:	Hastelloy C276
Soft goods:	EPDM, FKM
Filter:	Sintered SS 316L
Inlet connector	SS compression ring fitting 6x1 mm
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
(via seat)	1x10 ⁻⁶ mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/cl 1.6/NG50
Weight	4,5 kg

Flow curves BM55-1



Pressure control panel BM55-1

spectro lab



Process gas valve also with 300 bar - pneumatic-actuator upon request!

Ordering information:
Pressure control panels BM55-1

BM55 - 1 - 300 - 10 - M - M - V - N₂

Inlet pressure P₁

100 - max. 100 bar
200 - max. 200 bar
300 - max. 300 bar

Outlet pressure P₂

10 - max. 10 bar
20 - max. 20 bar
50 - max. 50 bar
100 - max. 100 bar
200 - max. 200 bar

Inlet press. indication

M - pressure gauge
K - contact pressure gauge

Gas type

Please specify gas type with your order (selection of valve seat material)

Outlet adapter

0 - without valve
V - valve (manual)
VP - pneumatic-valve

Outlet press. indication

M - pressure gauge
K - contact pressure gauge

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% Helium-leak-test.

Pressure indication

- All pressure regulators can be equipped with pressure gauges or contact gauges for in- and outlet pressure indication.

Important note regarding component selection


- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control panel.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Pressure control panel BM55-2

spectro lab



Pressure control panel BM55-2
Outlet adapter without valve




Product features

- Wall- and cabinet-mounting pressure control panels
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Ergonomically designed
- Modular design (to be extended to 2, 3 etc. cylinders)
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Suitable for ECD-applications
- Diaphragm-type pressure regulator with high control accuracy and anti-vibration device
- Outlet adapter with integrated relief valve and optional diaphragm-shut-off valve (this prevents the outlet piping from draining during disconnecting the panel)
- Designed for easy installation
- Approved for use with oxygen
- Suitable for inlet pressure values up to 300 bar
- Compact design especially for installation into safety cabinets for gas cylinders
- Double-stage model: BM56-2

Technical data


Type	single-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	10/20/50/100/200 bar
Materials	
Body regulator and valves:	chrome-plated brass
Valve seat regulator:	PA 11
Valve seat valves:	PVDF
Diaphragm regulator:	Hastelloy C276
Diaphragm valve:	Hastelloy C276
Soft goods:	EPDM, FKM
Filter:	Sintered SS 316L
Inlet connector	SS compression ring fitting 6x1 mm
Temperature range	-30°C to +60°C
Leak rate (to atmosphere) (via seat)	1×10^{-8} mbar l/s He 1×10^{-6} mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/cl 1.6/NG50
Weight	6 kg

Flow curves BM55-2



Pressure control panel BM55-2

spectro lab



Process gas valve
also with 300 bar -
pneumatic-actuator
upon request!

Ordering information:
Pressure control panels BM55-2

BM55 - 2 - 300 - 10 - M - M - V - N₂

Inlet pressure P₁

100 - max. 100 bar
200 - max. 200 bar
300 - max. 300 bar

Outlet pressure P₂

10 - max. 10 bar
20 - max. 20 bar
50 - max. 50 bar
100 - max. 100 bar
200 - max. 200 bar

Inlet press. indication

M - pressure gauge
K - contact pressure gauge

Gas type

Please specify gas type with
your order (selection of valve
seat material)

Outlet adapter

0 - without valve
V - valve (manual)
VP - pneumatic-valve

Outlet press. indication

M - pressure gauge
K - contact pressure gauge

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% Helium-leak-test.

Pressure indication

- All pressure regulators can be equipped with pressure gauges or contact gauges for in- and outlet pressure indication.

Important note regarding component selection


- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control panel.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Pressure control panel BM56-1

spectro lab



Pressure control panel BM56-1
with valve in the outlet adapter




Product features

- Double-stage wall- and cabinet-mounting pressure control panels
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Modular design (to be extended to 2, 3 etc. cylinders)
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Suitable for ECD-applications
- Double-stage diaphragm-type pressure regulator with high control accuracy and anti-vibration device
- Outlet adapter with integrated relief valve and optional diaphragm-shut-off valve (this prevents the outlet piping from draining during disconnecting the panel)
- Designed for easy installation
- Approved for use with oxygen
- Suitable for inlet pressure values up to 300 bar
- Compact design especially for installation into safety cabinets for gas cylinders
- Single-stage model: BM55-1

Technical data


Type	double-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	1,5 / 4 / 10 bar
Materials	
Body regulator and valves:	chrome-plated brass
Valve seat regulator:	PA
Valve seat valves:	PVDF
Diaphragm regulator:	Hastelloy C276
Diaphragm valve:	Hastelloy C276
Soft goods:	EPDM, FKM
Filter:	Sintered bronze B60
Inlet connector	SS compression ring fitting 6x1 mm
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
(via seat)	1x10 ⁻⁶ mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/cl 1.6/NG50
Weight	4,9 kg

Flow curves BM56-1



Pressure control panel BM56-1

spectro lab



Process gas valve
also with 300 bar -
pneumatic-actuator
upon request!

Ordering information:
Pressure control panels BM56-1

BM56 - 1 - 300 - 1,5 - M - M - V - N₂

Inlet pressure P₁

100 - max. 100 bar
200 - max. 200 bar
300 - max. 300 bar

Outlet pressure P₂

1,5 - max. 1,5 bar
4 - max. 4 bar
10 - max. 10 bar

Inlet press. indication

M - pressure gauge
K - contact pressure gauge

Gas type

Please specify gas type with
your order (selection of valve
seat material)

Outlet adapter

0 - without valve
V - valve (manual)
VP - pneumatic-valve

Outlet press. indication

M - pressure gauge
K - contact pressure gauge

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% Helium-leak-test.

Pressure indication

- All pressure regulators can be equipped with pressure gauges or contact gauges for in- and outlet pressure indication.

Important note regarding component selection


- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control panel.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Pressure control panel BM56-2

spectro lab



Pressure control panel BM56-2
Outlet adapter without valve




Product features

- Double-stage wall- and cabinet-mounting pressure control panels
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Modular design (to be extended to 2, 3 etc. cylinders)
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Suitable for ECD-applications
- Double-stage diaphragm-type pressure regulator with high control accuracy and anti-vibration device
- Outlet adapter with integrated relief valve and optional diaphragm-shut-off valve (this prevents the outlet piping from draining during disconnecting the panel)
- Designed for easy installation
- Approved for use with oxygen
- Suitable for inlet pressure values up to 300 bar
- Compact design especially for installation into safety cabinets for gas cylinders
- Single-stage model: BM55-2

Technical data


Type	double-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	1,5 / 4 / 10 bar
Materials	
Body regulator and valves:	chrome-plated brass
Valve seat regulator:	PA
Valve seat valves:	PVDF
Diaphragm regulator:	Hastelloy C276
Diaphragm valve:	Hastelloy C276
Soft goods:	EPDM, FKM
Filter:	Sintered bronze B60
Inlet connector	SS compression ring fitting 6x1 mm
Temperature range	-30°C to +60°C
Leak rate (to atmosphere) (via seat)	1×10^{-8} mbar l/s He 1×10^{-6} mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/cl 1.6/NG50
Weight	6,5 kg

Flow curves BM56-2



Pressure control panel BM56-2

spectro lab



Process gas valve
also with 300 bar -
pneumatic-actuator
upon request!

Ordering information:
Pressure control panels BM56-2

BM56 - 2 - 300 - 1,5 - M - M - V - N₂

Inlet pressure P₁

100 - max. 100 bar
200 - max. 200 bar
300 - max. 300 bar

Outlet pressure P₂

1,5 - max. 1,5 bar
4 - max. 4 bar
10 - max. 10 bar

Inlet press. indication

M - pressure gauge
K - contact pressure gauge

Gas type

Please specify gas type with
your order (selection of valve
seat material)

Outlet adapter

0 - without valve
V - valve (manual)
VP - pneumatic-valve

Outlet press. indication

M - pressure gauge
K - contact pressure gauge

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% Helium-leak-test.

Pressure indication


- All pressure regulators can be equipped with pressure gauges or contact gauges for in- and outlet pressure indication.

Important note regarding component selection

- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control panel.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Pressure control panel BM55-2U

spectro lab



Process gas valve also with 300 bar - pneumatic-actuator upon request!

Ordering information:
Pressure control panels BM55-2U

BM55 - 2U - 300 - 10 - M - M - V - N₂

Inlet pressure P₁

100 - max. 100 bar
200 - max. 200 bar
300 - max. 300 bar

Outlet pressure P₂

10 - max. 10 bar (middle position = 10 bar; P_{2 max / min} = ± 1,5 bar)
20 - max. 20 bar (middle position = 20 bar; P_{2 max / min} = ± 1,5 bar)
50 - max. 50 bar (middle position = 50 bar; P_{2 max / min} = ± 5 bar)
100 - max. 100 bar (middle position = 100 bar; P_{2 max / min} = ± 10 bar)
200 - max. 200 bar (middle position = 200 bar; P_{2 max / min} = ± 10 bar)

Inlet press. indication

M - pressure gauge
K - contact pressure gauge

Gas type

Please specify gas type with your order (selection of valve seat material)

Outlet adapter

0 - without valve
V - valve (manual)
VP - pneumatic-valve

Outlet press. indication

M - pressure gauge
K - contact pressure gauge

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% Helium-leak-test.

Pressure indication

- All pressure regulators can be equipped with pressure gauges or contact gauges for in- and outlet pressure indication.

Important note regarding component selection


- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control panel.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Pressure control panel BM55-2U

spectro lab



Pressure control panel BM55-2U
Outlet adapter without valve




Product features

- Wall- and cabinet-mounting pressure control panels with automatic change-over function
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Ergonomically designed
- Modular design (to be extended to 2, 3 etc. cylinders)
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Suitable for ECD-applications
- Diaphragm-type pressure regulator with high control accuracy and anti-vibration device
- Outlet adapter with integrated relief valve and optional diaphragm-shut-off valve (this prevents the outlet piping from draining during disconnecting the panel)
- Designed for easy installation
- Approved for use with oxygen
- Compact design especially for installation into safety cabinets for gas cylinders
- Minimised pressure difference between left and right hand side outlet pressure
- Double-stage model: BM56-2U

Technical data

Type	single-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	10/20/50/100/200 bar
Materials	
Body regulator and valves:	chrome-plated brass
Valve seat regulator:	PA 11
Valve seat valves:	PVDF
Diaphragm regulator:	Hastelloy C276
Diaphragm valve:	Hastelloy C276
Soft goods:	EPDM, FKM
Filter:	Sintered SS 316L
Inlet connector	SS compression ring fitting 6x1 mm
Temperature range	-30°C to +60°C
Leak rate (to atmosphere) (via seat)	1×10^{-8} mbar l/s He 1×10^{-6} mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/cl 1.6/NG50
Weight	7,7 kg

Flow curves BM55-2U




Pressure control panel BM56-2U

spectro lab



Pressure control panel BM56-2U




Product features

- Double-stage wall- and cabinet-mounting pressure control panels with automatic change-over function
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Ergonomically designed
- Modular design (to be extended to 2, 3 etc. cylinders)
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Suitable for ECD-applications
- Double stage pressure control with 3 diaphragm-type pressure regulators with high control accuracy, anti-vibration device and integrated relief valve
- Designed for easy installation
- Approved for use with oxygen
- Compact design especially for installation into safety cabinets for gas cylinders
- Minimised pressure difference between left and right hand side outlet pressure
- Single-stage model: BM55-2U

Technical data


Type	double-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	1,5 / 4 / 10 bar
Materials	
Body regulator and valves:	chrome-plated brass
Valve seat regulator:	PA 11
Valve seat valves:	PVDF
Diaphragm regulator:	Hastelloy C276
Diaphragm valve:	Hastelloy C276
Soft goods:	EPDM, FKM
Filter:	Sintered bronze B60
Inlet connector	SS compression ring fitting 6x1 mm
Temperature range	-30°C to +60°C
Leak rate (to atmosphere) (via seat)	1x10 ⁻⁸ mbar l/s He 1x10 ⁻⁶ mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/cl 1.6/NG50
Weight	8,7 kg

Flow curves BM56-2U



Pressure control panel BM56-2U

spectro lab



Process gas valve
also with 300 bar -
pneumatic-actuator
upon request!

Ordering information:
Pressure control panels BM56-2U

BM56 - 2U - 300 - 1,5 - M - M - N₂

Inlet pressure P₁

100 - max. 100 bar
200 - max. 200 bar
300 - max. 300 bar

Outlet pressure P₂

1,5 - max. 1,5 bar
4 - max. 4 bar
10 - max. 10 bar

Inlet press. indication

M - pressure gauge
K - contact pressure gauge

Gas type

Please specify gas type with
your order (selection of valve
seat material)

Outlet press. indication

M - pressure gauge
K - contact pressure gauge

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% Helium-leak-test.

Pressure indication

- All pressure regulators can be equipped with pressure gauges or contact gauges for in- and outlet pressure indication.

Important note regarding component selection


- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control panel.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Pressure control panel BM55-2A

spectro lab



Pressure control panel BM55-2A
without outlet pressure connection




Product features

- Wall- and cabinet-mounting pressure control panels with fully automatic change-over function
- For non-corrosive gases up to quality 5.0
- No pressure difference between the two gas source sides due to Ambimat
- Maximum emptying of the gas cylinders
- Laboratory-style design
- Ergonomically designed
- Modular design (to be extended to 2, 3 etc. cylinders)
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Diaphragm-type pressure regulator with high control accuracy and anti-vibration device
- Designed for easy installation
- Approved for use with oxygen
- Suitable for inlet pressure values up to 300 bar
- Compact design especially for installation into safety cabinets for gas cylinders

Technical data

Type	single-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	max. 10 / 20 / 50 / 100 / 200 bar
Materials	
Body regulator and valves:	chrome-plated brass
Valve seat regulator:	PA 11
Valve seat valves:	PVDF
Diaphragm regulator:	Hastelloy C276
Diaphragm valve:	Hastelloy C276
Soft goods:	EPDM, FKM
Filter pressure regulator:	Sintered SS 316L
Filter Ambimat:	Sintered bronze
Inlet connector	SS compression ring fitting 6x1 mm
Temperature range	-15°C to +60°C
Leak rate (to atmosphere) (via seat)	1×10^{-8} mbar l/s He 1×10^{-6} mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/c1 1.6/NG50
Weight	ca. 10 kg

Flow curves BM55-2A



High pressure panel BM50-1+2

spectro lab



High pressure panel BM50-1




High pressure panel BM50-2

Product features

- Wall- and cabinet-mounting high pressure panels
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Ergonomically designed
- Modular design (to be extended to 2, 3 etc. cylinders)
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Pressure gauge (optional)
- Suitable for ECD-applications
- Designed for easy installation
- Approved for use with oxygen
- Suitable for inlet pressure values up to 300 bar
- Compact design


Technical data

Type	without regulator
Working pressure P	max. 300 bar
Materials	
Body:	chrome-plated brass
Valve seat valves:	PVDF
Diaphragm valve:	Hastelloy C276
Filter:	Sintered bronze
Inlet connector	SS compression ring fitting 6x1 mm
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
(via seat)	1x10 ⁻⁶ mbar l/s He
Weight	BM50-1: 3,3 kg
	BM50-2: 5,3 kg



Extensions BM55+56-E

spectro lab




Product features

- Extension modules for pressure control panels Spectrolab BM55 and BM56 series
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Designed for easy installation
- With filter at the inlet of the individual extension modules


Technical data

Inlet pressure P_1	max. 300 bar
Materials	
Manifold body:	chrome-plated brass
Filter:	Sintered SS 316L
Inlet connection	SS compression ring fitting 6x1 mm
Temperature range	-30°C to +60°C
Weight	approx. 1 kg per side

Extensions right and left for pressure control panels BM55 and BM56 with **connection block**:




Extensions right and left for pressure control panels BM55 and BM56 with **valve**:



Extensions BM55+56-E

spectro lab

Extension modules completely assembled
Example: pressure control panel BM55-2
with BM55-E-LH-CB and BM55-E-RH-CB



Ordering information:
Extensions BM55+56-E

BM55 - E - LH - CB

Type

55 - single-stage pressure control panel BM55 or BM56-2U
56 - double-stage pressure control panel BM56-1 and BM56-2

Side

RH - right
LH - left

Inlet

CB - connection block
V - valve (manual)
VP - pneumatic-valve

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% Helium-leak-test.

Important note regarding component selection


- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting system components.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Pressure control panel BM65-1

spectro lab



Pressure control panel BM65-1
with outlet connection




Product features

- Wall- and cabinet-mounting pressure control panels
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Ergonomically designed
- Modular design (to be extended to 2, 3 etc. cylinders)
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Suitable for ECD-applications
- Regulator with high control accuracy and integrated relief valve
- Designed for easy installation
- Tested for use with oxygen
- Suitable for inlet pressure values up to 300 bar
- Compact design especially for installation into safety cabinets for gas cylinders
- Models for outlet pressure values of up to 50 and 100 bar available (piston type regulators)
- For dual-stage models see data sheet BM66-1

Technical data

Type	single-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	10 / 20 / 50 / 100 bar
Materials	
Body regulator and valves:	chrome-plated brass
Valve seat regulator:	PA 11
Valve seat shut-off valve:	PVDF
Diaphragm regulator:	SS 301 (SS 1.4310)
Diaphragm valve:	Hastelloy C276
Piston ($P_2 = 50 / 100$ bar):	brass
Soft goods:	Viton (FKM)
Filter:	Sintered SS 316L
Inlet connector	SS compression ring fitting 6x1 mm
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
(via seat)	1x10 ⁻⁶ mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/cl 1.6/NG50
Weight	4 kg

Flow curves BM65




BM65
Inlet pressure
 $P_1 = 21$ bar

Flow rate
 $Q [m^3/h \text{ air}]$

Pressure control panel BM65-1

spectro lab



Ordering information: Pressure control panels BM65-1

BM65 - 1 - 300 - 10 - M - M - N₂

Type

65 - single-stage control panel
66 - dual-stage control panel

Inlet pressure P_1

300 - max. 300 bar

Outlet pressure P_2

4 - up to 4 bar (dual-stage)
10 - up to 10 bar
20 - up to 20 bar
50 - up to 50 bar (piston type pressure regulator)
100 - up to 100 bar (piston type pressure regulator)

Gas type

Please specify gas type with your order (selection of valve seat material)

Outlet press. indication

M - pressure gauge
K - contact pressure gauge

Inlet press. indication

M - pressure gauge
K - contact pressure gauge

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% Helium-leak-test.

Pressure indication

- All pressure regulators can be equipped with pressure gauges or contact gauges for in- and outlet pressure indication.

Important note regarding component selection


- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control panel.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Pressure control panel BM66-1

spectro lab



Pressure control panel BM66-1




Product features

- Double stage wall- and cabinet-mounting pressure control panels
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Ergonomically designed
- Modular design (to be extended to 2x2, 2x3 etc. cylinders)
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Suitable for ECD-applications
- 2 pressure regulators with very high control accuracy and integrated relief valve
- Designed for easy installation
- Tested for use with oxygen
- Suitable for inlet pressure values up to 300 bar
- Compact design especially for installation into safety cabinets for gas cylinders

Technical data

Type:	double-stage
Inlet pressure P_1:	max. 300 bar
Outlet pressure P_2:	1.5 / 4 / 10 bar
Materials:	
Body regulator and valves:	chrome-plated brass
Valve seat regulator:	PA 11
Valve seat valves:	PVDF
Diaphragm regulator:	SS 301 (SS 1.4310)
Diaphragm valve:	Hastelloy C276
Soft goods:	Viton (FKM)
Filter:	sintered SS 316L
Inlet connector:	SS compression fitting 6x1 mm
Temperature range:	-30°C to +60°C
Leak rate: (to atmosphere)	1×10^{-8} mbar l/s He
(via seat)	1×10^{-6} mbar l/s He
Pressure gauge:	Safety pressure gauges ISO5171/KI1.6/NG50
Weight:	approx. 6 kg

Flow curves BM66




BM66
Inlet pressure
 $P_1 = 21$ bar

Flow rate
 Q in m^3/h Luft

Pressure control panel BM66-1

spectro lab



Ordering information:
Pressure control panels BM66-1

BM - 66 - 1 - 300 - 10 - M - M - O - N₂

Please specify gas type with your order (valve seat material)

Inlet pressure P₁

300 - max. 300 bar

Outlet pressure P₂

1,5 - max. 1,5 bar

4 - max. 4 bar

10 - max. 10 bar

Vordruckanzeige

M - pressure gauge

K - contact gauge

Gas type

Please specify gas type with your order (selection of valve seat material)

Outlet

O - top

U - bottom

Outlet press. indication

M - pressure gauge

K - contact gauge

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% function- and Helium-leak-test.

Pressure indication

- All pressure regulators can be equipped with pressure gauges or contact gauges for in- and outlet pressure indication.

Important note regarding component selection


- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control panel.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Pressure control panel BM65-2

spectro lab



Pressure control panel BM65-2
with outlet fitting




Product features

- Wall- and cabinet-mounting pressure control panels
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Ergonomically designed
- Modular design (to be extended to 2x2, 2x3 etc. cylinders)
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Suitable for ECD-applications
- Regulator with high control accuracy and integrated relief valve
- Designed for easy installation
- Tested for use with oxygen
- Suitable for inlet pressure values up to 300 bar
- Compact design especially for installation into safety cabinets for gas cylinders
- Models for outlet pressure values of up to 50 and 100 bar available (piston type regulators)
- Dual-stage models: see BM66-2

Technical data

Type	single-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	10/20/50/100 bar
Materials	
Body regulator and valves:	chrome-plated brass
Valve seat regulator:	PA 11
Valve seat shut-off valve:	PVDF
Diaphragm regulator:	SS 301 (SS 1.4310)
Diaphragm valve:	Hastelloy C276
Piston ($P_2=50/100\text{bar}$):	brass
Soft goods:	Viton (FKM)
Filter:	Sintered SS 316L
Inlet connector	SS compression ring fitting 6x1 mm
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1×10^{-8} mbar l/s He
(via seat)	1×10^{-6} mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/cl 1.6/NG50
Weight	6 kg


Flow curves BM65



BM65
Inlet pressure
 $P_1 = 21 \text{ bar}$

Flow rate
 $Q [\text{m}^3/\text{h air}]$

Pressure control panel BM65-2



Additional configurations upon request!

Ordering information:
Pressure control panels BM65-2

BM - 65 - 2 - 300 - 10 - M - M - N₂

Please specify gas type with your order

Type

65 - single-stage control panel
66 - dual-stage control panel

Inlet pressure P₁

300 - max. 300 bar

Outlet pressure P₂

4 - up to 4 bar (dual-stage)
10 - up to 10 bar
20 - up to 20 bar
50 - up to 50 bar (piston type regulator)
100 - up to 100 bar (piston type regulator)

Gas type

Please specify gas type with your order (selection of valve seat material)

Outlet press.

M - pressure gauge
K - Contact gauge

Inlet press. indication

M - pressure gauge
K - Contact gauge

- Specifications**

 - SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
 - All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
 - SPECTROLAB - components undergo a 100% Helium-leak-test.
- Pressure indication**

 - All pressure regulators can be equipped with pressure gauges or contact gauges for in- and outlet pressure indication.

Important note regarding component selection


 - In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control panel.
 - The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Pressure control panel BM65-2U

spectro lab



Pressure control panel BM65-2U
with outlet connection




Product features

- Wall- and cabinet-mounting pressure control panels with automatic change-over function
- For non-corrosive gases up to quality 6.0
- Simple outlet pressure adjustment
- Minimised pressure difference between left and right hand side outlet pressure
- Laboratory-style design
- Ergonomically designed
- Modular design (to be extended to 2x2, 2x3 etc. cylinders)
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Suitable for ECD-applications
- Regulator with high control accuracy and integrated relief valve
- Designed for easy installation
- Tested for use with oxygen
- Suitable for inlet pressure values up to 300 bar
- Compact design especially for installation into safety cabinets for gas cylinders

Technical data

Type	single-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2	max. 12 bar
Materials	
Body regulator and valves:	chrome-plated brass
Valve seat regulator:	PA 11
Valve seat shut-off valve:	PVDF
Diaphragm regulator:	SS 301 (SS 1.4310)
Diaphragm valve:	Hastelloy C276
Soft goods:	Viton (FKM)
Filter:	Sintered SS 316L
Inlet connector	SS compression ring fitting 6x1 mm
Temperature range	-30°C to +60°C
Leak rate (to atmosphere) (via seat)	1x10 ⁻⁸ mbar l/s He 1x10 ⁻⁶ mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/cl 1.6/NG50
Weight	8 kg

Flow curves BM65




BM65
Inlet pressure
 $P_1 = 21$ bar

Flow rate
 Q [m³/h air]

Pressure control panel BM65-2U

Dimensions pressure control panel BM65-2U



Additional configurations upon request!

Ordering information:
Pressure control panels BM 65-2U

BM65 - 2U - 300 - 10 - M - M - N₂

Type

65 - single-stage control panel

Inlet pressure P₁

50 - max. 50 bar
100 - max. 100 bar
300 - max. 300 bar

Outlet pressure P₂

10 - P_{2,max}: up to 10 bar (P_{2,min} = P_{2,max} - 2.5 ... 3 bar)

Gas type

Please specify gas type with your order (selection of valve seat material)

Outlet press. indication

M - pressure gauge
K - contact pressure gauge

Inlet press. indication

M - pressure gauge
K - contact pressure gauge

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% function- and Helium-leak-test.

Pressure indication

- All pressure regulators can be equipped with pressure gauges or contact gauges for in- and outlet pressure indication.

Important note regarding component selection


- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control panel.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Pressure control panel BM65-2L

spectro lab



Pressure control panel BM65-2L
with outlet connection




Product features

- Wall- and cabinet-mounting pressure control panels with automatic switch-over function
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Ergonomically designed
- Modular design (to be extended to 2x2, 2x3 etc. cylinders)
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Suitable for ECD-applications
- Regulator with high control accuracy
- Relief valve (adjustable version for $P_2 = 100$ bar)
- Designed for easy installation
- Tested for use with oxygen
- Suitable for inlet pressure values up to 300 bar
- Compact design especially for installation into safety cabinets for gas cylinders
- Models for outlet pressure values of up to 50 and 100 bar available (piston type regulators)
- Dual-stage models available upon request

Technical data

Type	single-stage
Inlet pressure P_1	max. 300 bar
Outlet pressure P_2 :	20/50/100 bar
Materials	
Body regulator and valves:	chrome-plated brass
Valve seat regulator:	PA 11
Valve seat shut-off valve:	PVDF
Diaphragm regulator:	SS 301 (SS 1.4310)
Diaphragm valve:	Hastelloy C276
Piston ($P_2=50/100$ bar):	brass
Soft goods:	Viton (FKM)
Filter:	Sintered SS 316L
Inlet connector	SS compression ring fitting 6x1 mm
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1×10^{-8} mbar l/s He
(via seat)	1×10^{-6} mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/cl 1.6/NG50
Weight	8 kg

Flow curves BM65





Inlet pressure
 $P_1 = 21$ bar

Flow rate
 $Q [m^3/h \text{ air}]$

Pressure control panel BM65-2L

spectro lab

Pressure control panel BM65-2L - Dimensions



Additional configurations upon request!

Ordering information:
Pressure control panels BM65-2L

BM - 65 - 2L - 300 - 20 - M - M - N₂

Please specify gas type with your order

Type

- 65 - single-stage control panel
- 66 - dual-stage control panel (upon request)

Inlet pressure P₁

300 - max. 300 bar

Outlet pressure P₂

- 20 - up to 20 bar
- 50 - up to 50 bar (piston type regulator)
- 100 - up to 100 bar (piston type regulator)

Gas type

Please specify gas type with your order (selection of valve seat material)

Outlet press.

- M - pressure gauge
- K - Contact gauge

Inlet press. indication

- M - pressure gauge
- K - Contact gauge

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% function- and Helium-leak-test.

Pressure indication


- All pressure regulators can be equipped with pressure gauges or contact gauges for in- and outlet pressure indication.

Important note regarding component selection


- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control panel.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Extensions BM 65-E

spectro lab




Product features		Technical data	
<ul style="list-style-type: none">• Extension modules for all Spectrolab BM 65 and 66 series pressure control panels• For non-corrosive gases up to quality 6.0• Laboratory-style design• Designed for easy installation• With filter at the inlet of the individual extension modules		Inlet pressure P_1	max. 300 bar
		Materials	
		Manifold body:	chrome-plated brass
		Filter:	Sintered SS 316L
		O-ring (for M12 connection):	FKM
		Inlet connection	SS compression ring fitting 6x1 mm
		Temperature range	-30°C to +60°C
		Weight	approx. 1 kg per side



Extensions BM 65-E



Extension modules completely assembled
(example: pressure control panel BM 65-2)



**Additional
configurations
upon request!**

Ordering information:
Extensions BM 65-E

BM 65 - E - 2 x 2

Type

- 1 x 2** - Extensions for panels BM 65/66-1 to 2 cylinders
- 1 x 3** - Extensions for panels BM 65/66-1 from 1 x 2 to 1 x 3 cylinders
- 1 x 4** - Extensions for panels BM 65/66-1 from 1 x 2 to 1 x 4 cylinders
- 2 x 2** - Extensions for panels BM 65/66-2 ... to 2 x 2 cylinders
- 2 x 3** - Extensions for panels BM 65/66-2 ... from 2 x 2 to 2 x 3 cylinders
- 2 x 4** - Extensions for panels BM 65/66-2 ... from 2 x 2 to 2 x 4 cylinders

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% Helium-leak-test.

Important note regarding component selection


- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting system components.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Pressure control panels BM65-AC

spectro lab



Pressure control panel BM65-1-M-KH-C2H2



Pressure control panel BM65-2-M-KH-C2H2

Product features

- Wall-mounting pressure control panels for acetylene
- Single-stage systems for 1 or 2 cylinders
- Laboratory-style design
- Ergonomically designed
- Pressure regulator with high control accuracy and integrated relief valve for protection of the device
- Quick-acting shut-off valve (manual)
- optionally: automatic quick-acting shut-off device
- optionally: Acetylene Safety Guard (ASG)
For further information please see data sheet ASG
- Flashback arrestor
- Over-pressure valve *
- Designed for easy installation
- Suitable for inlet pressure values up to 25 bar
- Compact design especially for installation into safety cabinets for gas cylinders
- Pressure control panels comply with DIN-EN-ISO 14114 and DIN-EN-ISO 15615

Technical data

Type	single-stage
Inlet pressure P_1	max. 25 bar
Outlet pressure P_2	1,5 bar
Materials	
Body regulator	
and connection blocks:	brass
Valve cone regulator:	PA
Diaphragm regulator:	EPDM
Ball valve:	steel, zinc-plated
Connectors	
Inlet	M 16 x 1,5 male
Outlet flashback arrestor	1/4"-NPT female
Outlet relief valve	1/8"-NPT female
Outlet over-pressure valve	welding stub 14 x 2
Temperature range	-30°C to +60°C
Leak rate	1x10 ⁻⁴ mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/KI2.5/NG63
Weight	BM65-1-AC: ca. 6 kg
	BM65-2-AC: ca. 7 kg

* An over-pressure valve cannot be used as an safety accessory according to the Pressure Equipment Directive (PED).


Flow rates BM65-AC:

The maximum flow rate is approx. 8 sm³/h acetylene.
At an inlet pressure of approx. 4 bar (resembling an acetylene cylinder almost empty) the pressure regulator still yields approx. 5 sm³/h acetylene.

Inlet press. P_1 [bar]	Outlet press. P_2 [bar]		
	0,5	1	1,2
18	5,0 m ³ /h	6,0 m ³ /h	8,0 m ³ /h
10	4,5 m ³ /h	5,5 m ³ /h	6,5 m ³ /h
4	3,0 m ³ /h	4,0 m ³ /h	5,0 m ³ /h
2	1,5 m ³ /h	2,0 m ³ /h	3,0 m ³ /h

The withdrawal rate should not exceed approx. 0,5 sm³/h per cylinder in permanent operation, so no solvent from the cylinder will enter the withdrawal system. However, the flow rate may be increased to approx. 1 sm³/h for brief peak loads.

Pressure control panels BM65-AC spectro lab



Ordering information:
Pressure control panels BM65-AC

BM65 - 1 - M - KH - C₂H₂

Type

- 1 - panel for 1 cylinder
- 2 - panel for 2 cylinders

Outlet press. indication

- M - Pressure gauge
- K - Contact pressure gauge

Quick-acting shut-off

- KH - manual quick-acting shut-off device (ball valve)
- SSE - automatic quick-acting shut-off device SSE
- ASG - Acetylene Safety Guard

Pressure control panel BM65-2A-AC



Pressure control panel BM65-2A-K-KH-SV-V for Acetylene with manual quick acting shut-off valve (ball valve), over-pressure valve SV73 and individual ball valves for each cylinder

Product features

- Wall mounting pressure control panel for acetylene with fully automatic change-over function
- Minimised pressure difference between left and right hand side outlet pressure due to Ambimat
- Maximum emptying of gas cylinders
- Designed for easy installation
- Pressure regulator with high control accuracy and integrated relief valve for protection of the device
- Pressure control panels comply with DIN-EN-ISO 14114 and DIN-EN-ISO 15615
- With all BAM-tested safety devices, e.g.:
 - Quick-acting shut-off valve
 - Flashback arrestor
 - optionally: over-pressure valve *
 - optionally: automatic quick-acting shut-off device

Attention:

Acetylene withdrawal systems may need to be certified before commissioning. Always refer to the local rules and regulations regarding such certifications.

Technical data

Type	single-stage
Inlet pressure P_1	max. 25 bar
Outlet pressure P_2	max. 1,5 bar
Change-over pressure P_v	ca. 3 bar
Materials	
Body regulator:	brass
Diaphragm regulator:	EPDM
Valve cone regulator:	PA
Mounting plate:	stainless steel
Ball valve:	steel, zinc-plated
Connection tube:	steel, zinc-plated
Connectors	
Inlets:	M16 x 1,5 male
Outlet flashback arrestor:	1/4"-NPT female
Outlet relief valve:	1/8"-NPT female
Outlet over-pressure valve:	welding stub 14 x 2
Temperature range	+15°C to +60°C
Leak rate	<10 ⁻⁴ mbar l/s He
Weight	15 kg

- * An over-pressure valve cannot be used as an safety accessory according to the Pressure Equipment Directive (PED).

Flow rates for BM65-2A-AC:

The maximum flow rate is approx. 8 sm³/h acetylene.
At an inlet pressure of approx. 4 bar (resembling an acetylene cylinder almost empty) the pressure regulator still yields approx. 5 sm³/h acetylene.


Inlet press. P_1 [bar]	Outlet press. P_2 [bar]		
	0,5	1	1,2
18	5,0 m ³ /h	6,0 m ³ /h	8,0 m ³ /h
10	4,5 m ³ /h	5,5 m ³ /h	6,5 m ³ /h
4	3,0 m ³ /h	4,0 m ³ /h	5,0 m ³ /h
2	1,5 m ³ /h	2,0 m ³ /h	3,0 m ³ /h

The withdrawal rate should not exceed approx. 0,5 sm³/h per cylinder in permanent operation, so no solvent from the cylinder will enter the withdrawal system. However, the flow rate may be increased to approx. 1 sm³/h for brief peak loads.

Pressure control panel BM65-2A-AC

spectro lab

Dimensions - pressure control panel BM65-2A-K-KH-SV-V-C2H2



Ordering information: Pressure control panels BM65-2A-AC

BM65-2A - M - KH - SV - 0 - C2H2

Inlet press. indication

M - Pressure gauge
K - Contact pressure gauge

Quick-acting shut-off

KH - manual quick-acting shut-off device (ball valve)
SSE - automatic quick-acting shut-off device SSE

Individual shut-off

0 - without individual valves
V - with additional ball valves for each individual cylinder

Over-pressure valve

0 - without over-pressure valve
SV - with over-pressure valve

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to DIN ISO 9001.
- All components which come into contact with the medium are cleaned free of oil and grease before the assembly.
- SPECTROLAB - components undergo a 100% leak- and function test.

Important note regarding component selection

- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control panel.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.



Shut-off valves MV3-M

spectro lab



MV3-DV-H-M-NPTF1/4



MV3-DV-PN25/100/300-M-NPTF1/4

Product features

- Brass valves for manual or automatic (pneumatic) shut-off
- For non corrosive gases and gas mixtures up to qualität 6.0
- Diaphragm metal-to-metal sealed to atmosphere
- In- and outlet filter
- Suitable for pressures up to 300 bar
- Fully functional under vacuum
- Ergonomically designed
- New laboratory-style design
- Compact design
- Manual valve with position indicator
- Pneumatic actuator optional for line pressure 25, 100, 200 and 300 bar
- Optional with inductive proximity switch
- Variable installation position

Technical data

Operating pressure	max. 300 bar
Nominal diameter	4 mm
Materials	
Body:	chrome-plated brass
Diaphragm:	Hastelloy C276
Valve seat:	PVDF
Filter:	sintered bronze
Inlet	1/4"-NPT female
Outlet	1/4"-NPT female
Temperature range	-30°C to +60°C
Leak rate	<10 ⁻⁸ mbar l/s He
Weight	0,5 kg
c _v -value	c _v = 0,33 / 0,09*

* with filter (must be installed for the use of oxygen)

Technical data pneumatic actuators

Actuator pressure:	6 to 8 bar
Actuator connector:	for hose Ø 4mm
Pneumatic function:	- normally closed (NC) - normally open (NO)
Option:	- inductive proximity switch

spectro lab

Dimensions shut-off valve MV3

optional:
inductive proximity switch

Dimensions with pneumatic actuator (in mm):

pneumatic actuator	NC	L NO
PN 25	108	98
PN 100	116	106
PN 200	125	115
PN 300	142	132

M6-mounting hole

MV3 - DV - H - M - NPTF1/4

N... -pneumatic actuator **NO / NC**


- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a component.
- The function of the component, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Diaphragm valves DVM

spectro lab



Product features		Technical data	
<ul style="list-style-type: none">• Brass diaphragm valve• For non-corrosive gases and gas mixtures up to quality 6.0• Suitable for pressures up to 40 bar• Fully functional under vacuum• Wide range of in-/ outlets• Metal-to metal sealing to atmosphere• Suitable to use with oxygen• Ergonomically designed		Type	Diaphragm valve
		Working pressure	DN8, DN13: max. 40 bar DN19: max. 25 bar
		Materials	
		Body:	chrome plated brass
		Diaphragm: DN8	stainless steel 1.4571
		DN13/19	stainless steel 1.4310
		In- and outlets	Female thread or stainless steel welding stub
		Temperature range	-30°C to +60°C
		Leak rate	<10 ⁻⁸ mbar l/s He
		Seat diameter	8, 13 or 19 mm
		Flow capacity (c _v)	
		DN8:	1/4"-NPT 1,47
			3/8"-NPT 1,47
			tube 6x1 mm 0,47
			tube 8x1 mm 1,09
			tube 10x1 mm 1,47
			tube 1/4" male 0,64
			tube 3/8" male 1,58
		DN13:	2,1
		DN19:	3,1



Diaphragm valves DVM

spectro lab


Ordering information:
Diaphragm valves DVM

DVM - 13 - NPT F - 1/2

8	13	19
NPT F 1/4* - 1/4"-NPT female	NPT F 1/2 - 1/2"-NPT female	NPT F 3/4 - 3/4"-NPT female
NPT F 3/8* - 3/8"-NPT female	OD 12 - SS-tube 12x1 mm	OD ... - SS-tube upon request
OD 6* - SS-tube 6x1 mm	OD 15 - SS-tube 15x1 mm	
OD 8* - SS-tube 8x1 mm	OD 1/2 - SS-tube 1/2" male	
OD 10* - SS-tube 10x1 mm		
OD 1/4* - SS-tube 1/4" male		
OD 3/8* - SS-tube 3/8" male		

*option:
... SA - with position indicator

Dimensions




Control- and shut-off valves V6M-3 **spectro lab**



Control valve EV-V6M-3

Dimensions: valves V6M-3




Product features

- Available as control valve (e. g. for the pressure regulator outlet)
- High control accuracy
- Shut-off valves (e.g. for in- and outlets of pressure regulators with inert gas purge arrangements)
- Diaphragm metal-to-metal sealed to atmosphere
- Ergonomically designed
- New laboratory-style design
- Compact design

Technical data

Operating pressure	
Control valve:	max. 50 bar
Shut-off valve:	max. 200 bar
Nominal diameter	3 mm
Materials	
Body:	chrome-plated brass
Diaphragm:	Duratherm 600
Control spindle:	SS 1.4404 (SS 316 L)
Inlet connection	1/4"-18 NPT-M
Outlet connection	1/4"-18 NPT-F
Leak rate	<10 ⁻⁸ mbar l/s He
Weight	0,5 kg
Flow rate	see flow curves
c_v-value shut-off valve	c _v = 0,08

Flow curves control valve V6M-3



Control- and shut-off valves V6M-3

spectro lab

Dimensions valves V6M-3

Technical drawing of V6M-3 valves showing dimensions: 78, 52, 25, 50, and connection types 1/4"-18 NPT-M and 1/4"-18 NPT-F.

Detail:
Control valve seat

Detail:
Shut-off valve seat

Ordering information:
V6M-3 series valves

DV - V6M-3 - CV

Type

DV - globe valve
EV - angle valve

Function

AV - shut-off valve
CV - control valve

Article numbers control valves

globe valve	DV-V6M-3-CV:	71801038
angle valve	EV-V6M-3-CV:	71801036

Article numbers shut-off valves

globe valve	DV-V6M-3-AV:	71804363
angle valve	EV-V6M-3-AV:	71804364

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% Helium-leak-test.

Important note regarding component selection

- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a component.
- The function of the component, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.


Tapping points EM55

spectro lab



Tapping point EM55-4

Dimensions EM55-1




Product features

- Wall-mounting tapping points
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Ergonomically designed
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Suitable for ECD-applications
- Pressure regulator with high control accuracy
- Designed for easy installation
- Approved for use with oxygen
- Tapping point can be extended into multiple tapping points
- Top-inlet or bottom-inlet configurations available

Technical data


Inlet pressure P_1	max. 200 bar
Outlet pressure P_2	1,5 / 4 / 10 / 20 / 50 bar
Materials	
Body regulator and valves:	chrome-plated brass
Valve seat regulator:	PA
Valve seat valves:	PVDF
Diaphragm regulator:	Hastelloy C276
Diaphragm valve:	Hastelloy C276
Soft goods:	FKM
Filter:	Sintered SS 316L
Connectors	1/4"-NPT female
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1x10 ⁻⁸ mbar l/s He
(via valve seat)	1x10 ⁻⁶ mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/KI1.6/NG50
Weight	2,5 kg

Flow curves EM55



Tapping points EM55

spectro lab



Ordering information:
Tapping points EM55

Please specify
gas type with order

EM55 - 1 - 40 - 10 - O

Type

- 1 - single tapping point
- 2 - double tapping point
- 3 - triple tapping point
- 4 - 4 tapping points

Inlet pressure P_1

- 40 - 40 bar
- 100 - 100 bar
- 200 - 200 bar

Inlet

- O - top inlet
- U - bottom inlet

Outlet pressure P_2

- 1,5 - 1,5 bar
- 4 - 4 bar
- 10 - 10 bar
- 20 - 20 bar
- 50 - 50 bar
- Higher outlet pressure upon request

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% function- and Helium-leak-test.

Pressure indication

- All pressure regulators are equipped with pressure gauges for outlet pressure indication for the relevant pressure range.

Important note regarding component selection

- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a tapping point.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.


Tapping points EM65

spectro lab



Tapping points EM65-4

Dimensions EM65-1




Product features

- Wall-mounting tapping points
- For non-corrosive gases up to quality 6.0
- Laboratory-style design
- Ergonomically designed
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume with On/Off position indicator
- Suitable for ECD-applications
- Regulator with high control accuracy
- Designed for easy installation
- Tested for use with oxygen
- Tapping point can be extended into multiple tapping points
- Top-inlet or bottom-inlet configurations available

Technical data

Inlet pressure P_1	max. 40 bar
Outlet pressure P_2	1.5 / 4 / 10 / 20 bar
Materials	
Body regulator and valve:	chrome-plated brass
Valve seat regulator:	PA 11
Valve seat shut-off valve:	PVDF
Diaphragm regulator:	SS 301 (SS 1.4310)
Diaphragm valve:	Hastelloy C276
Soft goods:	Viton (FKM)
Filter:	Sintered SS 316L
Connectors	1/4"-18 NPT-F
Temperature range	-30°C to +60°C
Leak rate (to atmosphere)	1×10^{-8} mbar l/s He
(via seat)	1×10^{-6} mbar l/s He
Pressure gauges	Safety pressure gauge EN562 / cl. 1.6 / NG50
Weight	2.5 kg

Flow curves EM65




EM65
Inlet pressure
 $P_1 = 21$ bar

Flow rate
 Q [m³/h air]

Tapping points EM65

spectro lab

Dimensions Tapping points EM65 in multiple installations



Ordering information:
EM65 series tapping points

EM65 - 1 - 40 - 10 - O

Please specify gas
type with your order
(valve seat material)

Type

- 1 - Single tapping point
- 2 - double tapping point
- 3 - triple tapping point
- 4 - 4 tapping points

Inlet pressure P_1

40 - 40 bar

Inlet

- O - Top-inlet
- U - Bottom-inlet

Outlet pressure P_2

1.5 - 1.5 bar
4 - 4 bar
10 - 10 bar
20 - 20 bar
Higher outlet pressure values
upon request

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% function- and Helium-leak-test.

Pressure indication

- All pressure regulators are equipped with pressure gauges for outlet pressure indication for the relevant pressure range.

Important note regarding component selection

- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a tapping point.
- The function of the components, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Compact laboratory tapping points EM15: for non-corrosive gases EE15: for corrosive gases

Surface-mounted

Laboratory equipment with rear wall inlet and front outlet



Type AW

Surface-mounted angle

Laboratory equipment with rear wall inlet and rear outlet



Type AE

Panel-mounted

Laboratory equipment with rear wall inlet and rear outlet



Type EP

Valves / wall outlets

Laboratory equipment with rear wall inlet and front outlet



Type AW / EP

Panel-mounted front

Laboratory equipment with rear wall inlet and front outlet



Type EF

Wall-mounted

Laboratory equipment for wall mounting (surface-mounted pipework)



Type ES

Column-mounted

Column-mounted laboratory equipment and front outlet



Type SC

Ceiling-mounted

Laboratory equipment with top inlet and front outlet



Type DC

Compact laboratory tapping points EM15 / EE15

spectro lab



with control / shut-off valve



without valve (long)



without valve



blind without regulator

Specifications

- The special laboratory tapping points incorporate the functions shut-off, pressure regulation and pressure indication in one compact, ergonomic unit.
- EM15: for non-corrosive gases up to quality 6.0
- EE15: for corrosive gases and gas mixtures with corrosive components up to quality 6.0
- The pressure regulator is diaphragm sensed for outlet pressures up to 10 bar and piston sensed for higher outlet pressure values.
- The acetone resistant pressure gauge is safely integrated into the adjusting hand wheel to create an extremely compact device.
- Integrated shut-off valve in the rear-wall connector allows the preparation of the tapping point without pressure regulator.
- Quick and easy mounting or disassembly of the regulating unit with filled gas piping.
- Diaphragm shut-off valve with position indicator
- Optional flow control / shut-off valve in the outlet
- All gas-wetted components have undergone the special SPECTROCLEAN® cleaning process and have been thoroughly baked out.
- For ECD-applications the devices can be treated in an extended cleaning process.
- All equipment has been 100%-helium-leak-tested using a mass-spectrometer.
- All components are plastic-covered resistant to acid and alkaline solutions.
- Acetylene version optional with flashback arrester.

Technical data

Materials

Body	M15:	brass
	E15:	SS 1.4404 (316L)
Diaphragms:		Hastelloy C276
other gas wetted surfaces:		brass or SS 1.4404 (316L)
Valve cone:		SS 1.4404 (316L)
Valve seat:		PTFE
Cover:		Polypropylene GB30

Leak rate

(to atmosphere): 10^{-8} mbar l/s He

Filter

150 μ m

Pressure ranges

Inlet P_1 (P_2 up to 10 bar): max. 40 bar
 ($P_2 > 10$ bar): max. 100 bar
 max. outlet pressure P_2 : 1,0 / 1,5 / 2,5 / 5 / 10 / 16 / 25 / 65 bar

P_2 up to 10 bar: The pressure setting will be done at 10 bar inlet pressure. The limitation of the outlet pressure setting is approx. $P_2 + 5\%$.





$P_2 > 10$ bar: The inlet pressure for the pressure setting will be done according to the customer's / user's specification.

Flow rates

see flow curves

with valve in the outlet

Connection to rear-wall G 3/8" RH connector




EM15 / EE15 Surface-mounted Type AW

spectro lab



Surface-mounted tapping point
with flow control / shut-off valve



*) for self-cutting screw
ME-T-50-16-TX25-A2-DIN7500

Bore template for installation

Specifications

- The surface-mounted tapping point is used for installations into panels independent of the panel thickness.
- The surface-mounted version consists of a rear-wall connector made of brass or stainless steel respectively, a round faceplate and assembly accessories.

Technical data



Materials

Rear-wall connector: brass or
SS 1.4404 (316L)
Covers: Polypropylene GB30

Connections inlet: see ordering info
outlet: 1/4"-NPT female

Weight ca. 0.8 kg

Surface-mounted type with valve in the outlet



Rear wall connector - see page 12


EM15 / EE15

Surface-mounted angle Type AE

spectro lab



Surface-mounted angle tapping point
with flow control / shut-off valve



Bore template for installation

*) for self-cutting screw
ME-T-50-16-TX25-A2-DIN7500

Specifications

- The surface-mounted tapping point is used for installations into panels independent of the panel thickness.
- The surface-mounted angle version consists of a rear-wall connector made of brass or stainless steel respectively, a round faceplate and assembly accessories.
- The rear outlet leads back into the panel.

Technical data



Materials

Rear-wall connector: brass or
SS 1.4404 (316L)
Covers: Polypropylene GB30

Connections inlet: see ordering info
outlet: 1/4"-NPT female

Weight ca. 0.8 kg

Surface-mounted angle type with valve in the outlet




EM15 / EE15 Panel-mounted Type EP

spectro lab



Panel-mounted tapping point
with flow control / shut-off valve



Bore template for installation


Specifications

- The panel-mounted tapping point is used for installations into panels between 2 and 8 mm thick.
- The panel-mounted version consists of an inlet adaptor made of brass or stainless steel respectively with 1/4"-NPT female thread, a plastic holder, a round faceplate (2-5 mm panel) and assembly accessories.


Technical data

Materials	
Inlet adaptor:	brass or SS 1.4404 (316L)
Holder:	Polypropylene GB30
Covers:	Polypropylene GB30
Connections	inlet: 1/4"-NPT female
	outlet: 1/4"-NPT female
Weight	ca. 0.8 kg

Panel-mounted type with valve in the outlet



Front view with recommended modular dimensions




Side view with interface dimensions for a panel 2 mm thick

EM15 / EE15 Panel-mounted front Type EF

spectro lab



Panel-mounted front tapping point with
flow control / shut-off valve



Bore template for installation


Specifications

- The panel-mounted tapping point is used for installations into panels between 2 and 8 mm thick.
- The front version consists of an inlet adaptor made of brass or stainless steel respectively with 1/4"-NPT female thread, a plastic holder, a round faceplate (2-5 mm panel) and assembly accessories.
- The outlet is to the front.


Technical data

Materials	
Inlet adaptor:	brass or SS 1.4404 (316L)
Holder:	Polypropylene GB30
Covers:	Polypropylene GB30
Connections	inlet: 1/4"-NPT female
	outlet: 1/4"-NPT female
Weight	ca. 0.8 kg

Panel-mounted front type with valve in the outlet



Front view with recommended modular dimensions




Top view with interface dimensions for a panel 2 mm thick

EM15 / EE15 Ceiling-mounted Type DC

spectro lab



Ceiling-mounted tapping point
with flow control / shut-off valve



*) for self-cutting screw
ME-T-50-16-TX25-A2-DIN7500

Bore template for installation

Specifications

- The ceiling-mounted tapping point is used for installations at the ceiling.
- The ceiling-mounted version consists of a rear-wall connector made of brass or stainless steel respectively with an 1/4"-NPT female inlet, plastic covers, washer, a round faceplate and assembly accessories.

Technical data



Materials

Rear-wall connector	Brass
P ₁ up to 40 bar	SS 1.4404 (316L)
P ₁ > 40 bar	Polypropylene GB30
Covers:	Polypropylene GB30
Washer:	Polypropylene GB30

Connections	inlet:	1/4"-NPT female
	outlet:	1/4"-NPT female

Weight	ca. 1.2 kg
---------------	------------

Ceiling type with valve in the outlet



EM15 / EE15 Column-mounted Type SC



**Column-mounted tapping point
with flow control / shut-off valve**

Specifications

- The column-mounted tapping point is used for installations on laboratory benches up to approx. 90 mm thickness.
- The column-mounted version consists of a metal column body, a metal connector with a tube (6x1 mm), plastic washer, plastic covers, a round faceplate and assembly accessories.
- The plastic covers of the metal column are acid and alkaline solutions resistant.

Technical data


Materials

Connector:	SS 1.4404 (316L)
Tube:	SS 1.4404 (316L)
Column body:	Aluminium
Washer:	Polypropylene GB30
Covers:	Polypropylene GB30

Connections	inlet:	tube 6x1 mm
	outlet:	1/4"-NPT female

Weight	ca. 1.8 kg
---------------	------------

Column-mounted type with valve in the outlet




EM15 / EE15
Wall-mounted Type ES

spectro lab



Wall-mounted tapping point
with flow control / shut-off valve

Ø 8 (2x) for plug Ø 8 mm



Bore template for installation


Specifications

- The wall-mounted tapping point is used for installations with surface-mounted pipe work.
- The wall-mounted version consists of a metal wall connector to connect both the gas line and the tapping point, a round faceplate and plastic covers.

Technical data

Materials	
Wall connector:	brass or SS 1.4404 (316L)
Covers:	Polypropylene GB30
Connections	inlet: 1/4"-NPT female
	outlet: 1/4"-NPT female
Weight	ca. 1.0 kg

Wall-mounted type ES




VM15 / VE15 Flow control / shut-off valves

spectro lab



Flow control / shut-off valve for surface mounting (angle) and panel mounting (globe version)



*) for self-cutting screw ME-T-50-16-TX25-A2-DIN7500

Bore template for surface mounting (left) and panel mounting (right)

Specifications

- The flow control and shut-off valves are also available in addition to the laboratory tapping points.
- The valves come as surface- or panel-mounted type.
- There is a globe and an angle version in brass or stainless steel available.
- The valves are suitable for pressure ranges up to 100 bar

Technical data


Materials

Body, flow control spindle: brass or SS 1.4404 (316L)
Valve seat: PTFE
Diaphragm: Hastelloy C276
Covers: Polypropylene GB30
Spring: Stainless steel 1.4310

Connections inlet: see drawings below
outlet: 1/4"-NPT female

Leak rate (to atmosphere) 10^{-8} mbar l/s He

Valves for surface- and panel mounting




AM15 / AE15 Wall outlets

spectro lab



Surface-mounted wall outlets
(angle and globe version)



Bore template for wall outlet (surface-mounted)

*) for self-cutting screw ME-T-50-16-TX25-A2-DIN7500

Specifications

- The wall outlets are also available in addition to the laboratory tapping points.
- The outlets come as surface-mounted type.
- There is a globe and an angle version in brass or stainless steel available.

Technical data


Materials

Body:	brass or SS 1.4404 (316L)
Valve seat:	PTFE
Covers:	Polypropylene GB30
Spring:	SS 1.4310

Connections	inlet:	see drawings below
	outlet:	1/4"-NPT female

Leak rate (to atmosphere)	10 ⁻⁸ mbar l/s He
---------------------------	------------------------------

Wall outlet (globe and angle version)



*) for self-cutting screw ME-T-50-16-TX25-A2-DIN7500

EM15 / EE15 Rear-wall connectors



spectro lab





Rear-wall connectors (for surface-mounting AW and AE) with integrated shut-off valve

Bore template and dimensions




1/4"-NPT female / 7 mm wall thickness (rear installation)



1/4"-NPT female / 30 mm wall thickness (rear installation)



1/4"-NPT female + M24x1 male (front installation)



EM15 / EE15 Ordering information

spectro lab

Ordering information: Tapping points EM15 / EE15 series

EM 15 - AW - 10 - 0 - V - Ar/H2

Material

M	Brass
E	Stainless steel

Type

AW	Surface-mounted
AE	Surface-mounted angle version
EP	Panel-mounted
EF	Panel-mounted front
DC	Ceiling-mounted
SC	Column-mounted
ES	Wall-mounted
GG	Basic regulator w/o rear-wall conn. (G 3/8" RH)

Pressure range

1,0	max. outlet pressure 1,0 bar
1,5	max. outlet pressure 1,5 bar
2,5	max. outlet pressure 2,5 bar
5	max. outlet pressure 5 bar
10	max. outlet pressure 10 bar
16	max. outlet pressure 16 bar (piston version up to $P_{1,max.} = 100$ bar)
25	max. outlet pressure 25 bar (piston version up to $P_{1,max.} = 100$ bar)
65	max. outlet pressure 65 bar (piston version up to $P_{1,max.} = 100$ bar)
0	Rear-wall connector incl. shut-off valve without pressure regulator

Gas type

Please specify with order

Outlet

0	1/4"-NPT female
CM3/6/...	Compression ring brass [DN]
CE3/6/...	Compression ring SS [DN]
SM	Hose connector brass
SE	Hose connector SS
CSM(E)	Compr. ring+hose connector
FS	Flashback arrestor

L	1/4"-NPT female (long)
LCM3/6/...	Compression ring brass [DN]
LCE3/6/...	Compression ring SS [DN]
LSM	Hose connector brass
LSE	Hose connector SS
LCSM(E)	Compr. ring+hose connector

V	Valve (1/4"-NPT female)
VCM(E)6	Valve with compression ring
VSM(E)	Valve with hose connector
VCSM(E)	Valve + compression ring and hose connector
B	Blind w/o pressure regulator

Inlet

0	EP/EF: 1/4"-NPT female
0	DC/ES: 1/4"-NPT female
L7	AW/AE: 1/4"-NPT f / 7 mm
L30	AW/AE: 1/4"-NPT f / 30 mm
NPT	AW/AE: 1/4"-NPT female + M24x1 male
CM6/8/...	Compression ring brass [DN]
CE6/8/...	Compression ring SS [DN]
CM(E)6w	angle compression ring [DN]
RS	SC: SS-tube stub 6x1 mm
X	without rear-wall connection



Ordering information: Valve / Wall outlet

VM 15 - AW - 0 - EV - 0 - Ar/H2

Model

V	Valve
A	Wall outlet

Material

M	brass
E	Stainless steel

Type

see above	
GG	Basic unit w/o rear-wall conn. (G 3/8" RH)

Gas type (see above)

Outlet (see above)

Version

DV	Globe version
EV	Angle version

Inlet (see above)



Spectrolab[®] plus Configurations / Overview

spectro lab



Basic unit with integrated shut-off-valve, pressure regulator and pressure gauge; pressure ranges, flow charts, materials, dimensions

Basic unit

Type GG

Ordering information



Laboratory equipment with rear-wall inlet and front outlet;
Connectors, materials, dimensions / drawing / template

Surface-mounted systems

Type AW

Ordering information



Laboratory equipment with rear-wall inlet and rear-wall outlet;
Connectors, materials, dimensions / drawing / template

Panel-mounted systems

Type EP

Ordering information



Laboratory equipment with top inlet and front outlet;
Connectors, materials, dimensions / drawing / template

Ceiling-mounted systems

Type DC

Ordering information



Column-mounted laboratory equipment (bottom inlet, front outlet);
Connectors, materials, dimensions / drawing / template

Column-mounted systems

Type SC

Ordering information



Wall-mounted laboratory tapping points (surface-mounted pipework);
Connectors, materials, dimensions / drawing / template

Wall-mounted systems

Type ES

Ordering information



Flow control valves in different configurations;
Connectors, flow charts, materials, dimensions / drawings / template

Flow control valves

Ordering information



In-/outlet fittings, hose connectors, wall outlets, etc.;
Materials, dimensions

Accessories


Ordering information

Spectrolab® plus Basic unit Type GG

spectro lab



Basic unit brass up to 10 bar with adapter 1/4" NPT



Specifications

- Spectrolab® plus - systems incorporate the functions shut-off, pressure regulation and pressure indication in one compact, ergonomic unit.
- The pressure regulator is diaphragm sensed for outlet pressures up to 10 bar and piston sensed for higher outlet pressure values.
- The acetone resistant pressure gauge is safely integrated into the adjusting handwheel to create an extremely compact device.
- The diaphragm-type shut-off valve engages in the open and closed position respectively and has an additional indicator on the adjusting knob.
- All gas-wetted components have undergone the special SPECTROCLEAR® cleaning process and have been thoroughly baked out.
- For ECD-applications the devices can be treated in an extended cleaning process.
- All equipment has been 100%-helium-leak-tested using a mass-spectrometer.
- All components are plastic-coated resistant to acid and alkaline solutions.

Technical data

Materials

Body:	M55:	brass or
	E55:	SS 316L (1.4404)
Diaphragms:		Hastelloy C276
Other gas-wetted surfaces:		brass or
		SS 316L (1.4404)
Valve stem:		SS 316L (1.4404)
Valve seat:		PTFE
Body coating:		Polypropylene GF30

Leak rate

(to atmosphere): 10^{-8} mbar l/s He

Pressure ranges





Inlet pressure P_1 ($P_2 \leq 10$ bar): 40 bar max.
 $(P_2 > 10$ bar): 60 bar max.
 max. outlet pressure P_2 : 1,5 / 5 / 10 / 50 bar

Flow rates: see flow charts

Weight

$(P_2$ up to 10 bar): 700 (SS)-750g (brass)
 $(P_2 > 10$ bar): 800 (SS)-850g (brass)

Connectors/Porting Inlet: G 3/8" RH female
 Outlet: 1/4"-NPT-female




Spectrolab[®] plus Surface-mounted Type AW

spectro lab




Basic unit c/w flow control valve (outlet 1/4"-NPT-female) and surface-mounting kit

Rear-wall connector with tube stub 8x1:



Notice:
Do not use rear-wall connectors with Cu-tubes for acetylene!

Rear-wall connector with NPT-female thread:



Specifications

- The surface-mounting kit for Spectrolab[®] plus systems is used for installations into panels between 2 mm and 8 mm.
- The mounting kit consists of a rear-wall connector made of brass or stainless steel respectively, a round fascia plate and small parts for the assembly (screws etc.).
- The rear-wall connector either has a 1/4"-NPT female thread or a tube (copper or stainless steel respectively) on the inlet side.

Technical data

Materials:

Rear-wall connector: brass + Cu-tube or SS 316L (1.4404)

Fascia plate: Polypropylene

Connectors/Porting: Outlet: 1/4"-NPT female
Inlet thread: 1/4"-NPT female
Inlet tube: Tube 8 x 1 mm
Tube length L: 750 mm (Cu-tube)
510 mm (SS 316L)




Figure: Complete surface-mounting kit (mounted position)

Surface-mounting equipment for panels from 19-25 mm thickness:

For panels between 19 and 25 mm thickness an extension of the rear-wall connector has to be used. Available in brass or in stainless steel 316L.

The minimum required bore for the extended rear-wall connector is 21 mm.




Spectrolab® plus Panel-mounted systems Type EP

spectro lab



Panel-mounting kit c/w basic unit and flow control valve (mounted position)



Left: Panel-mounting kit c/w basic unit - front view with recommended dimension for multiple installations. Right: Bore template for the installation

Specifications

- The panel-mounting kit for Spectrolab® plus systems is used for installations into panels between 2 and 8 mm thick.
- The panel-mounting kit consists of an inlet adaptor with 1/4"-NPT female thread, an (internal) plastic holder, a plastic fascia plate and small parts for the assembly (screws, stickers etc.).

Technical data


Materials:

Inlet adaptor:	Brass or SS 316L (1.4404)
Holder:	Polypropylene GF30
Fascia plate:	Polypropylene


Connectors / Porting:

Inlet:	G 3/8" RH female
Outlet:	1/4"-NPT female

Installation examples panel-mounting systems:



Basic unit c/w flow control valve (outlet 1/4"-NPT-female) and panel-mounting kit. Interface dimensions for a panel 2 mm thick




Basic unit c/w flow control valve (outlet 1/4"-NPT-female) and panel-mounting kit. Interface dimensions for a panel 8 mm thick

Spectrolab[®] plus Ceiling-mounted systems Type DC

spectro lab



Basic unit c/w flow control valve (outlet 1/4"-NPT female) and ceiling-mounting kit.



Basic unit c/w flow control valve and ceiling-mounting kit (mounted position)

Specifications

- The ceiling-mounting kit for Spectrolab[®] plus systems is used for installations the ceiling.
- The ceiling-mounting kit consists of a rear-wall connector, a plastic cover (two parts), a plastic washer and small parts for the assembly (screws, nuts etc.).
- The rear-wall connector has a 1/4"-NPT female thread on the inlet side.

Technical data

Materials:

Rear-wall connector:	Brass or SS 316L (1.4404)
Cover:	Polypropylene GF30
Washer:	Polypropylene GF30


Connectors/Porting:

Inlet:	1/4"-NPT female
Outlet:	1/4"-NPT female



Ceiling-mounting kit (mounted position)

Ceiling-mounting systems - Bore template (view from the top)




For ceilings thicker than 6 mm longer fastening screws are required!

Spectrolab[®] plus Column-mounted systems Type SC

spectro lab



Basic unit c/w flow control valve (outlet 1/4"-NPT-female) and column-mounting kit



Specifications


- The column-mounting kit for Spectrolab[®] plus systems is used for bench-mounting installations up to approx. 90 mm thickness.
- The column-mounting kit consists of a metal column body, a metal connector with a tube (8x1 mm), a plastic washer, a plastic cover and small parts for the assembly.
- The column body is plastic-coated and resistant to acid and alkaline solutions.

Technical data

Materials	
Connectors:	Brass + Cu-tube or SS 316L (1.4404)
Column body:	Aluminium
Washer, coating:	Polypropylene GF30
In- / Outlets	
Inlet:	tube 8 x 1 mm
Outlet:	1/4"-NPT female
Installation length L	
Brass (c/w Cu-tube):	approx. 700 mm
Brass (c/w SS-tube):	approx. 475 mm
SS 316L:	approx. 475 mm



Column-mounting kit (mounted position)



For a column-type installation into laboratory furniture a bore of at least 25 mm diameter is required.

UTTAKSPOST

EM55 SPECTROLAB PLUS




Spectrolab[®] plus Tapping points Type ES

spectro lab



Basic unit c/w globe-type flow control valve (outlet 1/4"-NPT-female), wall-mounting kit and inlet fitting



Specifications

- The wall-mounting kit for Spectrolab[®] plus systems is used for installations with surface-mounted pipework
- The wall-mounting kit consists of a plastic wall-cover, a plastic space cover, small parts for the assembly (screws, washers etc.) and a wall connector to connect both the gas line and the Spectrolab[®] plus device.

Technical data

Materials:

Wall connector:

Brass or
SS 316L (1.4404)

Wall cover:

Polypropylene

Space cover:

Polypropylene

Connections/Porting: Inlet: 1/4"-NPT female

Outlet: 1/4"-NPT female



Wall-mounting kit c/w inlet fitting

Example tapping point



Basic unit c/w outlet adaptor (1/8"-male to 1/4"-18 NPT-female), wall-mounting kit and inlet fitting


Spectrolab® plus Flow control valves

spectro lab



Left figure: Angle-type flow control valve (outlet 1/4"-NPT female) c/w rear-wall connector, coupling nut and plastic fascia plate

Right figure: Globe-type flow control valve (outlet 1/4"-NPT female) c/w rear-wall connector, coupling nut and plastic fascia plate



Top: Angle type flow control valve (outlet 1/4"-NPT female) c/w coupling nut.

Right: Globe-type flow control valve (outlet 1/4"-NPT female) c/w coupling nut.

Specifications

- The Spectrolab® plus - flow control valve is either used as part of the basic unit (fig. 1a/b), as a panel-mounted valve (fig. 2a/b, w/o basic unit) or as a tapping-point flow control valve (fig. 3a/b, w/o basic unit).
- The Spectrolab® plus - flow control valve is available in globe- (a) and in angle-configuration (b) in brass or in stainless steel 316L.

Fig. 1a/b: Globe-/Angle- flow control valve for the basic unit

Fig. 2a/b: Globe-/Angle- valve (panel-mounting EP)

Fig. 3a/b: Globe-/Angle- valve (tapping point)

Technical data

Materials:

Body, flow control spindle: Brass or SS316L (1.4404)
Valve seat: PVDF
Diaphragm: Hastelloy C276
Body coating: Epoxy coated
Spring: SS (1.4310)

Connectors/Porting:

Inlet: see drawings below
Outlet: 1/4"-NPT female

Leak rate (to atmosphere): 10^{-8} bar cm^3/s He

Flow rates: see flow chart (fig. 4)

fig. 1a:




fig. 1b:




fig. 2a:




fig. 4:




fig. 2b:




fig. 3a:





fig. 3b:



Spectrolab[®] plus Accessories

spectro lab



fig. 1

In- / outlet fittings

fig. 1

**Compression ring fittings
1/4"-NPT external thread
to tube-diameter:**

part no.:

	Brass:	SS:
3 mm, straight	0.291.284	0.291.281
6 mm, straight	0.291.283	0.291.280
8 mm, straight	0.049.106	0.049.033
10 mm, straight	0.291.282	0.291.279
3 mm, angle	0.291.317	0.291.320
6 mm, angle	0.291.316	0.291.319
8 mm, angle	0.049.107	0.049.035



fig. 2

Hose connectors

fig. 2

6 mm tube stub
(for compression ring fitting)
1/4"-NPT male

Brass:	SS:
0.400.032	0.400.031
717.02219	717.02218 (chrome plated)



fig. 3a

fig. 3b

Flashback arrestor (for fuel/flammable gas)

fig. 3a

For fuel/flammable gas applications
(Outlet 1/4"-NPT female)

Brass:
717.05888

Wall outlets

fig. 3b

Wall-outlet (outlet 1/4"-NPT female)

Brass:	SS:
717.07261	717.07262 (90°-angle)



fig. 4a

fig. 4b

Adaptors

fig. 4a, b

a) Extension rear-wall-connector
b) Outlet adaptor 1/8"-NPT male
to 1/4"-NPT female

Brass:	SS:
717.07167	717.07168
717.07163	717.07164




fig. 5a

fig. 5b

Levers, Gas type labels

fig. 5a, b

a) Levers	717.08591
b) Gas type labels:	
C ₂ H ₂ , N ₂ O, CB, NH ₃ , CO ₂ , DL:	717.08770
CH ₄ , CH ₄ /Ar, H ₂ /N ₂ , H ₂ /He, W1, W2:	717.08771
Ar/H ₂ , additional gases W3, W4:	717.08772
CA(compressed air), SA(syntetic air):	717.08773
Ar: 717.08972	He: 717.08973 (includes one label
O ₂ : 717.08974	H ₂ : 717.08975 for the pressure
SL: 717.08976	N ₂ : 717.08977 regulator and one
CO ₂ : 717.08978	CO: 717.08958 for the valve)
BA: 717.08959	C ₂ H ₄ : 717.09660

Spectrolab® plus

Ordering information

spectro lab



Ordering example:

E 55 series laboratory system Spectrolab plus

E M 55 - AW - 10 - 0 - CV - Ar/H₂



Ordering example inlet:
Rear-wall-connector with 1/4"
NPT-female thread

Material

M - Brass
E - Stainless steel

Configuration type

GG - Basic unit
AW - Surface-mounted
EP - Panel-mounted
DC - Ceiling-mounted
SC - Column-mounted
ES - Wall-mounted

Pressure range

1,5 - max. outlet press. 1,5 bar
5 - max. outlet press. 5 bar
10 - max. outlet press. 10 bar
50 - max. outlet press. 50 bar

*Note: Not all combinations are available!
Please refer to the data sheet for the
respective configuration! - Especially for
acetylene applications the rear-wall
connector with copper tubing must not
be used!*

Gas type

Please specify with your order

Outlet

0 1/4"-NPT-female
CM3,6... Compression ring brass [D_n]
CE3,6... Compression ring stainless steel [D_n]
SM Hose connector brass
SE Hose connector stainless steel
CSM(E) Comp. ring fitting c/w hose connector
CV Control valve only
VCM(E)6 Valve c/w comp. ring fitting
VSM(E) Valve c/w hose connector
VCSM(E) Valve c/w comp. ring and
hose connector

Inlet

0 G3/8"-female
NPT 1/4"-NPT female
CM3,6... Compr. ring brass [D_n]
CE3,6... Compr. ring stainless steel [D_n]
CM(E)6w Angle compr. ring [D_n]
RS Tube stub 8 x 1 mm



Ordering example:

55 series Valve Spectrolab plus

V M 55 - AW - 0 - EV - 0 - Ar/H₂



Ordering example inlet:
Rear-wall-connector with 1/4"
NPT-female thread

Materials (see above)

Configuration (s. a.)

Inlet (see above)

Gas type (see above)

Outlet (see above)

Valve type

DV - Globe valve
EV - Angle valve



Ordering example:

55 series wall-outlet Spectrolab plus

A M 55 - AW - 0 - 0



Ordering example inlet:
Rear-wall-connector with 1/4"
NPT-female thread

Materials (see above)

Configuration

AW - Wall-mounted only

Outlet (see above)

Inlet (see above)

Tapping point EM65-AC

spectro lab



Tapping point EM65-AC

Flow rates EM65-AC



Acetylene Inlet pressure (P ₁) [bar]	Flow rate [m ³ /h] @ outlet pressure (P ₂) [bar]		
	0,3	0,5	1
1,3	0,2	0,5	1

Product features

- Wall-mounting tapping point for acetylene
- Laboratory-style design
- Ergonomically designed
- Filter at the process gas inlet valve
- Diaphragm-type shut-off valves optimised for low internal volume
- Pressure regulator with high control accuracy
- Designed for easy installation
- Tapping point can be extended into multiple tapping points
- Safety devise (flashbach arrestor) in the outlet

Technical data

Inlet pressure P ₁	max. 1,5 bar
Outlet pressure P ₂	1,5 bar
Materials	
Body regulator and valves:	brass
Valve seat regulator:	PA
Diaphragm regulator:	EPDM
Diaphragm valve:	Hastelloy C276
Filter:	Sintered SS 316L
Connectors	1/4"-NPT female
Temperature range	-30°C to +60°C
Leak rate	< 10 ⁻³ mbar l/s He
Pressure gauges	Safety pressure gauges ISO5171/K11.6/NG50
Weight	2,6 kg




Flowmeter FLM32

spectro lab



Flowmeter
FLM32

Dimensions



Product features

- Flowmeter for use on pressure regulators with inert high-purity gases up to quality 6.0 for exact adjustment and indication of the flow rate
- Laboratory-style design
- Ergonomical and compact design
- With integrated control valve

Technical data

Inlet pressure (2 types): 1,4 or 4 bar resp.

Materials

Body: chrome-plated brass
Soft goods: Viton (FKM)
Flowmeter: glass
Outer tube: Polycarbon
Control spindle: Stainless steel

Connectors

Inlet: 1/4"-NPT male
Outlet: 1/4"-NPT female

Temperature range -30°C to +60°C

Leak rate (to atmosphere) 1×10^{-6} mbar l/s He

Weight ca. 0,4 kg

Table of flow rates for FLM32 with %-scale at 1,4 bar and 4 bar resp.
Flow rates at full scale (blue figures for a calibrating pressure of 1,4 bar)

Inlet pressure (bar gauge)	l/h nitrogen at a calibrating pressure	
[bar]	4 bar	1,4 bar
0,5	164	237
1	190	274
1,4	208	300
2	232	-
2,5	251	-
3	268	-
3,5	285	-
4	300	-

Example: gas type nitrogen

With an outlet pressure of 1,4 bar set at the pressure regulator the control valve is opened until the top of the ball is level with the 100% mark on the metering glass. Now 300 l/h N₂ flow through the flowmeter. At 50 % this means 150 l/h etc. The setting should not be below the 10% mark.

For Outlet pressure values P_{SOLL} below the calibrating pressure P_{KAL} the 100%-flow rate may be calculated using **Equation a)**, where the pressure values must be applied in **absolute pressure** values.

For other gas types the 100%-flow rate for the applicable outlet pressure and calibrating pressure can be calculated from the N₂ flow rate using **Equation b)**.

The **factor f_2** (see table) can be calculated using

$$f_2 = \sqrt{\frac{\text{density}_{\text{reference gas}}}{\text{density}_{\text{process gas}}}}$$

where density_{reference gas} is the density of nitrogen.

Equation a) $Q = f_1 \times Q_{100\%}$

with $f_1 = \sqrt{\frac{P_{SOLL}}{P_{KAL}}}$
P ⇒ absolute

For other gases:

Equation b) $Q = f_2 \times Q_{N_2}$


factor f_2

synth. air	0.983	argon	0.837
CO ₂	0.792	hydrogen	3.75
methane	1.32	helium	2.63
oxygen	0.965		

Flowmeter FLM32


spectro lab

Sectional drawing



Ordering information:
Flowmeter FLM32

FLM32 - 1,4



Series

FLM32 - Flowmeter FLM32

Calibrating pressure

1,4 - 1,4 bar
4 - 4 bar

Specifications

- SPECTROLAB - components guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% Helium-leak-test.

Important note regarding component selection

- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a control valve.
- The function of the valve, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

Pigtails / Cylinder brackets

spectro lab

Additional configurations upon request!

Ordering information:
Pigtails for BM/BE series pressure control panels

SR - 200 - DIN 10 - N₂

Type

SR - pigtails for BM/BE series pressure control panels

Nominal pressure

200 - max. 200 bar
300 - max. 300 bar (CEN)

Gas type

Please specify gas type (gasket material selection)

Cylinder connection

Detailed description of the cylinder connection (e. g. BS no. 3 for 200 bar or ISO 30 for 300 bar)

Product features cylinder brackets:

- Cylinder bracket to protect gas cylinders against falling and to position the cylinder
- Suitable for 20-ltr- and 50-ltr gas cylinders

Technical data


Materials

Bracket: cast aluminium, blasted
Chain: zink-plated Steel

Depth T 20 l cylinder: 130 mm
50 l cylinder: 180 mm

Ordering no. 718.32028

Figures: Cylinder bracket in front and top view
Figure right: Chain



Specifications

- SPECTROLAB - pigtails guarantee maximum quality by using high grade materials and a quality assurance program acc. to ISO 9001.
- All components which come into contact with the medium are cleaned in an ultrasonic cleaning system (CFC-free) with the special cleaning process SPECTRO-CLEAN® and are then baked out.
- SPECTROLAB - components undergo a 100% function- and Helium-leak-test.

Manual connectors

- All pigtails with DIN cylinder connections for non-corrosive gases and the pigtails with 300 bar (CEN-) connectors come with manual connectors (DIN: plastic handwheel on hex nut; CEN: knurled nut). Pigtails with connectors acc. to other standards come with a hex nut.

Important note regarding component selection

- In order to assure safe operation it is essential to take the configuration of the whole system into account when selecting a pressure regulator.
- The function of the regulator, the compatibility of the materials, correlating temperature ranges, correct installation, operation and maintenance in accordance with the relevant regulations are the responsibility of the system designer and the user.

High pressure hoses HDS

spectro **tec**

Product features

- Quality high pressure hoses for non-corrosive industrial gases, oxygen and acetylene
- 90° elbow on inlet
- Design in all essential points according to DIN EN ISO 14113 (Rubber and plastics hose)
- Design in all essential points according to EN ISO 10380 (Corrugated metal hose)
- Anti-whip cord (not for acetylene)
- Non-return-valve at cylinder- or bundle connection for acetylene to avoid air getting into the hose

Technical data

Working pressure P	max. 300 bar max. 25 bar (Acetylene)
Nominal diameter	DN 6 - DN 12
Length	0,5 - 3,5 m
Materials	
<u>Industrial gases</u>	
Inner surface:	Polyester
Outer surface:	Polyurethane
Reinforcement:	Aramid fibre
Fitting:	1.4305
<u>Oxygen:</u>	stainless steel
<u>Acetylene:</u>	rubber
Connections	
Inlet:	cylinder connection or 1/4"-NPT female
Outlet:	1/4"-NPT female
Temperature range	-20°C to +60°C
Leak rate	<10 ⁻³ mbar l/s He

High pressure hose HDS - PE for industrial gases except oxygen and acetylene



Ordering information:

High pressure hose for **industrial gases** except oxygen and acetylene HDS - PE

HDS - PE - 300 - 3,5M - DIN 477-6 - 0 - CM 1/4

Pressure range

200 - 200 bar
300 - 300 bar

Length

0,5M - 0,5 meter (DN 8)
1M - 1,0 meter (DN 8)
2M - 2,0 meters (DN 8)
3,5M - 3,5 meters (DN 8)

Inlet

Cylinder- or bundle connection:
Specify relevant standard and
connection type required

Outlet

Compression fitting (brass)
CM 1/4 - 1/8" / 1/4" / 1/2" -
CM 6 - 3/6/8/10/12 mm
Compression fitting (stainless steel)
CE 1/4 - 1/8" / 1/4" / 1/2" -
CE 6 - 3/6/8/10/12 mm
KK 1/2 - G 1/2" bull nose+union nut
0 - 1/4"-NPT female

Cylinder connection

0 - brass
M - chrome plated brass

[illegible]

[illegible]

[illegible]



iTec AS

Hegdalveien 80
3261 Larvik
Tlf. (+47) 95 800 700
itec@itec.as

ET FØRSTEVALG FOR INDUSTRIEN